

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Pix Star](#) /

› [PixStar 15 inch Large Digital Frame WiFi | Free Unlimited Cloud | Share Videos and Photos by Email or App | Motion Sensor | Best USNews Digital Photo Frame 2024 | Large Electronic Picture Frame User Manual](#)

Pix Star PXT515WR08

PixStar 15 inch Large Digital Frame User Manual

Brand: Pix Star

Model: PXT515WR08

INTRODUCTION

Thank you for choosing the PixStar 15 inch Large Digital Frame. This device allows you to display your cherished photos and videos with ease, offering features like unlimited cloud storage, a motion sensor, and multiple ways to load content. This manual will guide you through the setup, operation, and maintenance of your new digital frame.



Free Cloud storage

15"



The PixStar 15 inch Digital Frame, showcasing its large display, included remote control, and the companion mobile application for easy photo uploads.

WHAT'S IN THE Box

Upon unboxing your PixStar Digital Frame, please ensure all the following items are present:

- PixStar Digital Frame
- AC Adapter
- User Guide (this document)

SETUP

Initial Power On and Wi-Fi Connection

1. Connect the AC adapter to the frame and plug it into a power outlet.
2. The frame will power on automatically.

3. Follow the on-screen prompts to select your language and connect to your Wi-Fi network. You will need your Wi-Fi network name (SSID) and password.
4. Create a PixStar account as prompted. This account is essential for managing your frame and accessing cloud features.



EASY SET UP IN LESS THAN 3 MINUTES

Free
Online
Portal

PRELOAD FRAME WITH PICTURES FOR THE PERFECT GIFT

The PixStar frame is designed for easy setup, allowing you to get started quickly.

Loading and Syncing Photos

Your PixStar frame offers multiple convenient ways to load and sync your photos and videos:


- **Email:** Each frame comes with a personalized Pix-Star email address. Send photos and videos directly to this address, and they will appear on your frame.
- **iOS and Android App:** Download the Pix-Star Snap app from your device's app store to easily send photos and videos from your smartphone or tablet.
- **Online Digital Photo Album Sync:** Sync your frame with various online photo services such as Google Photos, Dropbox, OneDrive, Flickr, SmugMug, Zenfolio, RSS Feeds, UPnP & DLNA.
- **USB Stick/SD Card:** Insert a USB stick or SD card into the designated ports on the frame to directly load photos

and videos.

- **Frame-to-Frame Sharing:** Send photos directly from one PixStar digital frame to another.

MORE OPTIONS FOR CONNECTIVITY AND SHARING

- ✓ Custom Email
- ✓ Online Albums
- ✓ Pix-Star Snap App
- ✓ USB & SD Card
- ✓ Photo Storage Sites



Explore various connectivity and sharing options, including custom email, app, online albums, and USB/SD card support.

UNLIMITED CLOUD STORAGE

Free forever

**NEVER LOSE THE
SPECIAL MOMENTS**



Free, secure cloud backup of your photos & videos.

Benefit from free unlimited cloud storage to securely store and access your memories.

MULTIPLE OPTIONS

Display your way



The back of the PixStar frame features SD and USB ports, a remote control holder, and a versatile stand for portrait or landscape orientation, with wall-mountable design.

OPERATING

Display Features

The PixStar frame features a high-quality IPS display with a 4:3 aspect ratio and 1024x768 pixel resolution. This ratio is ideal for displaying smartphone pictures without cropping, ensuring your photos are viewed in their original composition. The no-glare screen enhances viewing experience from various angles.

THE QUALITY YOUR MEMORIES DESERVE

Energy saving
motion sensor



4:3 RATIO
Same as smartphone pics

Stereo speakers for up to
2 min video playback

No-Glare Display

The PixStar frame boasts a no-glare IPS display with a 4:3 ratio, perfect for smartphone photos, and includes an energy-saving motion sensor and stereo speakers for video playback.

Motion Sensor


The integrated motion sensor helps conserve energy by automatically turning the display on when motion is detected and off when the area is clear for a period of time. You can customize the sleep and wake hours through the frame's settings.

Photo Management and Slideshows

Customize your photo viewing experience with various slideshow configurations, transitions, and album management options. Use the remote control or the online portal to adjust settings such as playing mode (Normal), sorting mode (Random), and display intervals.

YOUR Photos YOUR STYLE

ADJUST THE LAYOUT
& TRANSITIONS TO
YOUR LIKING



Pix-Star offers the most options in
slideshows, transitions, albums, and timing.

The PixStar frame offers extensive options for adjusting photo layouts, transitions, and timing to personalize your slideshows.


Bonus Features

Beyond displaying photos, your PixStar frame includes several additional features:

- **Weather Forecasts:** View local weather information.
- **Clock and Calendar:** Display time and manage appointments.
- **Games:** Engage with built-in brain games.
- **Music:** Load and play MP3 files (external speaker via aux input supported).
- **Web Radio:** Listen to various web radio stations.

MORE THAN JUST A FRAME

DISCOVER THE FULL POTENTIAL



Bonus features including games and calendar.

Discover the full potential of your PixStar frame with bonus features including weather, calendar, games, music, web radio, and photo display.

MAINTENANCE

Cleaning the Frame

To maintain the clarity of your display, gently wipe the screen with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners, as they may damage the screen or frame finish.

General Care

Keep the frame away from direct sunlight, excessive heat, and moisture. Ensure proper ventilation around the device to prevent overheating. Do not block the ventilation slots.

TROUBLESHOOTING

Common Issues and Solutions

- Frame not powering on:** Ensure the AC adapter is securely connected to both the frame and a working power outlet.
- No Wi-Fi connection:** Verify your Wi-Fi password is correct. Try restarting your Wi-Fi router. Ensure the frame is within range of your Wi-Fi signal.
- Photos not appearing:** Check your internet connection. Ensure photos are sent to the correct Pix-Star email address or uploaded via the app/USB/SD card correctly. Allow some time for cloud-synced photos to appear.
- Motion sensor not working:** Ensure there are no obstructions in front of the sensor. Check the motion sensor settings in the frame's menu.

If you encounter persistent issues, please refer to the support section or contact customer service.

SPECIFICATIONS

Feature	Detail
Product Dimensions	11 x 15 x 0.99 inches
Item Weight	4.9 pounds
Item Model Number	PXT515WR08
Brand	Pix Star
Color	Black
Resolution	1024x768 (4:3 aspect ratio)
Compatible Devices	iPhone, Android
Screen Size	15 Inches
Manufacturer	Pix-Star
First Available Date	September 1, 2014

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Pix-Star website or the contact information provided with your purchase. You can also find additional resources and FAQs on the Pix-Star support portal.

An official User Guide (PDF) is available for download at:

<https://manuals.plus/m/294d08e6805a534dd3aad7db4c6f0bbe55ee12ac0d3aa03802a8c92b6d8a9b6c>