

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Esperanza](#) /

› [Esperanza EH141K Wired Circumaural Headphones User Manual](#)

## Esperanza EH141K

# Esperanza EH141K Wired Circumaural Headphones User Manual

Model: EH141K

## INTRODUCTION

Welcome to the user manual for your Esperanza EH141K Wired Circumaural Headphones. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your headphones for optimal performance. Please read this manual thoroughly before use.

## SAFETY INFORMATION

To ensure safe operation and prevent damage to your headphones or personal injury, please observe the following safety guidelines:

- Avoid prolonged listening at high volume levels to prevent hearing damage.
- Do not expose the headphones to extreme temperatures, humidity, or liquids.
- Do not attempt to disassemble or modify the headphones. This will void the warranty.
- Keep the headphones away from children and pets.
- Clean the headphones only with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

## PACKAGE CONTENTS

Please check that all items are present in your package:

- 1 x Esperanza EH141K Wired Circumaural Headphones

## PRODUCT OVERVIEW

The Esperanza EH141K headphones are designed for multimedia use, offering a comfortable circumaural fit and wired connectivity.



*Image: Front view of the Esperanza EH141K headphones, showing the earcups, headband, and attached cable.*

### **Key Features:**

- Wired Connectivity (3.5mm Jack)
- Circumaural (Over-Ear) Design
- Integrated Volume Control
- Adjustable Headband
- Foldable Design for Storage

### **SETUP**

#### **Connecting to an Audio Source**

1. Locate the 3.5mm audio jack on your device (e.g., computer, smartphone, tablet).

2. Insert the 3.5mm connector from the Esperanza EH141K headphones firmly into your device's audio jack.
3. Ensure the connection is secure for optimal audio transmission.

## **OPERATING INSTRUCTIONS**

### **Wearing the Headphones**

1. Adjust the headband to fit comfortably over your head. The earcups should fully enclose your ears.
2. Ensure the left (L) and right (R) indicators on the earcups correspond to your left and right ears for proper stereo sound.

### **Adjusting Volume**

The Esperanza EH141K headphones feature an inline volume control.

1. Locate the volume control unit on the headphone cable.
2. Slide the control up or down to increase or decrease the audio volume to your desired level.

### **Folding for Storage**

The headphones can be folded for compact storage and portability.



*Image: Esperanza EH141K headphones shown in a folded position, demonstrating their compact storage capability.*

1. Gently fold the earcups inwards towards the headband until they are compact.
2. This reduces the overall size of the headphones, making them easier to store or transport.

## MAINTENANCE

### Cleaning

Regularly clean your headphones to maintain hygiene and performance.

- Use a soft, dry, lint-free cloth to wipe the earcups and headband.
- For stubborn dirt, slightly dampen the cloth with water, but ensure no liquid enters the headphone components.
- Do not use alcohol, solvents, or abrasive cleaners.

### Storage

When not in use, store your headphones in a clean, dry place, away from direct sunlight and extreme temperatures. Utilize the foldable design for compact storage.

## TROUBLESHOOTING

If you encounter issues with your Esperanza EH141K headphones, please refer to the following common problems and solutions:

### No Sound

- Ensure the 3.5mm jack is fully inserted into your audio source.
- Check the volume level on your audio source and on the headphone's inline volume control.
- Test the headphones with a different audio source to rule out device-specific issues.
- Verify that the audio output on your device is set to the correct output (e.g., "Headphones").

### Distorted Sound

- Lower the volume on both your audio source and the headphone's inline control.
- Ensure the audio cable is not damaged or kinked.
- Test with a different audio source or audio file.

## SPECIFICATIONS

Feature	Specification
Model	EH141K
Brand	Esperanza
Connectivity Technology	Wired
Connector Type	3.5mm Jack
Form Factor	Circumaural (Over-Ear)
Ear Placement	Supra-aural
Impedance	32 Ohms
Frequency Response	20000 Hz

Feature	Specification
Cable Length	5 meters
Special Features	Volume Control
Material	Leather
Color	Black

## WARRANTY AND SUPPORT

### Warranty Information

The Esperanza EH141K headphones come with a 2-year availability of spare parts in the EU, which typically implies a corresponding warranty period for manufacturing defects. Please retain your proof of purchase for warranty claims.

### Customer Support

For technical assistance, warranty claims, or further inquiries, please contact your local retailer or visit the official Esperanza website.