Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics SE-1105-07-2

CalExotics Pocket Exotics Wired Bullet Vibrator User Manual

Model: SE-1105-07-2

Brand: CalExotics

1. Introduction

This manual provides detailed instructions for the safe and effective use of your CalExotics Pocket Exotics Wired Bullet Vibrator, Model SE-1105-07-2. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Information

- This product is intended for external use only.
- Do not immerse the battery pack or wire in water.
- Discontinue use if any discomfort or irritation occurs.
- Keep out of reach of children.
- Remove batteries when not in use for extended periods to prevent leakage.

2. Product Overview

The CalExotics Pocket Exotics Wired Bullet Vibrator is a compact, multi-speed personal massager designed for targeted stimulation. It features a gold-plated bullet connected to a wired controller for easy operation.

Key Features:

- **Compact Design:** Small and discreet for easy handling and portability.
- **Multi-Speed Control:** Adjustable vibration intensity via a wired dial.
- **Durable Materials:** Constructed from polypropylene and ABS plastic with a gold-plated bullet.
- **Wired Controller:** Provides direct control over vibration settings.



Image 1: CalExotics Pocket Exotics Wired Bullet Vibrator, showing the bullet and controller in its retail packaging.



Image 2: The vibrator and controller held in a hand, illustrating its compact size.



Image 3: A detailed view of the gold-plated bullet component.

3. Setup

Battery Installation

The CalExotics Pocket Exotics Wired Bullet Vibrator requires two (2) AA batteries (not included) for operation.

1. Locate the battery compartment on the wired controller.
2. Gently slide open the battery compartment cover.
3. Insert two AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

Your browser does not support the video tag.

Video 1: This video demonstrates the battery installation process and basic operation of the CalExotics Pocket Exotics Wired Bullet Vibrator.

4. Operating Instructions

Once batteries are installed, the vibrator is ready for use.

1. Ensure the bullet is clean before use.
2. Apply a water-based lubricant to the bullet for comfortable use (optional).
3. To activate the vibrator, turn the dial on the side of the controller.
4. Rotate the dial towards "HIGH" to increase vibration intensity.
5. Rotate the dial towards "LOW" to decrease vibration intensity.
6. To turn off the vibrator, rotate the dial completely to the "LOW" position until it clicks off.



Image 4: Close-up view of the multi-speed dial on the controller, indicating 'High' and 'Low' settings.

5. Maintenance and Care

Proper care will extend the life of your product.

- **Cleaning:** Before and after each use, wash the bullet with warm water and a mild soap. Rinse thoroughly. Do not soak the battery pack or wire.
- **Drying:** Pat dry with a lint-free cloth.
- **Storage:** Store in a clean, dry place away from direct sunlight and extreme temperatures.
- **Battery Removal:** Remove batteries if the product will not be used for an extended period to prevent potential battery leakage and damage.

6. Troubleshooting

Problem	Possible Cause	Solution
Vibrator does not turn on or has weak vibration.	Batteries are dead or low. Batteries are inserted incorrectly. Loose connection within the battery compartment. Dial not turned to an active position.	Replace with fresh AA batteries. Check battery polarity and reinsert correctly. Ensure battery compartment cover is secure and batteries are making proper contact. Rotate the control dial to increase vibration intensity.
Vibration is inconsistent or stops intermittently.	Low battery power. Loose connection.	Replace batteries. Check battery compartment for secure fit.

7. Specifications

Model Number	SE-1105-07-2
Brand	CalExotics
Product Dimensions	1.75 x 6 x 8.5 inches (packaging); 3.2 ounces (weight)
Power Source	2 AA batteries (not included)
Color	Gold (bullet)

Material	Polypropylene, ABS Plastic
Manufacturer	CalExotics
Date First Available	August 22, 2014
UPC	0716770080479

8. Warranty and Support

For information regarding warranty, returns, or product support, please contact CalExotics directly or refer to the retailer's policy where the product was purchased. Keep your proof of purchase for any warranty claims.
Manufacturer: CalExotics
Website: www.calexotics.com (General company website for support inquiries)

© 2024 CalExotics. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00MUUW1QY

More documents and user manuals: **https://manuals.plus/**