Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Villeroy & Boch 10-2525-8775

Villeroy & Boch NewWave 30-Piece Dinnerware Set Instruction Manual

Model: 10-2525-8775

1. Introduction

Thank you for choosing the Villeroy & Boch NewWave 30-Piece Basic Dinnerware Set. This set is crafted from high-quality porcelain, designed for both elegance and daily use. This manual provides essential information for the proper handling, care, and maintenance of your dinnerware to ensure its lasting beauty and functionality.



Image 1.1: The Villeroy & Boch NewWave 30-Piece Dinnerware Set in a typical table setting.

2. Product Overview

The Villeroy & Boch NewWave 30-Piece Basic Dinnerware Set provides service for six, featuring a distinctive wave design and made from premium German-made porcelain. The set includes the following components:

- 6 x Dinner Plates
- 6 x Salad Plates
- 6 x Rim Soup Bowls
- 6 x Tea Cups
- 6 x Tea/Coffee Cup Saucers



Image 2.1: A Villeroy & Boch NewWave dinner plate, showcasing its unique design.

3. Setup

Your Villeroy & Boch NewWave dinnerware set requires minimal setup. Follow these steps before first use:

1. **Unpacking:** Carefully remove all pieces from their packaging. Inspect each item for any signs of damage during transit.
2. **Initial Cleaning:** Before first use, wash all dinnerware pieces with warm, soapy water or place them in a dishwasher. Rinse thoroughly and dry.

4. Operating Instructions

The NewWave dinnerware is designed for everyday dining and special occasions. Its ergonomic and unique shapes enhance the dining experience.

- **Serving:** Use the dinner plates for main courses, salad plates for appetizers or salads, and soup bowls for soups, stews, or cereals.
- **Beverages:** The tea cups and saucers are suitable for hot beverages like tea and coffee.
- **Microwave Use:** All pieces in this set are microwave safe. You can safely reheat food directly on the dinnerware.



Image 4.1: A NewWave bowl demonstrating its use for breakfast items.



Image 4.2: A NewWave plate showcasing its use for a light meal.

5. Care and Maintenance

Proper care will preserve the quality and appearance of your Villeroy & Boch NewWave dinnerware for years to come.

- **Dishwasher Safe:** All pieces are dishwasher safe. For best results, load items carefully to prevent chipping or scratching. Use a mild detergent.
- **Microwave Safe:** The porcelain is safe for use in microwave ovens.
- **Storage:** Store dinnerware carefully to prevent scratches. If stacking, consider using felt protectors between plates.
- **Stains:** For stubborn stains, a non-abrasive cleaner or a paste of baking soda and water can be used. Avoid harsh scouring pads or abrasive cleaners that may damage the glaze.



Image 5.1: Stacked NewWave plates, illustrating their durable finish.

6. Troubleshooting

While Villeroy & Boch dinnerware is designed for durability, occasional issues may arise.

- **Chipping/Breakage:** Porcelain, while strong, can chip or break if dropped or subjected to sharp impacts. Handle with care. If a piece is chipped or broken, discontinue use to avoid injury.
- **Scratches:** Minor scratches can occur over time from cutlery. These are generally cosmetic and do not affect functionality. Avoid using abrasive utensils.
- **Dishwasher Residue:** If you notice residue after dishwashing, ensure your dishwasher's rinse aid dispenser is full and that you are using an appropriate amount of detergent. Hard water can also contribute to residue; consider a water softener if this is a persistent issue.

7. Specifications

Detailed specifications for your Villeroy & Boch NewWave Dinnerware Set:

Feature	Detail
Brand	Villeroy & Boch
Model Number	10-2525-8775
Material	Porcelain
Color	White
Number of Pieces	30
Included Components	6 Dinner Plates, 6 Salad Plates, 6 Rim Soup Bowls, 6 Tea Cups, 6 Tea/Coffee Cup Saucers
Special Features	Dishwasher Safe, Microwave Safe
Item Weight	36.8 Pounds (approximate total package weight)

8. Warranty and Support

Villeroy & Boch stands by the quality of its products. For specific warranty information or if you require support regarding your dinnerware set, please contact Villeroy & Boch directly through their official website or customer service channels. Keep your purchase receipt as proof of purchase.
Manufacturer: Villeroy & Boch
Website: www.villeroy-boch.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00MXTSTOK

More documents and user manuals: **https://manuals.plus/**