

[Manuals.plus](#) /

› [Sharper Image](#) /

› Sharper Image Quiet Power Tie Rack Instruction Manual

Sharper Image 02SEPA

Sharper Image Quiet Power Tie Rack Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Sharper Image Quiet Power Tie Rack. Designed for efficient organization, this motorized tie rack offers quiet operation, automatic illumination, and versatile mounting options to keep your ties, belts, and scarves neatly arranged and easily accessible.

PACKAGE CONTENTS

Please verify that all components are present before proceeding with installation:

- Sharper Image Quiet Power Tie Rack unit
- One-screw mount adapter
- Instruction Manual



Image: Contents of the Sharper Image Quiet Power Tie Rack box, including the instruction manual.

SETUP AND INSTALLATION

The Sharper Image Quiet Power Tie Rack offers multiple installation methods to suit various closet rod types. Installation is designed to be tool-free for most applications.

Mounting Options:

1. **Direct Attachment to Round or Oval Closet Rods:** The tie rack can be directly attached to standard round or oval closet rods without the need for additional tools.
2. **One-Screw Mount Adapter:** For enhanced stability or specific rod types, use the included one-screw mount adapter. This adapter secures the tie rack firmly to the closet rod.
3. **Wood Shelf Mounting:** The tie rack can also be mounted underneath a wood shelf using the appropriate hardware (not included).

Ensure the tie rack is securely fastened to prevent movement during operation. The unit is designed to hold up to 72 ties and features four fixed hooks for additional items like belts or scarves.



Image: Diagrams illustrating three different mounting methods for the Sharper Image Quiet Power Tie Rack.

OPERATING INSTRUCTIONS

The Quiet Power Tie Rack is designed for simple and intuitive operation.

Powering the Unit:

The tie rack operates on batteries (not included). Insert the required batteries into the designated compartment, ensuring correct polarity.

Selecting a Tie:

1. To rotate the rack, gently touch the control bar. The rack will begin to rotate, allowing you to view your collection.
2. The integrated bright light will illuminate automatically during rotation, providing clear visibility of your ties.
3. Once you have located your desired tie, press the stop button on the control bar. The rack will cease rotation, and the light will automatically switch off approximately 10 seconds after stopping.

Accessory Hooks:

Utilize the four fixed hooks located on the unit to store additional accessories such as belts or scarves. Each hook can hold multiple items.



Image: Sharper Image Quiet Power Tie Rack in its packaging, highlighting features.

MAINTENANCE

To ensure the longevity and optimal performance of your Quiet Power Tie Rack, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the exterior surfaces with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish.
- **Battery Replacement:** If the rotation speed decreases or the light dims, it is time to replace the batteries. Refer to the battery compartment for the correct battery type and orientation.
- **Load Capacity:** Do not overload the tie rack beyond its recommended capacity of 72 ties and 8+ belts/scarves on the hooks. Excessive weight can strain the motor and affect performance.

TROUBLESHOOTING

If you encounter any issues with your Quiet Power Tie Rack, please refer to the following common solutions:

- **Rack does not rotate or light does not turn on:**
 - Check the batteries. Ensure they are inserted correctly and are not depleted. Replace with fresh batteries if necessary.
 - Verify that the unit is properly mounted and not obstructed by other items in the closet.
- **Rotation is slow or jerky:**
 - This often indicates low battery power. Replace the batteries.
 - Ensure the rack is not overloaded. Remove some items to see if performance improves.

- **Light stays on or turns off too quickly:**

- The light is designed to turn off approximately 10 seconds after rotation stops. If it deviates significantly, check battery levels.

If problems persist after attempting these solutions, please contact customer support (information not provided in this manual).

SPECIFICATIONS

Feature	Detail
Model Number	02SEPA
Brand	Sharper Image
Material	Metal, Plastic
Color	Gray
Capacity	Up to 72 ties, 4 hooks for belts/scarves
Product Dimensions	18 x 6 x 8 inches
Item Weight	2.43 pounds
Power Source	Batteries (not included)

WARRANTY AND SUPPORT

Information regarding product warranty and customer support contact details is not provided within this instruction manual. Please refer to the product packaging or the retailer's website for further details.