

[Manuals.plus](#) /

› [Hasbro Gaming](#) /

› Hasbro Gaming Simon Micro Series Electronic Game for 1 or More Players, Classic Simon Gameplay in a Compact Size, Fun Party Game for Kids Ages 8+ Simon Micro Series Game

Hasbro Gaming B0640000

Hasbro Gaming Simon Micro Series Electronic Game User Manual

Your compact companion for memory-challenging fun.

1. SETUP

The Simon Micro Series game comes ready for play with the game unit and instructions included in the box. Two AA batteries are required and are included with the product.

Battery Installation:

- Locate the battery compartment on the back of the game unit.
- Using a Phillips head screwdriver, open the battery compartment.
- Insert 2 AA batteries, ensuring correct polarity (+/-).
- Close the battery compartment and secure it with the screw.



Figure 1: The Simon Micro Series game in its retail packaging, highlighting its compact size and 'Watch, Remember, Repeat!' slogan.

2. OPERATING INSTRUCTIONS

The Simon Micro Series game offers classic Simon gameplay in a portable size. The objective is to watch, remember, and repeat the color patterns generated by the game.

Game Modes:

- **Solo Play:** Challenge yourself to beat your high score by accurately repeating increasingly complex color sequences.
- **Pass-it Mode:** For 2 or more players, this mode adds a new challenge. Players take turns repeating the pattern, and when the music plays, it's time to pass the game to the next person.

Gameplay:

1. **Watch for the Lights:** The game will light up one or more colored buttons in a sequence.

2. **Remember the Colors:** Pay close attention to the order and timing of the lights.
3. **Repeat the Pattern:** Press the colored buttons in the exact same order as they lit up.
4. **Advanced Levels:** At higher levels, multiple lights may come on simultaneously, requiring you to press those buttons at the same time.
5. **Sounds:** The game includes fun sounds from the classic Simon game to accompany the lights.



Figure 2: Front view of the Simon Micro Series game, showing its four colored buttons (green, red, blue, yellow) and the central 'Simon' logo.



Figure 3: Back view of the Simon Micro Series game packaging, illustrating the 'Follow the Colors!' steps: Watch for the lights, Remember the colors, Repeat the pattern, Win! It also highlights solo and pass-it game modes.



Figure 4: Two boys engaged in playing the Simon Micro Series game, demonstrating the Pass-it mode where the game is handed between players.

3. MAINTENANCE

To ensure the longevity and optimal performance of your Simon Micro Series game, follow these general maintenance guidelines:

- Keep the game clean by wiping it with a dry, soft cloth. Avoid using abrasive cleaners or solvents.
- Store the game in a cool, dry place away from direct sunlight and extreme temperatures.
- If the game will not be used for an extended period, remove the batteries to prevent leakage and corrosion.

4. TROUBLESHOOTING

If you encounter any issues with your Simon Micro Series game, please consider the following common solutions:

- **No Power:** Ensure batteries are correctly installed and are not depleted. Replace with fresh AA batteries if necessary.
- **Incorrect Response:** Verify that buttons are being pressed firmly and in the correct sequence as indicated by the lights and sounds.
- **Unresponsive Buttons:** Check for any debris or obstruction around the buttons. If the issue persists, try replacing the batteries.

For further assistance, please refer to the 'Warranty and Support' section.

5. SPECIFICATIONS

Feature	Detail
Product Dimensions	1.61 x 5.51 x 8.27 inches
Item Weight	6.4 ounces
Country of Origin	Vietnam
Item Model Number	B0640000
Manufacturer Recommended Age	8 years and up
Batteries	2 AA batteries required (included)
Release Date	August 27, 2014
Language	English
Manufacturer	Hasbro

6. WARRANTY AND SUPPORT

Specific warranty details for the Hasbro Gaming Simon Micro Series Electronic Game are not provided in the available product information. For comprehensive warranty information, product support, or to inquire about replacement parts, please contact Hasbro Gaming directly.

You can visit the official Hasbro Gaming store for more information and contact options:[Hasbro Gaming Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question