

[Manuals.plus](#) /

› [Weber](#) /

› Weber Performer Premium Charcoal Grill (Model 15401001) User Manual

Weber 15401001

Weber Performer Premium Charcoal Grill (Model 15401001) User Manual

22-Inch, Black

1. IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions before operating this grill. Failure to follow these instructions could result in fire, explosion, or burn hazard, which could cause property damage, personal injury, or death.

Proposition 65 Warning:

- This product can expose you to chemicals including nickel, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.
- Combustion byproducts produced when using this product contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.
- This product can expose you to soot, which is known to the State of California to cause cancer, and carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

2. PRODUCT OVERVIEW

The Weber Performer Premium Charcoal Grill offers a robust grilling experience with convenient features designed for ease of use and durability. This 22-inch charcoal grill is built with quality materials to ensure consistent performance.




Figure 1: Front view of the Weber Performer Premium Charcoal Grill.



AT THE GRILL

PERFORMER® PREMIUM



AT THE GRATE

363 SQUARE INCHES

FITS 13



MEASURED WITH A WEBER BURGER PRESS

7.5 INCH LID HEIGHT



COOKING GRATE
GOURMET BBQ SYSTEM® HINGED

FEATURES

EASY TO CLEAN:

- ONE-TOUCH™ CLEANING SYSTEM
- REMOVABLE, ASH CATCHER



BUILT-IN LID THERMOMETER

LID HOLDER

WORK TABLE
CHAR-BASKETS

SHIPPING CARTON



H 20.3" W 38.7" D 27.2" WT 96 LB

Figure 2: Diagram illustrating key dimensions and features of the grill, including 363 square inches of cooking grate space, 7.5 inch lid height, built-in lid thermometer, work table, and Char-Baskets.

3. SETUP AND ASSEMBLY

The Weber Performer Premium Charcoal Grill requires assembly. It is recommended to follow the detailed instructions provided in the included manual or use the BILT app for interactive 3D instructions.

Assembly Guide Video

Your browser does not support the video tag.

Video 1: Manufacturer's assembly guide for the Performer Premium grill. This video provides visual steps for putting the grill together.

4. OPERATING INSTRUCTIONS

Charcoal Management

- The grill features a weather-protected CharBin storage container for convenient charcoal storage.
- Char-Baskets are included for efficient charcoal organization, allowing for direct or indirect heat grilling.



Figure 3: The integrated CharBin provides convenient storage for charcoal.

Grilling Features

- The porcelain-enameled lid and bowl are designed to retain heat effectively for consistent cooking.
- The cooking grate is compatible with GBS (Gourmet BBQ System) inserts and is hinged for easy addition of charcoal during grilling.
- The grill can accommodate up to 13 burgers made with a Weber burger press.
- A built-in lid thermometer displays the internal grill temperature.
- Dampers on the lid allow for precision heat control.
- A tuck-away lid holder provides convenient placement for the lid while checking food.
- Tool hooks are available for easily accessing grilling tools.



Figure 4: Food cooking on the grill grate, demonstrating the cooking capacity.



Figure 5: A GBS insert being placed into the hinged cooking grate, expanding grilling possibilities.



Figure 6: The tuck-away lid holder keeps the lid conveniently off the ground.

Product Features Overview Video

Your browser does not support the video tag.

Video 2: Manufacturer's overview of the Weber Performer Premium Charcoal Grill, highlighting its key features and benefits.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Weber Performer Premium Charcoal Grill.

- The One-Touch cleaning system with a high-capacity ash catcher provides hassle-free ash cleanup.
- The porcelain-enameled lid and bowl are designed to resist rust and peeling, simplifying exterior cleaning.



Figure 7: The One-Touch cleaning system allows for easy ash removal into the ash catcher.

6. TROUBLESHOOTING

For common issues, consult the full owner's manual provided with your grill. If problems persist, contact Weber customer support.

- **Difficulty maintaining temperature:** Ensure dampers are properly adjusted and charcoal quantity is sufficient.
- **Ash buildup:** Regularly use the One-Touch cleaning system to clear ash from the bowl.
- **Lid not fitting correctly:** Check for any obstructions or damage to the lid or bowl.

7. SPECIFICATIONS

Feature	Detail
Brand	Weber
Model Number	15401001

Feature	Detail
Product Dimensions (D x W x H)	48"D x 30"W x 48"H
Color	Black
Fuel Type	Charcoal
Special Features	Heavy Duty, Rust Resistant
Main Burner Count	1
Number Of Racks	1
Grill Configuration	Cart-style grill
Cooking System	Grill, Griddle (with optional GBS inserts)
Primary Cooking Method	Grilling
Item Weight	91 pounds
Finish Types	Painted
Material Type	Alloy Steel, Porcelain
Handle Material	Nylon
Frame Material	Alloy Steel
Installation Type	Built In, Peel (referring to assembly)
Recommended Uses For Product	Outdoor
Included Components	Heavy duty steel cart, Side table, LCD timer, Charcoal bin, Tuck-away lid holder, Hinged cooking grate with a removable center section, Removable ash catcher, Weber cooking components
Indoor Outdoor Usage	Outdoor
Number of Items	1
Manufacturer	WEBER
UPC	077924032530

8. WARRANTY AND SUPPORT

Warranty Information

This product comes with a limited manufacturer warranty. For complete details regarding warranty coverage, terms, and conditions, please refer to the official owner's manual included with your grill or visit the Weber website.

Customer Support

For assistance with assembly, operation, maintenance, or any other product-related inquiries, please contact Weber customer support. Contact information can typically be found in your owner's manual or on the official Weber website.

© 2023 Weber. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00N634UJK>

More documents and user manuals: <https://manuals.plus/>