

Blackmore Pro Audio BJST-60KG

Blackmore Pro Audio BJST-60KG DJ Speaker Stand Instruction Manual

Model: BJST-60KG

INTRODUCTION

The Blackmore Pro Audio BJST-60KG DJ Speaker Stand is designed for stable and reliable support of PA speakers. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your speaker stand. Please read these instructions thoroughly before initial use.

SAFETY INFORMATION

- Always ensure the stand is placed on a stable, level, and non-slip surface.
- Do not exceed the maximum load capacity of 60 kg (132 lbs). Overloading can cause instability and damage.
- Ensure all locking mechanisms, including the central knob and height adjustment knob, are securely tightened before mounting a speaker.
- Distribute weight evenly when placing a speaker on the stand. An off-center load can compromise stability.
- Keep hands clear of moving parts during adjustment to prevent pinching or injury.
- Regularly inspect the stand for any signs of wear, damage, or loose components. Do not use the stand if it appears damaged.
- Never leave the stand unattended in areas where it could be easily knocked over, especially with a speaker mounted.

PACKAGE CONTENTS

- 1 x Blackmore Pro Audio BJST-60KG Speaker Stand
- 1 x Safety Pin

SETUP INSTRUCTIONS

1. Place the folded stand on a flat, stable surface.
2. Gently spread the tripod legs outwards until they are fully extended and stable. The housing should slide smoothly

along the lower shaft to facilitate opening and closing the legs.

3. Secure the leg spread by tightening the central locking knob firmly.
4. Loosen the height adjustment knob on the upper shaft.
5. Carefully extend the upper shaft to the desired height.
6. Insert the safety pin into the nearest appropriate hole on the upper shaft to prevent accidental lowering.
7. Tighten the height adjustment knob firmly to secure the upper shaft in place.



Image 1: The Blackmore Pro Audio BJST-60KG DJ Speaker Stand in its fully extended, ready-to-use configuration. This image illustrates the tripod base and the adjustable central pole.

OPERATING THE SPEAKER STAND

1. After ensuring the stand is securely set up and all knobs are tightened, carefully lift your PA speaker.
2. Align the speaker's pole mount with the top pole of the BJST-60KG stand.
3. Gently lower the speaker onto the stand, ensuring it is seated securely and level.
4. Verify that the speaker is stable and does not wobble before leaving it unattended.
5. To adjust the height during operation, first remove the speaker from the stand. Then, loosen the height adjustment knob, adjust the height, re-insert the safety pin, and re-tighten the knob before remounting the speaker.

MAINTENANCE

- Clean the stand regularly with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- Periodically check all nuts, bolts, and locking mechanisms for tightness. Tighten any loose components.
- Inspect the aluminum and iron components for any signs of corrosion, bends, or cracks. Replace any damaged parts immediately.
- Ensure the rubber feet are intact to provide maximum stability and prevent damage to floor surfaces.
- Store the stand in a dry, cool environment when not in use to prevent rust and material degradation.

TROUBLESHOOTING

Stand is unstable:

- Ensure the tripod legs are fully extended and the central locking knob is tight.
- Verify the stand is placed on a completely level and stable surface.
- Check that the speaker is centered on the stand and not exceeding the maximum weight capacity.

Height adjustment mechanism is stiff:

- Ensure the height adjustment knob is fully loosened.
- Clean any dirt or debris from the inner and outer shafts.
- Apply a small amount of silicone-based lubricant to the sliding surfaces if necessary, avoiding petroleum-based products which can attract dirt.

SPECIFICATIONS

Feature	Detail
Model Number	BJST-60KG
Brand	Blackmore Pro Audio
Material	Aluminum, Iron
Load Capacity	60 kg (132 lbs)
Item Weight	7.28 pounds
Product Dimensions (Folded)	46 x 4 x 6 inches
Finish	Black powder coat
Design	Fold-out tripod

WARRANTY AND SUPPORT

For specific warranty information, technical support, or to inquire about replacement parts, please refer to the official Blackmore Pro Audio website or contact their customer service directly. It is recommended to retain your purchase receipt as proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question