

## Disney 12880

# Disney Frozen Jumbo Plush Olaf Instruction Manual

Model: 12880

## INTRODUCTION

This instruction manual provides essential information for the proper handling, care, and maintenance of your Disney Frozen Jumbo Plush Olaf. Please read this manual thoroughly to ensure the longevity and enjoyment of your product. This plush toy is designed for ages 3 and up.

## SETUP

The Disney Frozen Jumbo Plush Olaf arrives ready for immediate use. No assembly is required. Upon receiving your plush toy, carefully remove it from its packaging. Inspect the plush for any shipping damage or loose tags. Remove all plastic tags and packaging materials before allowing use, especially by children.



**Figure 1:** Front view of the Disney Frozen Jumbo Plush Olaf. This image displays the plush toy in its full form, highlighting its soft texture and characteristic features, including the carrot nose, stick arms, and coal buttons.

## USAGE GUIDELINES

The Jumbo Plush Olaf is designed for cuddling and imaginative play. Its soft and cuddly nature makes it suitable for various activities.

- **Cuddling:** The plush is soft and sized at approximately 24 inches, making it ideal for hugging and comforting.
- **Imaginative Play:** Encourage creative storytelling and role-playing with Olaf as a companion.
- **Decoration:** The plush can also serve as a decorative item in a child's room.



**Figure 2:** Side view of the Disney Frozen Jumbo Plush Olaf. This image provides a profile view of the plush, showing its three-tiered body structure and the details of its stick-like arms and hair.

## CARE AND MAINTENANCE

Proper care will help maintain the quality and appearance of your plush toy.

- **Spot Cleaning:** For minor dirt or stains, use a damp cloth with mild soap. Gently rub the affected area and then blot dry.
- **Hand Washing:** For more thorough cleaning, hand wash with cold water and a gentle detergent. Rinse thoroughly and gently squeeze out excess water.
- **Drying:** Air dry completely. Do not use a machine dryer, as high heat can damage the plush material. Lay flat on a clean surface or hang in a well-ventilated area away from direct sunlight.
- **Storage:** Store in a clean, dry place away from direct sunlight to prevent fading and material degradation.
- **Avoid:** Do not bleach, iron, or dry clean the plush toy.

## TROUBLESHOOTING

Below are common issues and recommended solutions for your plush toy.

Problem	Solution
Loose stitching or seams	Carefully hand-stitch the affected area with a needle and thread matching the plush color. If the damage is extensive, contact customer support.
Plush appears flattened or matted	Gently fluff the plush by hand. For matted fur, lightly brush with a soft-bristled brush.

Problem	Solution
Stains or dirt	Refer to the 'Care and Maintenance' section for spot cleaning or hand washing instructions.

## PRODUCT SPECIFICATIONS

Feature	Detail
Product Dimensions	12 x 10 x 24 inches (L x W x H)
Item Weight	14.1 ounces
Model Number	12880
Recommended Age	36 months - 6 years
Manufacturer	Just Play
ASIN	B00N7RRCPY



## WARRANTY INFORMATION





This product is manufactured by Just Play. For specific warranty details, please refer to the information provided on the product's packaging or contact the manufacturer directly. General warranties typically cover manufacturing defects for a limited period from the date of purchase.

## CUSTOMER SUPPORT

Should you have any questions, concerns, or require assistance with your Disney Frozen Jumbo Plush Olaf, please contact the manufacturer, Just Play, through their official customer service channels. Contact information can typically be found on the product packaging or their official website.

### Related Documents - 12880

	<a href="#">Olaf Remote Control Duck Instruction Manual</a> Instruction manual for the Disney Frozen Olaf Remote Control Duck (Model ET-0903-OLAF), detailing setup, operation, and safety guidelines.
	<a href="#">Interactive Olaf Toy: How to Use, Modes, and Features</a> Official instruction sheet for the Disney Interactive Olaf toy. Discover how to activate Try Me Mode, RF Mode for talking to other Olafs, and Interactive Mode with voice commands. Learn about shoulder placement and battery replacement. Includes key phrases and FCC compliance information.

	<p><a href="#">6V Frozen 2 Quad Ride On - User Manual and Safety Guidelines</a></p> <p>This document provides essential safety guidelines, vehicle care instructions, battery information, and assembly steps for the Disney Frozen 6V Quad Ride On toy, model KL-40052.</p>
	<p><a href="#">Interactive Banshee Hatchling: Setup and Operation Guide</a></p> <p>Comprehensive instruction sheet for the Interactive Banshee Hatchling toy, detailing setup, activation, interaction modes, and battery information. Learn how to bring your Banshee to life.</p>
	<p><a href="#">Setting Up a Disney MagicMobile Pass for iPhone, Apple Watch, and Android Devices</a></p> <p>Learn how to set up and use your Disney MagicMobile Pass on iPhone, Apple Watch, and Android smartphones with Google Wallet for seamless access to theme parks, Lightning Lane entrances, and more.</p>
	<p><a href="#">Disney Frozen Bluetooth Wireless Stereo Headphones Instruction Manual</a></p> <p>This manual provides instructions for using the Disney Frozen Bluetooth Wireless Stereo Headphones, including charging, pairing, controls, and troubleshooting.</p>