Pyrex 7404-PC

Pyrex 7404-PC 4.5-Quart Blue Food Storage Replacement Lid Instruction Manual

Model: 7404-PC

Introduction

This manual provides essential information for the proper use and care of your Pyrex 7404-PC 4.5-Quart Blue Food Storage Replacement Lid. Designed for convenience and durability, this lid ensures your food stays fresh.

Product Overview

The Pyrex 7404-PC lid is a durable, BPA-free plastic replacement lid specifically designed for Pyrex 4.5-Quart glass mixing bowls. Its robust construction is intended to withstand regular use without bending or cracking, providing a secure seal for food storage.



Image: The Pyrex 7404-PC 4.5-Quart Blue Food Storage Replacement Lid.

Compatibility

This replacement lid is specifically engineered to fit the Pyrex 7404 4.5-Quart glass mixing bowl. It is crucial to verify your bowl's model number to ensure a proper and secure fit. The lid is not compatible with other bowl sizes, such as the 7401-SCU.



Image: Visual guide for lid compatibility, showing correct fit for 7404-SCU and incorrect fit for 7401-SCU.

Setup and Usage

Attaching the Lid

To attach the lid, align it with the rim of your Pyrex 7404 4.5-Quart glass mixing bowl. Press down firmly around the edges until the lid creates a secure seal. Ensure all edges are properly seated to prevent leaks and maintain food freshness.



Image: The Pyrex 7404-PC lid securely placed on its compatible glass mixing bowl.

Versatile Use

The Pyrex 7404-PC lid is designed for versatile food storage and reheating:

- **Refrigerator and Freezer:** Safely store food in the refrigerator or freezer to preserve freshness.
- **Microwave:** The lid is safe for microwave use. **Important:** Always loosen the lid before microwaving to allow steam to escape and prevent pressure buildup.



Image: Underside of the Pyrex 7404-PC lid, displaying embossed usage instructions.

Care and Maintenance

Cleaning your Pyrex 7404-PC lid is simple:

- **Dishwasher Safe:** The lid is dishwasher safe. For best results and to prolong its lifespan, place it on the **top rack only**.
- **Hand Washing:** If hand washing, use warm, soapy water and a soft sponge. Rinse thoroughly and air dry or towel dry.

Safety Information

- **DO NOT use the lid in a conventional oven.** The plastic material is not designed for high oven temperatures and will melt or deform.
- Always loosen the lid when microwaving to prevent steam buildup.
- Avoid using abrasive cleaners or scouring pads, as these can scratch or damage the lid's surface.

Specifications

Brand	Pyrex
Model Number	7404-PC
Material	Plastic
Color	Blue
Item Weight	4 ounces
Compatibility	Pyrex 7404 4.5-Quart Glass Mixing Bowl
Care Instructions	Dishwasher safe (top rack only)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question