

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Polk Audio AM6913-A

Polk Omni S2R Rechargeable Compact Wireless Music Streaming Speaker User Manual

Model: AM6913-A | Brand: Polk Audio

WELCOME

Thank you for choosing the Polk Omni S2R Rechargeable Compact Wireless Music Streaming Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. The Omni S2R offers a portable solution for enjoying Polk's signature sound wirelessly, whether indoors or outdoors.

PRODUCT OVERVIEW

Key Features

- Up to 6 hours of battery life for portable use.
- Integrated Bluetooth adapter for flexible streaming.
- Room-filling sound from twin 2-inch full-range drivers and passive bass radiators.
- Wi-Fi streaming via the Free Polk Omni App (Amazon Prime Music, Pandora, Spotify, iHeartRadio, personal music collection).
- Splash and humidity resistant design with a tough metal grille for outdoor use.
- Extended range Wi-Fi antenna for broad coverage.
- Multi-room audio capabilities with other Polk Omni Collection speakers.

Package Contents

- Polk Omni S2R Speaker
- Power Adapter
- Quick Start Guide



Image: The Polk Omni S2R speaker, showcasing its compact and portable design.

SETUP GUIDE

Initial Charge

Before first use, fully charge your Polk Omni S2R speaker using the provided power adapter. A full charge provides up to 6 hours of playback at moderate listening levels.

Connecting to Wi-Fi

1. Download the free Polk Omni App from your device's app store.
2. Plug in your Omni S2R speaker.
3. Open the Polk Omni App and follow the on-screen instructions to connect your speaker to your Wi-Fi network. This process typically involves selecting your Wi-Fi network and entering the password.
4. Once connected, the speaker's Wi-Fi indicator light will confirm the connection.

Bluetooth Pairing

The Omni S2R includes an ultra-compact Bluetooth adapter for direct streaming when Wi-Fi is not available or preferred.

1. Ensure the Bluetooth adapter is connected to the speaker.
2. Activate Bluetooth on your smartphone, tablet, or computer.
3. Select the Polk Omni S2R from the list of available Bluetooth devices to pair.
4. The speaker will indicate a successful Bluetooth connection.

Video: An overview of the Polk Omni Wireless Music System, demonstrating its multi-room capabilities and ease of use.

OPERATING INSTRUCTIONS

Using the Polk Omni App

The Polk Omni App is your central control for the speaker. It allows you to:

- Browse and play music from various streaming services (e.g., Amazon Prime Music, Pandora, Spotify, iHeartRadio) or your personal music library.
- Adjust volume levels for individual speakers or groups.
- Create and manage multi-room audio zones, playing the same music in all rooms or different songs in different rooms.
- Access speaker settings and perform firmware updates.

Music Streaming

Stream your favorite audio content seamlessly:

- **Wi-Fi Streaming:** For the highest quality audio and multi-room functionality, use the Polk Omni App to stream over your Wi-Fi network. This provides a stable connection and allows for synchronized playback across multiple Omni devices.
- **Bluetooth Streaming:** For quick, direct connection to a single device, use the Bluetooth adapter. This is ideal for portable use outside your Wi-Fi network range.



Image: The Polk Omni S2R speaker positioned on an outdoor patio table, demonstrating its portability for outdoor entertainment.



Image: The Polk Omni S2R speaker placed on a wooden surface indoors, highlighting its versatile design for any room.

MAINTENANCE AND CARE

Cleaning

To clean your speaker, use a soft, dry cloth. Do not use liquid cleaners or aerosol sprays, as they may damage the finish or internal components.

Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before long-term storage to preserve battery health.

Weather Resistance

The Omni S2R features a weather-resistant design suitable for casual outdoor use. However, it is **not waterproof**. Avoid submerging the speaker in water or exposing it to heavy rain. Always ensure the charging port cover is securely closed when outdoors.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Speaker not charging	Power adapter not connected properly; Faulty outlet; Battery depleted.	Ensure power adapter is securely plugged into speaker and a working outlet. Allow sufficient time for charging.

Problem	Possible Cause	Solution
No sound/Low volume	Volume too low; Muted; Incorrect source selected; Speaker not connected.	Increase volume on speaker and source device. Check if speaker is muted. Verify correct input source in the app. Re-establish Wi-Fi or Bluetooth connection.
Wi-Fi connectivity issues	Incorrect Wi-Fi password; Speaker out of range; Network interference.	Double-check Wi-Fi password. Move speaker closer to router. Reduce interference from other wireless devices. Restart router and speaker.
Bluetooth pairing issues	Bluetooth not enabled; Speaker not in pairing mode; Device already paired.	Ensure Bluetooth is enabled on your device. Put speaker into Bluetooth pairing mode (refer to quick start guide). Forget previous pairings on your device and try again.
Sound distortion/Skipping	Weak Wi-Fi/Bluetooth signal; Interference; Source audio quality.	Move speaker closer to router/Bluetooth device. Avoid placing near other electronics. Check audio source quality.
Multi-room sync issues	Network congestion; Speaker placement; Firmware outdated.	Ensure strong Wi-Fi signal to all speakers. Reduce network traffic. Check for and install any available firmware updates via the Polk Omni App.

PRODUCT SPECIFICATIONS

Specification	Detail
Model Name	Omni S2R
Speaker Type	Outdoor
Special Feature	Portable
Recommended Uses For Product	Music
Compatible Devices	Smartphone, Tablet, MP3 Player, Desktop, Television, Projector, Laptop
Controller Type	Battery Powered
Surround Sound Channel Configuration	2.0
Color	GRAY
Battery Life	6 Hours
Included Components	Speakers
Item Weight	4.85 Pounds
Is Waterproof	FALSE

Specification	Detail
Warranty Type	Manufacturer Warranty
Number of Items	1
Control Method	Touch
Wireless Communication Technology	Bluetooth, Wireless
Speaker Size	2 Inches
Power Source	Battery Powered
Woofer Diameter	2 Inches
Customer Package Type	Standard Packaging
Number of Batteries	1 Lithium Ion batteries required. (included)
Audio Driver Type	Dynamic Driver
Connectivity Protocol	Bluetooth, Wi-Fi
Includes MP3 player?	No
UPC	747192124687
Style	Portable
Indoor/Outdoor Usage	Outdoor
Global Trade Identification Number	00747192124687
Manufacturer	Polk Audio
Product Dimensions	6.7 x 7.9 x 12.7 inches
Item Weight	4.85 pounds
ASIN	B00NAMZBQS
Item model number	AM6913-A
Batteries	1 Lithium Ion batteries required. (included)
Is Discontinued By Manufacturer	No
Date First Available	September 15, 2014
Brand	Polk Audio
Speaker Maximum Output Power	5 Watts
Connectivity Technology	Bluetooth, Wi-Fi

Specification	Detail
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount

WARRANTY AND SUPPORT

Warranty Information

This product is covered by a Manufacturer Warranty. Please refer to the warranty card included with your product for specific terms and conditions, or visit the Polk Audio official website for detailed warranty information.

Additional Support

For further assistance, you can refer to the official User Manual (PDF) available online: [Polk Omni S2R User Manual PDF](#)

Documents - Polk Audio – AM6913-A



[\[pdf\]](#) Specifications Warranty

Omni Collection Polk Audio All the music you love anywhere in your home The S2 Rechargeable is part of a series wireless products that allow to omni S6 A1 P1 SB1 rechargeable polkaudio S2R productpreview media files documentmaster polk us s2r

Omni Collection omni S2 omni S2 rechargeable omni S6 omni A1 omni P1
www.polkaudio.com omni S ... full-range drivers, 2 passive radiators Analog 323 mm H x 200 mm W x 170 mm D External Power Supply **AM6913-A** AM6916-A INTL 747192124687 747192125301 INTL 1 year Use vertically or horizontally Om...
 lang:en score:18 filesize: 1.84 M page_count: 2 document date: 2015-10-15