

Steba 39.18.00

Steba BS-1800 Quick Heater User Manual

Model: BS-1800 (39.18.00)

INTRODUCTION

Thank you for choosing the Steba BS-1800 Quick Heater. This manual provides essential information for the safe and efficient operation of your new appliance. Please read all instructions carefully before installation and use, and retain this manual for future reference.

The Steba BS-1800 is an energy-saving quick heater designed for bathroom use, featuring a programmable timer, motion sensor, and touch controls for enhanced comfort and efficiency.



Image: Front view of the Steba BS-1800 Quick Heater, showcasing its sleek white design and integrated digital display with touch controls.

IMPORTANT SAFETY INSTRUCTIONS

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors. This heater is intended for indoor, bathroom use only.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner.
- This heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- This appliance is splash-proof (IP24 rated) and suitable for bathroom installation, but must not be installed directly above a bath or shower.

SETUP AND INSTALLATION

The Steba BS-1800 Quick Heater is designed for wall-mounted installation. Ensure the mounting location is suitable and adheres to local electrical and safety regulations.

Mounting Location

- Choose a wall location that is clear of obstructions and allows for proper air circulation.
- Ensure the wall material can support the weight of the heater (approximately 4.84 pounds).
- Maintain a safe distance from water sources, as per IP24 rating guidelines for bathroom appliances.

Installation Steps

1. Carefully unpack the heater and all accessories. Inspect for any damage.
2. Using the provided mounting template (if included) or by measuring the heater's dimensions, mark the drilling points on the wall. Refer to the dimensions diagram below.
3. Drill holes and insert appropriate wall plugs (not always included, depending on wall type).
4. Secure the mounting bracket to the wall.
5. Carefully hang the heater onto the mounting bracket, ensuring it is securely seated.
6. Connect the power plug to a suitable electrical outlet. Ensure the outlet is properly grounded and rated for the heater's power requirements.



Image: Dimensional diagram of the Steba BS-1800 heater, indicating a height of 49 cm, width of 30 cm, and depth of 10 cm for precise installation planning.



**Geräuschlose Entspannung –
Genieße wohlige Wärme, ohne
störende Geräusche**



**Sichere Nutzung –
Perfekt für feuchte Räume, dank IP 24
Schutzklasse**



**Intelligente Wärme –
Der Bewegungssensor
erkennt Bewegungen
und passt die
Heizleistung
automatisch an**



**Praktischer Komfort –
Halte deine
Handtücher immer
warm und griffbereit**



Image: Rear view of the Steba BS-1800 Quick Heater, illustrating the design for wall mounting and the location of the air intake vent.

OPERATING INSTRUCTIONS

The Steba BS-1800 features intuitive touch controls and various modes for optimal heating.

Control Panel Overview

The front panel features a digital display and touch-sensitive buttons for power, mode selection, temperature adjustment, and timer settings.

Basic Operation

1. **Power On/Off:** Press the power button (usually indicated by a circle with a vertical line) to turn the heater on or off.
2. **Temperature Adjustment:** Use the up/down arrows to set your desired room temperature. The heater features a stepless adjustable room thermostat.
3. **Mode Selection:** Press the 'mode' button to cycle through available operating modes.

Advanced Features

- **Programmable Timer:** Set the timer for a daily hot bath or specific heating periods. Consult the display for timer programming options.
- **Motion Sensor:** The integrated motion sensor detects presence and can activate an ECO mode, reducing energy consumption when no movement is detected.
- **ECO Mode:** This energy-saving mode automatically adjusts heating output based on motion detection, optimizing power usage.
- **Open Window Detection:** The heater can detect open windows and temporarily suspend heating to prevent energy waste.
- **Frost Protection Mode:** This mode maintains a minimum temperature to prevent freezing in the room.



Image: A graphic highlighting key features of the Steba BS-1800, including motion detection, open window detection, frost protection mode, and a programmable timer for individual weekday scheduling.

BS 1800 TOUCH



Image: The Steba BS-1800 Quick Heater installed in a modern bathroom, demonstrating its function as a towel warmer, providing practical comfort.

MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your Steba BS-1800 Quick Heater.

Cleaning

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the internal components.

Filter Maintenance

The heater may contain a washable, removable filter. Regularly check and clean the filter to maintain optimal airflow and heating efficiency.

- Locate the filter access point (typically on the side or rear of the unit).
- Remove the filter and gently clean it with a soft brush or rinse under lukewarm water.
- Allow the filter to dry completely before reinserting it into the heater.

TROUBLESHOOTING

If you encounter issues with your Steba BS-1800 Quick Heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; power button not pressed; overheating protection activated.	Check power outlet and plug connection. Press power button. Allow unit to cool down if overheating protection was triggered.
Heater produces insufficient heat.	Temperature setting too low; air intake/exhaust blocked; dirty filter.	Increase temperature setting. Ensure clear airflow around the unit. Clean the air filter.
Motion sensor not responding.	Sensor obstructed; incorrect mode selected.	Ensure sensor is clear of obstructions. Verify the heater is in a mode that utilizes the motion sensor.
Unusual noises or odors.	Dust accumulation; internal component issue.	Unplug immediately. Clean the unit. If problem persists, discontinue use and contact customer support.

If the problem persists after attempting these solutions, please contact Steba customer support for assistance.

SPECIFICATIONS

Feature	Detail
Model Number	39.18.00 (BS-1800)
Product Dimensions	3.94 x 11.81 x 19.29 inches (10 x 30 x 49 cm)
Item Weight	4.84 pounds
Manufacturer	Steba
ASIN	B00NEKCDX0
Power Features	Programmable timer, Motion sensor, ECO mode, Stepless adjustable room thermostat


Feature	Detail
Safety Features	Overheating protection, Splash-proof (IP24), Open window detection, Frost protection mode
Control Type	Touch control with display
Installation	Wall mounted




WARRANTY AND SUPPORT

Specific warranty details are not provided in the product information. For warranty claims, technical support, or service inquiries, please contact Steba customer service directly or refer to the warranty card included with your purchase.

Keep your purchase receipt as proof of purchase for any warranty-related matters.

Related Documents - 39.18.00

 <p>Badschnellheizer BS 1800 Touch</p> <p>Gebruiksaanwijzing 2 Instructions for use 18 Mode d'emploi 28 Gebruiksaanwijzing 42</p> <p>www.steba.com</p>	<p>Steba BS 1800 Touch Badschnellheizer Bedienungsanleitung</p> <p>Umfassende Installations- und Bedienungsanleitung für den Steba BS 1800 Touch Badschnellheizer. Dieses Dokument bietet detaillierte Informationen zur sicheren Installation, Bedienung und Wartung des Geräts. Erfahren Sie mehr über die intelligenten Funktionen wie den Bewegungssensor zur Energieeinsparung, den Timer für individuelle Zeitpläne und die Heizleistung von 1800 Watt.</p>
 <p>Keramikheizer KH2</p> <p>Gebruiksaanwijzing 3 Instructions for use 9 Gebruiksaanwijzing 14 Mode d'emploi 20 Pyrodescriptio in gebruik 26 Bugsanwijzing 28</p> <p>www.steba.com</p>	<p>Steba KH2 Ceramic Heater User Manual</p> <p>Comprehensive user manual for the Steba KH2 ceramic fan heater, covering safe operation, features, maintenance, and disposal. It is designed for household use and emphasizes safety precautions.</p>
 <p>Pikkolo Basic Pikkolo 60 T 3</p> <p>Gebruiksaanwijzing Instructions for use Mode d'emploi Gebruiksaanwijzing</p> <p>Comprehensive user manual for Steba Pikkolo Basic and Pikkolo 60 T 3 fan heaters. Includes detailed instructions on safety, installation, operation, thermostat/timer use, maintenance, and warranty.</p>	<p>Steba Pikkolo Basic & Pikkolo 60 T 3 Fan Heater User Manual Safety, Operation, Installation</p> <p>Comprehensive user manual for Steba Pikkolo Basic and Pikkolo 60 T 3 fan heaters. Includes detailed instructions on safety, installation, operation, thermostat/timer use, maintenance, and warranty.</p>

 <p>Carbon-Heizstrahler CH 2 ECO</p> <p>202-01111 - 0001-06-2012-01</p> <p>Gebruiksaanwijzing 2 Instructions for use 9 Mode d'emploi 18 Brugsaanwijzing 23 Instrukcijskijedok 30 Gebruiksaanwijzing 37</p> <p>www.steba.com</p>	<p>Steba CH 2 ECO Carbon-Heizstrahler Bedienungsanleitung</p> <p>Dieses Dokument ist die Bedienungsanleitung für den Steba CH 2 ECO Carbon-Heizstrahler. Es enthält wichtige Informationen zur sicheren Bedienung, Installation, Nutzung, Reinigung und Entsorgung des Geräts. Wichtige Sicherheitshinweise, technische Spezifikationen und Kontaktdaten des Kundendienstes sind enthalten.</p>
 <p>Slush Maker FDM 2</p> <p>202-01111 - 0001-06-2012-01</p> <p>Gebruiksaanwijzing 2 Instructions for use 9 Mode d'emploi 18 Brugsaanwijzing 23 Instrukcijskijedok 30 Gebruiksaanwijzing 37</p> <p>www.steba.com</p>	<p>Steba Slush Maker FDM 2 User Manual and Instructions</p> <p>Detailed instructions and specifications for the Steba Slush Maker FDM 2, covering setup, operation, cleaning, and troubleshooting. Learn how to make perfect slushies, milkshakes, and frozen drinks.</p>
 <p>Zerkleinerer AC 20 zu Stabmixer MX 50</p> <p>202-01111 - 0001-06-2012-01</p> <p>Gebruiksaanwijzing 2 Instructions for use 9 Mode d'emploi 18 Brugsaanwijzing 23 Instrukcijskijedok 30 Gebruiksaanwijzing 37</p> <p>www.steba.com</p>	<p>Steba AC 20 Food Chopper Accessory for Stick Blender MX 50 - User Manual</p> <p>Official user manual and instructions for the Steba AC 20 food chopper accessory, designed for use with the Steba stick blender MX 50. Learn about safety, operation, cleaning, and disposal.</p>