

LEGO 41062

LEGO Disney Princess Elsa's Sparkling Ice Castle (Model 41062) Instruction Manual

Official User Guide

INTRODUCTION

Welcome to the magical world of Arendelle with your new LEGO Disney Princess Elsa's Sparkling Ice Castle. This set allows you to recreate iconic scenes and imagine new adventures with Queen Elsa, Princess Anna, and Olaf the snowman. Designed for builders aged 6-12, this set features a beautiful ice castle with interactive elements and various accessories for endless creative play.

PRODUCT OVERVIEW

The LEGO Disney Princess Elsa's Sparkling Ice Castle set (Model 41062) includes 292 pieces to construct a multi-level ice castle. Key features and included components are:

- **Elsa's Sparkling Ice Castle:** Features an icicle tree, a secret staircase, an ice cream bar, a bed, and an ice hill.
- **Mini-doll Figures:** Queen Elsa and Princess Anna.
- **Olaf the Snowman Figure:** A buildable Olaf figure with a rubbery carrot nose.
- **Accessories:** Skis, ice skates, glittery wall elements, decorative stickers, 2 capes, tiara, hair bow, a carrot nose for Olaf, a book, and various food items like popsicles and ice cream cones.
- **Sleigh:** A buildable sleigh for Anna and Elsa.



Image Description: The product box for LEGO Disney Princess Elsa's Sparkling Ice Castle, showing the assembled castle with Elsa and Anna figures, Olaf, and various play features. The box indicates ages 6-12 and 292 pieces.

SETUP AND ASSEMBLY

Follow the step-by-step instructions provided in the LEGO building guide included with your set. Ensure all pieces are accounted for before beginning assembly. The building process is designed to be engaging and enjoyable.

1. **Unpack Components:** Carefully open the box and sort the LEGO bricks by color and type to facilitate easier building.
2. **Follow Instructions:** Refer to the detailed instruction booklet to assemble the castle structure, mini-dolls, and accessories.
3. **Attach Stickers:** Apply decorative stickers as indicated in the instructions to enhance the castle's appearance.



Image Description: A close-up of the LEGO Anna mini-doll figure seated on a brown and pink sled, holding a golden torch with an orange flame. She wears a purple cape and a blue dress.



Image Description: A close-up of the LEGO Elsa mini-doll figure standing on purple skis. She wears a light blue dress with a shimmering cape.



Image Description: A close-up of the LEGO Olaf the snowman figure, featuring a rubbery orange carrot nose and stick arms. He stands next to a small white and green structure with a cookie.

OPERATING AND PLAY FEATURES

The Elsa's Sparkling Ice Castle offers numerous interactive play features:

- **Secret Staircase:** The castle features a secret staircase that can be moved to reveal hidden areas or create dynamic play scenarios.
- **Ice Hill:** Use the included sled or skis to slide down the ice hill for thrilling adventures.
- **Ice Cream Bar:** Serve frosty treats at the ice cream bar with the included popsicle and ice cream cone accessories.
- **Bed and Book:** Elsa's room includes a bed and a book for quiet moments or storytelling.
- **Character Interaction:** Engage Queen Elsa, Princess Anna, and Olaf in imaginative play, recreating scenes from the movie or inventing new stories.



Image Description: A rear view of the assembled LEGO Elsa's Sparkling Ice Castle, showcasing the spiral staircase, the ice cream bar area with Olaf, and Elsa on the upper balcony. Various accessories are visible.

MAINTENANCE

To ensure the longevity and cleanliness of your LEGO set:

- **Cleaning:** Clean LEGO bricks with mild soap and water (not exceeding 40°C or 104°F). Rinse thoroughly and air dry. Avoid using hot water, harsh chemicals, or abrasive materials.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent discoloration or warping of plastic elements.
- **Handling:** Handle the set with care to prevent pieces from detaching or breaking.

TROUBLESHOOTING

If you encounter any issues with your LEGO set, consider the following:

- **Missing Pieces:** In the rare event of a missing piece, please contact LEGO Customer Service directly through their official website.
- **Assembly Difficulties:** Double-check the instruction manual for the correct placement of bricks. Sometimes a small error can affect subsequent steps.
- **Loose Connections:** Ensure all bricks are firmly pressed together. LEGO connections are designed to be secure but may require a firm push.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	11.1 x 10.31 x 2.32 inches
Item Weight	1.06 pounds
ASIN	B00NHQGE04
Item Model Number	6100661
Manufacturer Recommended Age	6 years and up
Release Date	January 1, 2015
Manufacturer	LEGO

WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. For any concerns regarding product quality, missing parts, or general support, please visit the official LEGO Customer Service website or contact their support line. Specific warranty details may vary by region and product; refer to the packaging or LEGO's official website for the most current information. **Legal Disclaimer:** This product is brand new in a sealed box. Please refer to the manufacturer's official channels for any legal or warranty-related inquiries.