GoPro ARMTE-002

GoPro Smart Remote Control (ARMTE-002) Instruction Manual

Model: ARMTE-002

1. Introduction

The GoPro Smart Remote Control provides comprehensive control over your compatible GoPro cameras. This rugged, waterproof accessory allows you to manage camera functions, settings, and capture content from a distance, enhancing your filming experience in various environments.



Image 1: Front view of the GoPro Smart Remote Control.

2. What's in the Box

- GoPro Smart Remote
- Wrist Strap
- Key Ring
- USB Charging Cable

3. Product Features

- **Complete Camera Control:** Delivers full remote control of all camera functions, including shutter, on/off, and settings.
- **Long-Range Control:** Control your camera from distances of up to 600ft (180m) in optimal conditions.
- **Multi-Camera Control:** Enables control of up to 50 GoPro cameras at a time, ideal for multi-cam setups.
- **LCD Screen:** A built-in LCD screen mirrors your camera's status screen for quick confirmation of camera functions and settings.
- **Rugged Design:** The remote is wearable, mountable, and waterproof to 33ft (10m).
- **Enhanced Battery:** Features 40% increased battery capacity compared to the previous Wi-Fi Remote.

4. Setup

4.1 Charging the Remote

Before initial use, fully charge your Smart Remote. Connect the included USB charging cable to the remote's charging port and a USB power source. The LCD screen will display the charging status.



Image 2: The Smart Remote connected to its USB charging cable.

4.2 Pairing with Your GoPro Camera

To pair your Smart Remote with a compatible GoPro camera:

1. Ensure your GoPro camera is powered on and fully charged.
2. On your GoPro camera, navigate to the**Connections** menu (usually found by swiping down on the screen and then left to access preferences).
3. Select **Connect Device**, then choose **Smart Remote**.
4. On the Smart Remote, power it on by pressing the power/mode button.
5. The remote will display a pairing screen. Follow the on-screen prompts on both devices to complete the pairing process.
6. Once paired, the remote's LCD screen will mirror your camera's status.

5. Operating Instructions

5.1 Basic Controls

- **Power/Mode Button:** Press to power on/off the remote or cycle through camera modes (Video, Photo, Time Lapse).
- **Shutter/Select Button:** Press to start/stop recording, take a photo, or confirm selections in menus.
- **Settings/Tag Button:** Press to access camera settings or add a HiLight tag during recording.

5.2 Changing Modes and Presets

Use the **Power/Mode Button** to cycle through the main shooting modes. Once in a mode, use the **Settings/Tag Button** to browse through available presets for that mode. Confirm your selection with the **Shutter/Select Button**.

5.3 Adding HiLight Tags

During video recording, press the **Settings/Tag Button** to add a HiLight tag. This marks key moments in your footage, making them easier to find and edit later.

6. Compatibility

The GoPro Smart Remote Control (ARMTE-002) is compatible with the following GoPro camera models:

- HERO8 Black
- MAX
- HERO7 Black
- HERO6 Black
- HERO5 Black
- HERO5 Session
- Fusion

7. Maintenance

- **Waterproofing:** Ensure the charging port cover is securely closed before exposing the remote to water. The remote is waterproof up to 33ft (10m).
- **Battery Care:** To maximize battery life, avoid leaving the remote fully discharged for extended periods. Charge regularly.
- **Cleaning:** Clean the remote with a damp cloth. Avoid harsh chemicals.

8. Troubleshooting

- **Connectivity Issues:** If the remote loses connection or fails to pair, ensure both the remote and camera are fully charged and within range. Try re-pairing the devices.
- **Charging Problems:** If the remote does not charge, ensure the USB cable is properly connected and the power source is functional. Check the charging port for any debris.
- **Unresponsive Buttons:** Ensure the remote is powered on. If buttons remain unresponsive, try resetting the remote (refer to the remote's internal settings menu for a reset option).

9. Specifications

Feature	Detail

Product Dimensions	1.97 x 4.17 x 7.09 inches
Item Weight	3.52 ounces
Item Model Number	ARMTE-002
Batteries	1 CR123A batteries required (included)
Special Feature	Waterproof
Color	Black
Max Number of Supported Devices	1 (Note: Product features state up to 50 cameras can be controlled, but specifications list 1. Please refer to product packaging for definitive information.)

10. Warranty and Support

Legal Disclaimer: NO EXPRESSED WARRANTY. NO REFUND/RETURN IF RETAIL PACKAGING OPENED.

For further support or inquiries, please visit the official GoPro support website or contact their customer service.

© 2024 GoPro. All rights reserved.