Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- InSinkErator /
- > InSinkErator F-HC2200CRB Antique Instant Hot and Cold Water Dispenser Faucet User Manual

InSinkErator F-HC2200

InSinkErator F-HC2200CRB Antique Instant Hot and Cold Water Dispenser Faucet

USER MANUAL

Introduction

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of your InSinkErator F-HC2200CRB Antique Instant Hot and Cold Water Dispenser Faucet. This faucet is designed to deliver near-boiling hot water and filtered cold water instantly, enhancing convenience in your kitchen. Please read these instructions thoroughly before installation and use.

Note: This faucet requires a compatible InSinkErator hot water tank and filtration system (e.g., HWT-F1000S), which are sold separately, to function as an instant hot water dispenser.

Important Safety Information

- Always disconnect power to the hot water tank before performing any service or maintenance.
- · Ensure all plumbing connections are secure to prevent leaks.
- Near-boiling water can cause severe burns. Exercise caution when operating the hot water dispenser.
- Do not allow children to operate the hot water dispenser without supervision.
- This product is intended for household use only.

Product Components

The InSinkErator F-HC2200CRB faucet package typically includes:

- · Faucet assembly
- · Water supply lines
- · Flexible outlet tube
- Flexible vent tube
- · Mounting hardware

Additional items required (sold separately):

- InSinkErator HWT-F1000S Hot Water Tank
- InSinkErator Water Filtration System (e.g., F-1000 or F-2000)

Setup and Installation

Installation of the InSinkErator F-HC2200CRB faucet involves mounting the faucet to your sink or countertop, connecting it to the hot water tank, and integrating it with your water supply and filtration system. Due to the complexity of plumbing and electrical connections, professional installation is recommended. Refer to the detailed installation guide provided with your InSinkErator hot water tank and faucet for complete step-by-step instructions.



Figure 1: Front view of the InSinkErator F-HC2200CRB Antique Instant Hot and Cold Water Dispenser Faucet.



Figure 2: Side view of the InSinkErator F-HC2200CRB faucet, showing the two levers for hot and cold water.

Key Installation Considerations:

- Countertop Hole: Ensure your sink or countertop has a standard faucet hole (typically 1-3/8 to 1-1/2 inches in diameter).
- Tank Placement: The hot water tank should be installed under the sink, close to the faucet.
- **Electrical Outlet:** A grounded 115-volt, 3-prong electrical outlet is required for the hot water tank.
- Water Supply: Connect to a cold water supply line with a shut-off valve.

Operating Instructions

Once properly installed and the hot water tank is heated (allow approximately 15-20 minutes for initial heating), your InSinkErator F-HC2200CRB faucet is ready for use.

Dispensing Hot Water:

- 1. Locate the hot water lever (typically marked with red or on the left side).
- 2. Push the hot water lever **backwards** to activate the flow of near-boiling water.
- 3. The hot water lever is designed to automatically shut off when released, preventing continuous flow for safety.
- 4. Exercise extreme caution as the water dispensed is very hot.

Dispensing Cold Water:

- 1. Locate the cold water lever (typically marked with blue or on the right side).
- 2. Push the cold water lever **forwards** to activate the flow of filtered cold water.
- 3. The cold water lever is designed to stay on until manually turned off, allowing for continuous flow.



Figure 3: The faucet in use, dispensing hot water for instant meals.



Figure 4: The faucet can be used for various tasks, including warming baby bottles.

Maintenance

Regular maintenance ensures optimal performance and longevity of your InSinkErator faucet.

Cleaning:

- Clean the faucet exterior with a soft, damp cloth and mild soap. Avoid abrasive cleaners, polishes, or harsh chemicals, as these can damage the finish.
- For the Classic Oil Rubbed Bronze finish, gentle cleaning is recommended to preserve its appearance.

Filter Replacement:

The water filtration system (e.g., F-1000 or F-2000) connected to your hot water tank requires periodic filter replacement to maintain water quality and flow. Refer to your filter's specific instructions for replacement frequency, typically every 6-12 months depending on water usage and quality.



Figure 5: InSinkErator F-1000 and F-2000 water filters, essential for maintaining water quality.



Figure 6: The InSinkErator instant hot water tank, which supplies the hot water to the faucet.

Troubleshooting

If you encounter issues with your faucet, consult the following common troubleshooting steps. For more complex problems, refer to the full hot water tank manual or contact customer support.

Problem	Possible Cause	Solution
No hot water	Hot water tank not plugged in or powered on; tank not heated; water supply valve closed.	Check power to the tank; allow 15-20 minutes for heating; ensure water supply valve is open.
Slow flow from faucet	Clogged filter; low water pressure.	Replace water filter; check household water pressure.
Water dripping after hot water shut-off	Normal residual drip due to expansion/contraction; minor internal component issue.	A few drops are normal. If dripping is continuous or excessive, contact customer support.

Problem	Possible Cause	Solution
No cold water	Cold water supply valve closed; clogged filter.	Ensure cold water supply valve is open; replace water filter.

Specifications

Feature	Detail
Model Number	F-HC2200-CRB
Color	Classic Oil Rubbed Bronze
Style	Hot and Cold
Material	Brass
Item Weight	6 pounds
Product Dimensions	5.25 x 5.25 x 8 inches
Number of Handles	2
Power Source	Corded Electric (for tank, not faucet)
Certification	Certified frustration-free

Warranty and Support

Warranty Information:

This InSinkErator faucet is backed by a **5-Year We Come To You In-Home Service Warranty**. This warranty covers parts and labor for defects in materials or workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty service, or to purchase replacement parts, please contact InSinkErator customer support. Visit the official InSinkErator website for current contact information and support resources.

Online Resources: www.insinkerator.com