

Coleman Spa Filter Pump Replacement Cartridge Type VI User Manual

1. PRODUCT OVERVIEW

The Coleman Spa Filter Pump Replacement Cartridge Type VI is designed to maintain the cleanliness and clarity of your inflatable spa water. This cartridge effectively filters out debris and impurities, contributing to a hygienic and enjoyable spa experience. Regular replacement and cleaning are crucial for optimal performance.



Image: Two Coleman Spa Filter Pump Replacement Cartridges Type VI, showing their pleated design and blue end caps.

2. COMPATIBILITY

This replacement cartridge is compatible with various Coleman and Bestway Lay-Z Spa inflatable models, including:

- Coleman inflatable spas (models 54131E and 13804)
- Bestway Lay-Z Spa models: Vegas, Miami, and Monaco

The item number for this cartridge is 58323, and it is compatible with 58239.

3. INSTALLATION AND REPLACEMENT

Follow these steps to replace your spa filter cartridge:

1. **Turn off the spa pump:** Ensure the spa pump is completely turned off and unplugged from the power source before beginning any maintenance.
2. **Remove the filter housing cover:** Locate the filter housing inside your spa. Unscrew or unclip the cover to access the existing filter cartridge.
3. **Remove the old cartridge:** Carefully lift out the used filter cartridge from the housing. Dispose of the old cartridge responsibly.
4. **Insert the new cartridge:** Place the new Coleman Spa Filter Pump Replacement Cartridge Type VI into the filter housing, ensuring it sits securely.
5. **Secure the filter housing:** Replace the filter housing cover and secure it by screwing or clipping it back into place.
6. **Restart the pump:** Plug in and restart your spa pump. Check for any leaks and ensure the system is operating correctly.



Image: Hands demonstrating the removal of a used filter cartridge from its housing.



Image: Hands demonstrating the insertion of a new filter cartridge into its housing.

4. MAINTENANCE

4.1. Cleaning the Filter Cartridge

To prolong the life of your filter cartridge and maintain water quality, regular cleaning is recommended. The cartridges are designed to be easy to clean.

- Remove the filter cartridge from the spa as described in the installation steps.
- Use a garden hose with a straight flow nozzle to rinse the filter element. Work from the top to the bottom, holding the nozzle at a 45-degree angle.
- Wash all the pleats as well as between the pleats. Rinse until all dirt and debris is gone.
- For heavily soiled filters, a specialized filter cleaning solution can be used. Follow the product instructions for soaking and rinsing.
- Allow the filter to dry completely before reinserting it into the spa, or use a clean, dry spare filter.



Image: Hands rinsing a spa filter cartridge with a garden hose to remove debris.

4.2. Replacement Frequency

It is recommended to replace the filter cartridge at least once a month, or more frequently depending on spa usage and water conditions. Regular replacement ensures efficient filtration and prevents strain on your spa pump.

Your browser does not support the video tag.

Video: This video provides an overview of the Type VI spa filter, including its dimensions (106mm/4.2in diameter, 80mm/3.1in height) and its function in filtering various debris like leaves, hair, and sand from spa water. It highlights the filter's role in maintaining water clarity.

Your browser does not support the video tag.

Video: This video demonstrates the cleaning process for a spa filter, showing how to rinse it under running water to remove accumulated dirt and debris. It emphasizes the washable and reusable nature of the filter to prolong its service life.

Your browser does not support the video tag.

Video: This video illustrates the process of cleaning a pool filter, demonstrating how to use a garden hose with a straight flow nozzle to effectively remove dirt and debris from the filter pleats. It advises cleaning once a month and replacing based on usage to extend filter life.

5. SPECIFICATIONS

Specification	Detail
Item Weight	5.6 ounces
Manufacturer	Coleman
ASIN	B00NO8AURI
Item Model Number	58323

6. TROUBLESHOOTING

If your spa water appears cloudy or dirty despite regular use of the filter, consider the following:

- **Filter Clogging:** The filter may be heavily clogged. Remove and thoroughly clean the cartridge. If cleaning does not restore performance, replace it with a new one.
- **Chemical Imbalance:** Ensure your spa water chemistry (pH, alkalinity, sanitizer levels) is balanced. An imbalance can lead to cloudy water even with a clean filter.
- **Insufficient Filtration Time:** Verify that your spa pump is running for an adequate amount of time each day to properly circulate and filter the water.
- **Damaged Filter:** Inspect the filter cartridge for any tears or damage to the pleats. A damaged filter will not filter effectively and should be replaced.

7. WARRANTY AND SUPPORT

For specific warranty information and customer support regarding your Coleman Spa Filter Pump Replacement Cartridge Type VI, please refer to the documentation provided with your original spa purchase or contact Coleman customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.