Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Go-Bowen XW-EGK1-R

Baja 1000W 48V Electric Kids Go-Kart User Manual

Model: XW-EGK1-R | Brand: Go-Bowen

Introduction

Thank you for choosing the Go-Bowen Baja 1000W 48V Electric Kids Go-Kart. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new electric go-kart. Please read this manual thoroughly before initial use and retain it for future reference.

Important Safety Notice: Always ensure proper supervision of children operating this go-kart. Adhere to all local regulations regarding electric vehicle use.

Safety Warnings and Guidelines

- Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads.
- Ensure the 4-point seat belt is securely fastened before operation.
- Operate the go-kart only on flat, dry surfaces away from traffic, water, and other hazards.
- Do not exceed the maximum weight capacity of the go-kart.
- Keep hands, feet, hair, and clothing away from moving parts such as wheels and the chain drive.
- The parental key speed control should be used to set an appropriate maximum speed for the rider's skill level and environment.
- Regularly inspect the go-kart for any loose parts, damage, or wear before each use.
- Do not modify the go-kart in any way, as this may compromise safety and void the warranty.
- Charging should only be performed by an adult or under adult supervision.

Setup and Initial Preparation

Unpacking and Assembly

The Baja 1000W 48V Electric Kids Go-Kart comes largely pre-assembled. Minor assembly, such as attaching the upper roll bars, may be required. Refer to the included assembly diagram for detailed steps.

Initial Charging

Before first use, fully charge the 48 Volt battery. The charging box features indicator lights: a red light typically indicates charging, and a green light indicates a full charge. Ensure the go-kart is turned off during charging. Charging time may vary.



Image: Front 3/4 view of the Go-Bowen Baja 1000W 48V Electric Kids Go-Kart in red, showcasing its robust frame and knobby tires.

Operating Instructions

Starting the Go-Kart

1. Ensure the battery is fully charged.
2. Insert the parental key into the designated slot.
3. Select the desired speed setting using the parental key: 10mph, 13mph, or 20mph. Remove the key to lock in the speed setting for safety.
4. Adjust the seat for comfortable and safe reach of the controls.
5. Fasten the 4-point seat belt securely.
6. Turn the main power switch to the "ON" position.

Driving the Go-Kart

- The go-kart features a chain drive system for power delivery.
- Use the foot pedal for acceleration.
- To brake, press the foot-controlled hydraulic disc brake pedal.
- Utilize the F/R (Forward/Reverse) switch to change driving direction.
- The 13-inch knobby tires on steel rims are designed for various terrains.



Image: Rear 3/4 view of the Go-Bowen Baja 1000W 48V Electric Kids Go-Kart, highlighting the rear axle and motor housing.



Image: Front view of the Go-Bowen Baja 1000W 48V Electric Kids Go-Kart, showing the steering wheel and front mesh guard.

Maintenance

Battery Care

- Always fully charge the battery after each use, even if only used for a short period.
- If storing the go-kart for an extended period, charge the battery at least once a month to maintain its lifespan.
- Do not overcharge the battery. Disconnect the charger once the indicator light turns green.

Tire Maintenance

- Regularly check tire pressure and inflate to the recommended PSI (refer to tire sidewall for details).
- Inspect tires for wear, punctures, or damage. Small leaks can sometimes be treated with tire sealant.

General Cleaning and Inspection

- Clean the go-kart with a damp cloth. Avoid using harsh chemicals or direct water spray on electrical components.
- Periodically check all nuts, bolts, and fasteners to ensure they are tight.
- Inspect the chain drive for proper tension and lubrication.
- Ensure the brake system is functioning correctly and provides adequate stopping power.

Troubleshooting

Problem	Possible Cause	Solution
Go-kart does not start or move.	Battery is low or not charged; power switch is off; loose electrical connection.	Charge the battery fully; ensure power switch is ON; check all connections.
Go-kart loses power or runs slowly.	Low battery charge; battery nearing end of life; motor issue.	Recharge battery; consider battery replacement if issue persists; contact support for motor issues.
Throttle not responding (especially in speed 2).	Loose connection to throttle pedal or motor; switch malfunction.	Check connections; try cycling power and F/R switch; if issue persists, professional inspection may be needed.
Tire losing air.	Puncture or valve stem issue.	Inspect for punctures; apply tire sealant for small leaks; replace tire or inner tube if necessary.

Specifications

Feature	Detail
Motor Power	1000 Watt Brushless Motor
Battery	48 Volt

Feature	Detail
Parental Speed Control	10mph, 13mph, 17-20mph (three settings)
Driving System	Chain Drive
Brake System	Disc Brake (Foot Control)
Frame Material	High-tensile Steel
Forward and Reverse	F/R Switch
Seat	Adjustable By 0.5 inch
Seat Belt	Yes (4-point harness)
Tires	13-inch Knobby Tires on Steel Rims
Color	Red
Item Dimensions (LxWxH)	55 x 26 x 33 inches
Packing Size	55 x 33 x 26 inches
Net Weight (N.W)	141 LBS
Gross Weight (G.W)	179 LBS
Model Number	XW-EGK1-R

Warranty and Support

Warranty Information

The product includes a 30-day warranty for all defective parts. Customers must return the old defective part before a new one is shipped. Replacement parts are typically mailed out within 5-14 business days.
Please Note:

- Accidents, Abuse, Neglect, Labor & Mechanic costs, and Return Shipping are NOT covered under warranty.
- A 30% restocking fee will apply for returns.
- Upon delivery, please inspect the cargo for any damage. If any box or package is damaged, inform the delivery driver and ensure it is noted on the Bill of Lading.

Customer Support

For any questions, technical assistance, or warranty claims, please contact Go-Bowen customer support. Refer to your purchase documentation for specific contact details.
Disclaimer: The manufacturer is not responsible for any accidents or injuries occurring due to any reason whatsoever (including manufacturer's default) on your purchased go-kart. In no event will the manufacturer and all its affiliates be liable for damages, lost revenue, lost wages, lost savings, or any other incidental or consequential damages arising from purchase, use, or inability to use the product or for manufacturer's defects. The manufacturer

and all its affiliates are not responsible for any damages arising from misuse, natural, or personal disaster.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can the seat on the Go-Bowen Baja 1000W 48V Electric Kids Go-Kart be adjusted backward?

Yes, the seat on the Go-Bowen Baja 1000W 48V Electric Kids Go-Kart (Model XW-EGK1-R) is adjustable. According to the product specifications, the seat can be adjusted by approximately 0.5 inches to help the rider...

Read full answer

How do I adjust the seat on the Go-Bowen Baja 1000W 48V Electric Kids Go-Kart?

The Go-Bowen Baja 1000W 48V Electric Kids Go-Kart (Model XW-EGK1-R) features an adjustable seat to ensure the rider can comfortably and safely reach the foot pedals and steering wheel. According to the product specifications,...

Read full answer

Open the live page

https://manuals.plus/asin/B00NOD6T4G

More documents and user manuals: **https://manuals.plus/**