Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TELESIN GP-JFM-003

TELESIN 360° Rotating Clip Mount User Manual

Model: GP-JFM-003

1. Introduction

Thank you for choosing the TELESIN 360° Rotating Clip Mount. This product is designed to provide a secure and versatile mounting solution for your action camera, allowing you to capture hands-free footage from various perspectives. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your clip mount to ensure optimal performance and longevity.

2. Product Overview and Features

The TELESIN 360° Rotating Clip Mount is a robust accessory crafted for action camera enthusiasts. Its key features include:

- **360° Rotation:** Allows for complete angle adjustment, enabling you to capture footage from any desired direction without remounting.
- **Secure Grip:** Equipped with strong clamping force and serrated teeth to firmly attach to backpack straps, belts, or other compatible surfaces.
- **Durable Construction:** Made from high-quality PC (Polycarbonate) and Stainless Steel for long-lasting use in various environments.
- **Wide Compatibility:** Designed to work with most action cameras, including GoPro Hero series, DJI Osmo Action, Insta360, SJCAM, Xiaomi Yi, and more.
- **Lightweight Design:** Weighing approximately 60-70 grams, it adds minimal bulk to your gear.



Image 1: The TELESIN clip mount features a 360-degree rotatable base for flexible camera positioning.



Image 2: Detail of the clip's robust serrated jaws, designed for a secure and stable attachment.

3. Package Contents

Please check the package for the following items:

- TELESIN 360° Rotating Clip Mount x 1
- Mounting Screw x 1

Note: Action camera, camera case, and backpack strap are not included.

4. Setup Instructions

1. **Attach Camera to Mount:** Align your action camera's mounting frame or waterproof case with the three-pronged interface on the clip mount. Insert the provided mounting screw through the aligned holes and tighten it securely by hand. Ensure the camera is stable and does not wobble.
2. **Attach Mount to Surface:** Open the clip mount by pressing the release mechanism. Position the open jaws around a backpack strap, belt, or other suitable surface. Ensure the surface is between 1mm and 10mm thick for optimal grip. Release the clip to secure it firmly. The serrated teeth will help prevent slipping.
3. **Verify Security:** Gently tug on the mounted camera and clip to ensure it is securely fastened and will not detach during activity.



Image 3: The clip mount securely attached to a backpack shoulder strap with an action camera.

5. Operating Instructions

Once the clip mount and camera are securely attached, you can adjust your shooting angle:

- **Adjusting Camera Angle:** The base of the mount allows for 360° rotation. Gently rotate your camera to achieve the desired

horizontal angle. The rotation mechanism is designed to be firm to maintain your chosen angle during movement.

- **Vertical Adjustment:** If your camera's mounting frame allows, you can also adjust the vertical tilt of your camera using its native hinge mechanism.

6. Maintenance

To ensure the longevity and optimal performance of your TELESIN 360° Rotating Clip Mount, follow these maintenance guidelines:

- **Cleaning:** Wipe the mount with a soft, damp cloth to remove dust, dirt, or debris. Avoid using harsh chemicals or abrasive cleaners, as these can damage the materials.
- **Storage:** Store the mount in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically inspect the mount for any signs of wear, cracks, or damage, especially before critical use. Ensure the mounting screw is not stripped and the clip mechanism operates smoothly.

7. Troubleshooting

- **Issue: The 360° rotation is very stiff.**
  Solution: The rotation mechanism is designed to be firm for secure positioning. It may be stiff when new. Rotate it several times, and it will gradually become smoother. Installing the camera onto the mount can also make rotation easier due to added leverage.
- **Issue: The clip does not hold securely.**
  Solution: Ensure the surface you are clipping to is within the recommended thickness (approx. 1mm-10mm). Make sure the serrated teeth are fully engaged with the fabric or material. Avoid clipping to very thin or slippery surfaces.
- **Issue: Camera wobbles after mounting.**
  Solution: Ensure the mounting screw connecting the camera to the clip mount is fully tightened. Check that your camera's frame or case is properly seated on the mount's interface.

8. Specifications

Brand	TELESIN
Model Name	GP-JFM-003
Color	Black
Material	PC (Polycarbonate), Stainless Steel, ABS, Metal
Product Dimensions	6 cm x 4 cm x 5 cm
Product Weight	Approx. 60-70 grams
Max Load Capacity	70 grams
Mounting Type	Clamp Mount
Rotation	360° Rotatable
Compatibility	Most action cameras (GoPro, DJI Osmo Action, Insta360, Xiaomi Yi, etc.)
UPC / GTIN	710228943446

9. Warranty and Support

Your TELESIN 360° Rotating Clip Mount comes with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.
If you encounter any initial defects or issues with your product, please contact your retailer or TELESIN customer support for assistance. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00NPRE2WM

More documents and user manuals: **https://manuals.plus/**