

Sealey CT30048P100W

Sealey CT30048P100W 300 x 4.8mm White Cable Tie User Manual

Model: CT30048P100W | Brand: Sealey

1. INTRODUCTION

This instruction manual provides essential information for the proper use and handling of your Sealey CT30048P100W White Cable Ties. These cable ties are designed for securing cables, wires, and other items, offering a reliable and heat-resistant solution for various applications.

2. SAFETY INFORMATION

- Keep cable ties out of reach of children to prevent choking hazards.
- Do not use cable ties for lifting or supporting human weight.
- Avoid using cable ties near open flames or extreme heat sources beyond their specified temperature range.
- Exercise caution when trimming excess tie material to prevent injury from sharp edges.
- Inspect cable ties for any damage or defects before use. Do not use damaged ties.

3. PRODUCT OVERVIEW

The Sealey CT30048P100W cable ties are made from durable Nylon 66, providing excellent heat resistance from -40°C to +85°C. Each pack contains 100 white cable ties, each measuring 300mm in length and 4.8mm in width. They are suitable for a wide range of applications including workshop, garden, and home use.



Figure 1: A bundle of Sealey CT30048P100W white cable ties, showing their uniform appearance and flexible material.

Key Features:

- Manufactured from Nylon 66 for durability.
- Heat resistant over the temperature range -40°C to $+85^{\circ}\text{C}$.
- Supplied in convenient packs of 100.
- Versatile for workshop, garden, and home applications.

4. APPLICATION INSTRUCTIONS

Follow these steps to properly apply a Sealey cable tie:

1. **Preparation:** Gather the items you wish to secure. Ensure the cable tie is of appropriate length and strength for the task.
2. **Insertion:** Take one cable tie. Insert the pointed end of the tie into the locking head (the square-shaped end) until it passes through.
3. **Securing:** Wrap the cable tie around the items to be secured. Pull the pointed end through the locking head to tighten the loop. Pull firmly until the items are held securely in place, ensuring the tie is snug but not overly tight to avoid damage to the secured items.
4. **Trimming (Optional):** If there is excess tie material protruding from the locking head, use a pair of sharp scissors or a cable tie cutting tool to trim the excess flush with the head. This prevents snagging and provides a neat finish.

Once tightened, the cable tie is designed for single-use and cannot be easily released without cutting.

5. MAINTENANCE AND STORAGE

To ensure the longevity and performance of your cable ties:

- **Storage:** Store unused cable ties in their original packaging or a sealed container in a cool, dry place, away from direct sunlight and extreme temperatures. Prolonged exposure to UV light can degrade the nylon material.
- **Handling:** Avoid excessive bending or creasing of cable ties before use, as this can weaken the material.
- **Cleaning:** Cable ties do not require cleaning. If they become dirty, a simple wipe with a damp cloth is sufficient.

6. TROUBLESHOOTING

- **Cable tie breaks during tightening:**

Ensure you are using the correct size cable tie for the bundle. Avoid excessive force when tightening. Inspect the tie for any pre-existing damage or manufacturing defects before use.
- **Cable tie does not secure or slips:**

Verify that the pointed end is fully inserted into the locking head and pulled through completely. Ensure the locking mechanism is engaged. If the tie still slips, it may be too large for the application, or the locking mechanism might be faulty (in which case, discard and use a new tie).

7. SPECIFICATIONS

Attribute	Value
Model Number	CT30048P100W
Brand	Sealey
Material	Nylon 66
Color	White
Length	300 mm
Width	4.8 mm
Quantity per Pack	100
Temperature Range	-40°C to +85°C
Style	Zip

8. WARRANTY AND SUPPORT

Specific warranty details for the Sealey CT30048P100W cable ties are not provided within this document. For information regarding warranty coverage, product support, or any technical inquiries, please contact Sealey customer service directly or refer to the official Sealey website.

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question