

Manuals.plus /

› Victrola /

› Victrola The Quincy 6-in-1 Bluetooth Record Player & Multimedia Center User Manual

## Victrola VTA-200B

# Victrola The Quincy 6-in-1 Bluetooth Record Player & Multimedia Center

Model: VTA-200B | Brand: Victrola

## PRODUCT OVERVIEW

The Victrola Nostalgic 6-in-1 Solid Wood Record Player and Multimedia Player is a perfect blend of modern technology and nostalgic design. This versatile entertainment center allows you to enjoy music through various formats, including vinyl records, CDs, cassettes, AM/FM radio, and wireless Bluetooth streaming.

Key features include:

- **6-in-1 Entertainment Center:** Play vinyl records, CDs, cassettes, AM/FM radio, or stream music via Bluetooth or 3.5mm Aux/headphone jack.
- **Integrated System:** No additional stereo equipment is required for immediate use.
- **Three-Speed Turntable:** Supports 33 1/3, 45, and 78 RPM records with upgraded premium sound quality.
- **Expanded Connectivity:** RCA Line outputs for external speakers/amplifiers and a headphone jack for private listening.
- **Intuitive Controls:** Features an input select knob, power button, volume knob, AM/FM tuner, playback controls, and dedicated CD/cassette buttons.
- **High-Quality Design:** Crafted with a stylish retro real wood case, strong hinges, and fabric grilles.



Front view of the Victrola The Quincy 6-in-1 Record Player in Mahogany finish.

# ALL-IN-ONE MUSIC POWERHOUSE



An annotated diagram highlighting the various features: FM Radio, 3-Speed Turntable, Bluetooth Connectivity, CD Player, 3.5mm AUX Input & Headphone Jack, and Cassette Player.

## SETUP GUIDE

- 1. Unpacking:** Carefully remove the unit from its packaging. Ensure all components, including the turntable, power adapter, and any included cables (like RCA), are present.
- 2. Placement:** Place the record player on a stable, flat surface away from direct sunlight, heat sources, and excessive dust. Ensure adequate ventilation around the unit.
- 3. Power Connection:** Connect the power adapter to the DC IN jack on the back of the unit, then plug it into a standard wall outlet.
- 4. Turntable Preparation:** Remove the stylus protector from the turntable's needle. Ensure the turntable's transport screw (if present, usually located near the platter) is adjusted according to the instructions to allow the platter to spin freely.
- 5. Initial Power On:** Turn the POWER knob to the ON position. The unit's display should illuminate.

## OPERATING INSTRUCTIONS

### Playing Vinyl Records

1. Turn the function knob to 'PHONO'.
2. Place a record on the turntable platter.
3. Select the appropriate speed (33 1/3, 45, or 78 RPM) using the speed selector switch.
4. Lift the tone arm using the cue lever and position it over the desired track on the record.
5. Gently lower the tone arm onto the record using the cue lever. The platter will begin to spin and music will play.
6. At the end of the record, the tone arm will automatically return to its rest position (auto-stop feature).



**REDISCOVER YOUR VINYL  
COLLECTION WITH IMMERSIVE,  
WELL-DEFINED SOUND.**

**SUPPORTS  
33  $\frac{1}{3}$ , 45, 78 RPM**

Rediscover your vinyl collection with immersive, well-defined sound. Supports 33  $\frac{1}{3}$ , 45, and 78 RPM.

### **Playing CDs**

1. Turn the function knob to 'CD'.
2. Press the 'OPEN/CLOSE' button to open the CD tray.
3. Place a CD into the tray with the label side facing up.
4. Press the 'OPEN/CLOSE' button again to close the tray. The CD will load and begin playing automatically or display track information.
5. Use the 'PLAY/PAUSE', 'NEXT', and 'PREVIOUS' buttons for playback control.

### **Playing Cassettes**

1. Insert a cassette tape into the cassette slot on the side of the unit.
2. The tape will automatically begin playing.
3. Use the 'PLAY/PAUSE', 'FAST FORWARD', and 'REWIND' buttons for control. Press 'EJECT' to remove the cassette.



**EVERYTHING YOU NEED,  
EASY TO ENJOY.**

**QUICK SETUP AND INTUITIVE  
CONTROLS LET YOU DIVE  
STRAIGHT INTO THE MUSIC.**

Quick setup and intuitive controls let you dive straight into the music, including the side-loading cassette player.

### **Listening to AM/FM Radio**

1. Turn the function knob to 'FM' or 'AM'.
2. Rotate the 'TUNING' knob to select your desired radio station.
3. Adjust the volume using the 'VOLUME' knob.

### **Bluetooth Streaming**

1. Turn the function knob to 'BT' (Bluetooth). The unit will enter pairing mode, indicated by a flashing Bluetooth indicator.
2. Enable Bluetooth on your smartphone or other audio device.
3. Select 'Victrola VTA-200B' from the list of available devices.
4. Once paired, the Bluetooth indicator will become solid, and you can stream music wirelessly through the unit's speakers.

**NO RECORD?  
NO PROBLEM.**



**STREAM MUSIC WIRELESSLY  
FROM YOUR SMART DEVICE WITH  
RICH, ROOM-FILLING SOUND.**

Stream music wirelessly from your smart device with rich, room-filling sound via Bluetooth connectivity.

### **Using Auxiliary Input / External Speakers**

- **Auxiliary Input:** Connect an external audio device (e.g., MP3 player) to the 3.5mm AUX IN jack on the front panel. Select 'AUX' mode to play audio from the connected device.
- **External Speakers:** For enhanced sound, connect external speakers or an amplifier to the RCA Line outputs on the back of the unit. Ensure proper left and right channel connections.

**CLEAR, POWERFUL SOUND FROM  
BUILT-IN STEREO SPEAKERS.**



Clear, powerful sound from built-in stereo speakers, with an option to amplify further with external speaker connections.

## **MAINTENANCE AND CARE**

- **Cleaning the Unit:** Wipe the exterior of the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Cleaning the Stylus:** Gently clean the stylus (needle) periodically with a soft brush, brushing from back to front.
- **Record Care:** Keep records clean and free of dust. Store them vertically in their sleeves to prevent warping.
- **CD/Cassette Care:** Handle CDs by the edges to avoid fingerprints. Store cassettes in their cases to protect the tape.
- **Ventilation:** Ensure the unit has proper ventilation and is not placed in an enclosed space that could trap heat.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not securely connected; Power outlet not active.	Ensure power cord is firmly plugged in. Test outlet with another device.
No sound from turntable	Function knob not set to 'PHONO'; Stylus protector still on; Tone arm not lowered onto record; Volume too low.	Select 'PHONO' mode. Remove stylus protector. Lower tone arm. Increase volume.
Turntable not spinning	Tone arm not moved over record; Transport screw not loosened.	Move tone arm over record to activate auto-start. Ensure transport screw is loosened for operation.
Bluetooth not connecting	Unit not in 'BT' mode; Device too far; Already paired with another device.	Select 'BT' mode. Move device closer (within 33 ft). Disconnect from other devices.
CD not playing	CD inserted incorrectly; CD is scratched/damaged.	Ensure CD is inserted label-side up. Try a different CD.
Cassette not playing/ejecting	Cassette inserted incorrectly; Tape jammed.	Ensure cassette is fully inserted. Gently try to eject. Do not force.

## PRODUCT SPECIFICATIONS

**Product Dimensions:** 18.1 x 13.4 x 9.5 inches (460 x 340 x 255 mm)

**Item Weight:** 17.6 pounds

**Model Number:** VTA-200B

**Brand:** Victrola

**Connectivity Technology:** Wireless (Bluetooth)

**Maximum Rotational Speed:** 78 RPM

**Material:** Engineered Wood

**Color:** Mahogany

**Manufacturer:** Innovative Technology

**Country of Origin:** China

**Included Components:** Bluetooth Turntable

**Special Features:** Manual Belt Drive, Volume Control, RCA Output, Built-In Bluetooth Receiver

**On-mode power consumption:** 30 watts

**18"**  
**460MM**



**10"**  
**255MM**

**13.4"**  
**340MM**

Detailed dimensions of the Victrola The Quincy 6-in-1 Record Player.

## **WARRANTY AND SUPPORT**

For detailed warranty information and customer support, please refer to the official user manual provided with your product or visit the Victrola support website.

A digital version of the user manual is available for download: [User Manual \(PDF\)](#)

Protection plans are also available for extended coverage:

- 2-Year Protection Plan: \$9.99
- 3-Year Protection Plan: \$13.49
- Complete Protect: \$16.99/month (covers all eligible past and future purchases)

