Beurer 637.08

Beurer FB 35 Foot Spa

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Beurer FB 35 Foot Spa. This device is designed to provide a relaxing and therapeutic foot massage experience with vibration, bubble massage, water temperature control, magnetic field application, and integrated aroma therapy. Please read this instruction manual carefully before first use and keep it for future reference. Proper use and maintenance will ensure the longevity and optimal performance of your foot spa.

Safety Instructions

Always observe the following safety instructions to prevent personal injury or damage to the device:

- **Dry Environment Use:** Use the device only in dry areas. Do not use it in bathrooms or other damp environments where it could come into contact with water.
- **No Immersion:** Never immerse the device in water or any other liquids. This can cause electrical shock or damage to the unit.
- **Power Supply:** Ensure the power supply matches the voltage specified on the device.
- **Supervision:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Medical Advice:** If you have any health concerns, especially regarding circulation, diabetes, or open wounds on your feet, consult your doctor before using the foot spa.
- **Damaged Device:** Do not operate the device if it is damaged, has a damaged cable, or if it has been dropped. Contact customer service for repair.
- **Unplug When Not in Use:** Always unplug the device from the power outlet after use and before cleaning.

Product Features

The Beurer FB 35 Foot Spa is equipped with several features to enhance your foot care experience:

- **3 Functions:** Vibration massage, bubble massage, and water temperature control.
- **Aroma Filter:** Integrated filter for the use of bath additives, allowing for relaxing aroma therapy.
- **Infrared Light Points:** Soothing infrared light points for added relaxation.
- **Magnetic Field Application:** 16 integrated magnets for magnetic field therapy.
- **Pedicure Attachments:** Three changeable pedicure attachments for comprehensive foot care, with practical hanging storage.
- **Foot Reflex Zone Massage:** Removable roller attachments for targeted foot reflex zone massage.
- **Massage-Supported Footbed:** Textured footbed for additional massage benefits.
- **Convenient Design:** Practical carrying handle, removable splash guard, non-slip rubber feet, and cable winding for easy storage.
- **Double-Walled Construction:** For improved heat insulation, helping to maintain water temperature.

Package Contents

Please check that all items are present and undamaged upon unpacking:

- Beurer FB 35 Foot Spa
- 3 changeable Pedicure Attachments (Brush attachment, Massage attachment, Callus remover)
- Removable Roller Attachments (pre-installed or separate)
- Instruction Manual



Image: The three interchangeable pedicure attachments: brush, massage, and callus remover.

Setup

1. **Placement:** Place the foot spa on a firm, level, and non-slip surface. Ensure there is enough space around the unit for comfortable use.
2. **Fill with Water:** Fill the foot spa with warm or cold water up to the indicated maximum fill line. Do not overfill.
3. **Add Additives (Optional):** If desired, place bath salts or other suitable bath additives into the integrated aroma filter. Do not add essential oils or other substances directly into the water without using the aroma filter, as this may damage the unit.

4. **Connect Power:** Plug the power cord into a suitable electrical outlet.



Image: The Beurer FB 35 Foot Spa with its main components visible, including the control panel and footbed.



Image: A close-up view of the aroma filter, designed to hold bath salts or other additives.

Operating Instructions

Follow these steps to operate your Beurer FB 35 Foot Spa:

1. **Power On:** Press the power button on the control panel to turn on the device.
2. **Select Function:** Choose your desired massage function using the control buttons:
    - **Vibration Massage:** Activates a gentle vibrating sensation.
    - **Bubble Massage:** Produces soothing bubbles for a relaxing effect.
    - **Water Temperature Control:** Helps maintain the water temperature. Note: This function is primarily for temperature maintenance, not rapid heating of cold water.
3. **Foot Placement:** Carefully place your feet into the foot spa.
4. **Use Reflex Zone Rollers:** For a more intense foot reflex zone massage, move your feet back and forth over the removable roller attachments located on the footbed.
5. **Pedicure Attachments:** Attach one of the three pedicure attachments (brush, massage, or callus remover) to the central post for targeted foot care. Gently apply pressure as needed.

6. **Enjoy:** Relax and enjoy your foot spa session. The infrared light points will automatically activate when the unit is on.
7. **Power Off:** After your session, press the power button again to turn off the device.



Image: A person comfortably using the Beurer FB 35 Foot Spa, demonstrating typical usage.

Maintenance and Cleaning

Regular cleaning and proper maintenance will extend the life of your foot spa:

1. **Unplug:** Always unplug the device from the power outlet before cleaning.
2. **Empty Water:** Carefully empty the water from the foot spa. Do not pour water over the control panel or power cord.
3. **Clean Surfaces:** Wipe down the interior and exterior surfaces of the foot spa with a damp cloth and mild detergent. Do not use abrasive cleaners or harsh chemicals.
4. **Clean Attachments:** Rinse the pedicure attachments and roller attachments under running water. Allow them to air dry completely before storing.
5. **Dry Thoroughly:** Ensure all parts of the foot spa are completely dry before storing it.
6. **Storage:** Store the foot spa in a cool, dry place, away from direct sunlight and moisture. Use the cable winding feature for neat storage of the power cord.

Troubleshooting

If you encounter any issues with your Beurer FB 35 Foot Spa, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Not plugged in; power outlet faulty; device damaged.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another appliance. If still not working, contact customer service.

Problem	Possible Cause	Solution
No bubbles or vibration.	Function not selected; water level too low/high; air vents blocked.	Ensure the correct function button is pressed. Check water level is between MIN and MAX lines. Ensure air vents are not blocked by debris.
Water is not heating up or maintaining temperature.	Heating element not active; initial water temperature too low.	The device primarily maintains temperature; it does not rapidly heat cold water. Start with warm water for best results. Ensure the temperature control function is selected.
Unusual noise during operation.	Normal operating noise; foreign object inside; motor issue.	Some noise is normal for bubble and vibration functions. Check for any foreign objects in the foot spa. If noise is excessive or unusual, discontinue use and contact customer service.

Specifications

Feature	Detail
Model Number	637.08
Brand	Beurer
Functions	Vibration massage, Bubble massage, Water temperature control
Additional Features	Infrared light points, Magnetic field application (16 magnets), Aroma filter
Pedicure Attachments	3 changeable (Brush, Massage, Callus remover)
Power Source	Corded Electric
Power (Watt)	140 W
Product Dimensions (L x W x H)	41 x 38 x 17 cm (16.1 x 15 x 6.7 inches)
Item Weight	2.4 kg (5.29 lbs)
Material	Rubber (for non-slip feet)
Color	White, Red

Warranty and Support

The Beurer FB 35 Foot Spa comes with a**3-year warranty**. For detailed warranty conditions and to register your product, please refer to the official Beurer website or contact Beurer customer support directly. If you have any questions, require technical assistance, or need to claim warranty service, please contact the manufacturer's customer service department. Keep your proof of purchase for warranty claims.
You can find more information and contact details on the official Beurer website:www.beurer.com

© 2025 Beurer GmbH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question