Beurer BY 76

Beurer BY 76 Steam Sterilizer Instruction Manual

Model: BY 76

1. Introduction

The Beurer BY 76 Steam Sterilizer is designed to provide a hygienic environment for your infant by effectively disinfecting baby bottles, pacifiers, and other baby accessories using steam. This manual contains important information regarding the safe and proper use, maintenance, and troubleshooting of your device. Please read these instructions carefully before first use and keep them for future reference.

2. Safety Instructions

Always observe the following safety precautions to prevent injury or damage to the device:

- Read all instructions thoroughly before operating the sterilizer.
- Keep the appliance out of reach of children.
- Do not immerse the main unit, power cord, or plug in water or other liquids.
- Use only distilled water to minimize limescale buildup on the heating plate.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from heat sources.
- Unplug the sterilizer from the power outlet when not in use, before cleaning, or if a malfunction occurs.
- Exercise caution when opening the lid after sterilization, as hot steam will escape. Use the provided gripping tongs to remove hot items.
- Do not operate the appliance if it has been damaged or is not functioning correctly. Contact customer service for repairs.

3. Package Contents

Verify that all items are present and undamaged upon unpacking:

- 1x Beurer BY 76 Steam Sterilizer Base Unit
- 1x Removable Bottle Grid
- 1x Accessory Tray
- 1x Lid

- 1x Gripping Tongs
- 1x Measuring Cup
- 1x Instruction Manual

4. Product Components



Figure 1: Beurer BY 76 Steam Sterilizer. This image shows the complete sterilizer unit, including the white base with the Beurer logo and control panel, the yellow internal components (bottle grid and accessory tray), and the transparent lid.

1. **Lid:** Transparent cover to contain steam.

2. **Accessory Tray:** Upper tray for smaller items like pacifiers and bottle caps.
3. **Bottle Grid:** Lower grid designed to hold up to six baby bottles.
4. **Base Unit:** Contains the heating plate and electronic controls.
5. **LED Display:** Shows remaining sterilization time.
6. **Control Button:** For starting and stopping the sterilization cycle.
7. **Heating Plate:** Located at the bottom of the base unit, where water is heated to produce steam.

5. Setup

Follow these steps for initial setup and before each use:

1. **Placement:** Place the sterilizer on a clean, flat, and stable surface, ensuring it is out of reach of children.
2. **Initial Cleaning:** Before first use, wash all removable parts (lid, accessory tray, bottle grid, gripping tongs, measuring cup) with warm soapy water, rinse thoroughly, and dry. Wipe the base unit with a damp cloth.
3. **Add Water:** Using the provided measuring cup, add 100 ml of distilled water directly onto the heating plate in the base unit. Do not overfill or underfill.
4. **Load Items:**
   - Place clean, empty baby bottles upside down onto the bottle grid.
   - Place smaller accessories such as pacifiers, teats, and bottle caps onto the accessory tray.
5. **Close Lid:** Place the lid securely onto the sterilizer unit.

6. Operating Instructions

To begin the sterilization process:

1. **Connect Power:** Plug the sterilizer into a suitable electrical outlet.
2. **Start Cycle:** Press the control button on the front of the base unit. The LED display will illuminate, and the sterilization cycle will begin.
3. **Sterilization Process:** The unit will heat the water to produce steam, which disinfects the contents. The LED display will show the remaining sterilization time, which is approximately 7 minutes.
4. **Cycle Completion:** Once the sterilization cycle is complete, an acoustic signal will sound, and the LED display may indicate "0" or turn off.
5. **Cool Down:** Allow the unit to cool down for a few minutes before opening the lid. The contents will remain sterile for up to 3 hours if the lid remains closed.
6. **Remove Items:** Carefully open the lid, directing steam away from your face. Use the provided gripping tongs to safely remove the hot, sterilized items.
7. **Unplug:** Unplug the sterilizer from the power outlet after use.

7. Cleaning and Maintenance

Regular cleaning and maintenance ensure optimal performance and longevity of your sterilizer:

- **Daily Cleaning:** After each use, unplug the unit and allow it to cool. Discard any remaining water from the heating plate. Wash the lid, accessory tray, bottle grid, gripping tongs, and measuring cup with warm soapy water and rinse thoroughly. These components are also dishwasher safe.
- **Base Unit Cleaning:** Wipe the exterior of the base unit with a damp cloth. Do not use abrasive cleaners or immerse the base unit in water.

- **Descaling:** Limescale can build up on the heating plate, especially in areas with hard water. Descale the unit regularly (e.g., weekly or bi-weekly, depending on water hardness).
  a. Ensure the unit is unplugged and cool.
  b. Pour 100 ml of white vinegar (or a suitable descaling solution) onto the heating plate.
  c. Allow it to soak for 30 minutes to an hour, or longer for heavy buildup. Do not turn on the sterilizer during descaling.
  d. Pour out the vinegar and rinse the heating plate thoroughly with clean water several times to remove any residue.
  e. Run a sterilization cycle with clean water (without items) to ensure all vinegar residue is removed before sterilizing baby items again.
- **Storage:** Store the clean and dry sterilizer in a cool, dry place away from direct sunlight.

8. Troubleshooting

Refer to this section for common issues and their solutions:

Problem	Possible Cause	Solution
Sterilizer does not turn on.	No power supply.	Check if the power cord is securely plugged into the outlet and the unit. Test the outlet with another appliance.
Sterilization cycle is too short or ineffective.	Insufficient water or lid not properly closed.	Ensure 100 ml of water is added to the heating plate. Verify the lid is securely closed before starting.
White or brown residue on the heating plate.	Limescale buildup from hard water.	Perform the descaling procedure as described in Section 7. Use distilled water for future cycles.
Strong odor during operation.	New unit odor or residue from previous cleaning.	Run a few sterilization cycles with only water (no items) to dissipate new unit odors. Ensure thorough rinsing after descaling.

9. Technical Specifications

- **Model:** BY 76
- **Product Number:** 953.08
- **Dimensions (L x W x H):** 22.5 x 22.5 x 33.5 cm
- **Weight:** Approximately 1.23 kg
- **Sterilization Time:** Approximately 7 minutes (excluding heating time)
- **Capacity:** Up to 6 baby bottles and accessories
- **Display Type:** LED
- **Main Material:** Silicone (for certain components)
- **Country of Origin:** China

10. Warranty and Support

For information regarding warranty terms, conditions, and customer support, please refer to the warranty card included with your purchase or visit the official Beurer website. You may also contact Beurer customer service directly for assistance with product inquiries, technical support, or spare parts.
Manufacturer: Beurer GmbH
Website: www.beurer.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question