

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GE](#) /

> [GE Enbrighten LED Lantern Model 11012 Instruction Manual](#)

GE 11012

GE Enbrighten LED Lantern Model 11012 Instruction Manual

Your guide to setup, operation, and maintenance

INTRODUCTION

The GE Enbrighten LED Lantern Model 11012 is a versatile, battery-operated lighting solution designed for various indoor and outdoor applications. Featuring ultra-bright LED technology, this lantern provides consistent illumination with exceptional energy efficiency. Its durable, weather-resistant design and multi-level dimming capabilities make it suitable for camping, emergencies, patios, and general backyard use.





The GE Enbrighten LED Lantern in red, showcasing its compact design and integrated handle.

SETUP

Battery Installation

1. Ensure the lantern is turned off.

2. Locate the battery compartment cover at the bottom of the lantern.
3. Twist the cover counter-clockwise to unlock and remove it.
4. Insert four (4) D-cell batteries (not included) into the compartment, ensuring correct polarity (+/-) as indicated inside the compartment.
5. Replace the battery compartment cover and twist clockwise to secure it.

Initial Use

After installing batteries, the lantern is ready for use. Press the power button located on the front of the lantern to turn it on.

OPERATING INSTRUCTIONS

Power On/Off and Dimming

The GE Enbrighten LED Lantern features a single power button for controlling illumination and brightness levels:

- **First Press:** Turns the lantern ON to the HIGH brightness setting (approximately 500 lumens).
- **Second Press:** Switches to the MEDIUM brightness setting.
- **Third Press:** Switches to the LOW brightness setting (up to 180 hours of battery life).
- **Fourth Press:** Turns the lantern OFF.

Using the Carabiner Handle

The lantern is equipped with a locking carabiner handle for convenient hanging. To use:

1. Locate the small latch on the side of the handle.
2. Press the latch to open the carabiner mechanism.
3. Hook the handle onto a suitable support (e.g., tent loop, branch).
4. Release the latch to secure the lantern in place.



A close-up view of a hand operating the locking carabiner handle, highlighting its ease of use for hanging.

KEY FEATURES

- **Ultra-Bright LED Technology:** Delivers 500 lumens of omnidirectional light.

- **Long Battery Life:** Up to 180 hours on the low setting with 4 D-cell batteries.
- **3-Level Dimming:** Adjustable brightness settings (Low, Medium, High) to conserve power or provide maximum illumination.
- **Weather-Resistant:** IPX4 rated, protecting against rain and splashing water.
- **Locking Carabiner Handle:** For easy hanging and portability.



The GE Enbrighten LED Lantern providing bright, omnidirectional light in an outdoor setting, demonstrating its use for patios or backyards.

MAINTENANCE

Cleaning

To clean the lantern, wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the lantern in water.

Storage

For long-term storage, remove the D-cell batteries from the lantern to prevent potential leakage and damage. Store the lantern in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

- **Lantern does not turn on:**
 - Check if the batteries are inserted correctly with the proper polarity.
 - Ensure the batteries are fresh and not depleted. Replace if necessary.
- **Light is dim or flickers:**
 - The batteries may be low. Replace all four D-cell batteries with new ones.

SPECIFICATIONS

Specification	Detail
Model Number	11012
Brand	GE
Light Source Type	LED
Color	Red
Power Source	Battery Powered (4 D batteries required)
Item Weight	1.55 Pounds
Water Resistance Level	IPX4 Water Resistant
Special Features	Dimmable (3 levels)
Manufacturer	Jasco
UPC	030878110129

PRODUCT VIDEO

Your browser does not support the video tag.

Official product video demonstrating the features and benefits of the GE Enbrighten LED Lantern, including its LED technology, battery life, and weather resistance.

WARRANTY AND SUPPORT

Warranty Information

This GE Enbrighten LED Lantern is backed by a 5-year limited manufacturer's warranty. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact GE customer support. Refer to the product packaging or the official GE website for the most current contact information.