Samsung EO-HS130DWEGIN

Samsung EO-HS130DWEGIN Wired In-Ear Earphones User Manual

Model: EO-HS130DWEGIN

Introduction

This manual provides instructions for the proper use and care of your Samsung EO-HS130DWEGIN wired in-ear earphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: Samsung EO-HS130DWEGIN earphones showing the earbuds and the in-line remote control.

What's in the Box

Verify that all components are present in the package:

- Samsung EO-HS130DWEGIN Headset (Earphones with Mic)

Setup

1. **Connecting to a Device:** Locate the 3.5mm audio jack on your smartphone, tablet, or other compatible audio device. Insert the 3.5mm connector of the earphones firmly into the device's audio jack.
2. **Wearing the Earphones:** Gently insert the earbuds into your ears. Ensure a comfortable and secure fit for optimal sound quality and to prevent them from falling out. The left earbud is typically marked with an 'L' and the right with an 'R'.



Image: Full view of the Samsung EO-HS130DWEGIN earphones, showing the 3.5mm audio jack and the cable leading to the earbuds.

Operating Instructions

The EO-HS130DWEGIN earphones feature an in-line remote control for easy management of audio playback and calls.



Image: Detailed view of the in-line remote control with volume and multi-function buttons.

- **Multi-function Button (Center Button):**
  - Press once to Play/Pause music.
  - Press once to Answer/End a call.
  - Press twice to skip to the next track.
  - Press three times to go to the previous track.
- **Volume Up Button (+):** Press to increase the volume.
- **Volume Down Button (-):** Press to decrease the volume.
- **Microphone:** The built-in microphone allows for hands-free calling. Ensure the microphone is positioned appropriately for clear voice transmission during calls.

Maintenance

- **Cleaning:** Regularly clean the earbuds and the ear tips with a soft, dry cloth. Do not use liquid cleaners or abrasive materials. Ensure no moisture enters the speaker mesh.
- **Storage:** When not in use, store the earphones in a clean, dry place, preferably in a protective pouch, to prevent tangling and damage to the cable.
- **Cable Care:** Avoid pulling the cable excessively or bending it sharply, especially near the connectors, as this can cause internal damage.



Image: Close-up view of an earbud, highlighting the speaker mesh, which should be kept clean.

Troubleshooting

No Sound or Low Volume:

- Ensure the 3.5mm jack is fully inserted into your device.
- Check the volume level on your device and using the in-line remote.
- Test the earphones with another audio device to rule out a device-specific issue.
- Inspect the cable for any visible damage or kinks.

Poor Sound Quality (Distortion, Static):

- Ensure the audio source is of good quality.
- Clean the earbud speaker meshes as described in the Maintenance section.
- Try adjusting the equalizer settings on your audio device, if available.

Microphone Not Working:

- Ensure the earphones are fully plugged into the device.
- Check your device's settings to confirm the external microphone is selected, if applicable.
- Test the microphone with another application or device.

Specifications

Brand:	Samsung
Model Number:	EO-HS130DWEGIN
Ear Placement:	In Ear
Form Factor:	In Ear
Headphones Jack:	3.5 mm Jack
Microphone:	Included
Control Type:	Volume Control, Multi-function Remote
Cable Length:	1.2 meters
Color:	White
Material:	Plastic
Item Weight:	100 Grams

Warranty and Support

Your Samsung EO-HS130DWEGIN earphones come with a **6 months warranty** from the date of purchase. This warranty covers manufacturing defects under normal use conditions.
For warranty claims, technical support, or further assistance, please contact Samsung customer service or visit the official Samsung support website.
Manufacturer Contact Information:
DLF Centre, Sansad Marg 6th Floor New Delhi, 110001 India
Importer/Packer Contact Information:
SAMSUNG INDIA ELECTRONICS PVT LTD
You can find more information and support resources on the official Samsung website: www.samsung.com

© 2023 Samsung. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question