Casio TQ-750J-7JF

CASIO TQ-750J-7JF Radio Analog Table Clock User Manual

Model: TQ-750J-7JF

Introduction Setup Operation Maintenance Warranty & Support Troubleshooting Specifications

1. Introduction

This manual provides instructions for the CASIO TQ-750J-7JF Radio Analog Table Clock. This compact alarm clock is designed for convenience, featuring radio-controlled time synchronization, an electronic sound alarm, snooze function, and a light for visibility in low-light conditions. The second hand also stops when the alarm is set, ensuring quiet operation.



Image 1.1: Front view of the CASIO TQ-750J-7JF radio analog table clock. The clock features a white square casing with a white analog dial, black numbers, and gray hour and minute hands. A blue second hand is also visible. A gray button is located on the top right of the clock face.



Image 1.2: Three CASIO TQ-750J clocks displayed in white, black, and blue color variations, illustrating the compact design suitable for various settings.

2. Setup

2.1 Battery Installation

1. Locate the battery compartment cover on the back of the clock.
2. Remove the cover by sliding it or gently prying it open.
3. Insert one (1) AA alkaline battery, ensuring the positive (+) and negative (-) terminals are aligned correctly according to the indicators inside the compartment.
4. Replace the battery compartment cover securely.

2.2 Initial Time Setting and Radio Reception

This clock features a radio reception function that automatically synchronizes the time. Upon battery installation, the clock

will attempt to receive a time calibration signal.

- Place the clock in a location where it can easily receive radio signals, ideally near a window and away from electronic devices that may cause interference.
- The clock will automatically adjust to the correct time once a signal is successfully received. This process may take several minutes.
- If automatic reception fails, you may need to manually initiate reception or adjust the time manually (refer to the "Operating Instructions" section for manual time setting).
- The radio wave reception function can be turned ON or OFF. Ensure it is ON for automatic time synchronization.



Image 2.1: Rear view of the CASIO TQ-750J-7JF clock. Visible controls include a switch for ON/OFF, a recessed button for SET/RESET, and the battery compartment cover at the bottom.



Image 2.2: The CASIO Wave Ceptor logo against an Earth background, highlighting the clock's radio-controlled timekeeping technology for precise time synchronization.

3. Operating Instructions

3.1 Setting the Alarm

1. Locate the alarm setting knob on the back of the clock (often a small rotating dial).
2. Rotate the knob to set the desired alarm time.
3. To activate the alarm, slide the alarm switch (usually labeled ON/OFF) to the ON position.
4. When the alarm is set to ON, the second hand will stop moving to ensure quiet operation until the alarm sounds.

3.2 Snooze Function

When the alarm sounds, press the large button on the top of the clock (or the designated snooze button). The alarm will temporarily stop and sound again after a few minutes (typically 5-10 minutes).

3.3 Light Function

To illuminate the clock face in the dark, press the light button (often the same button as the snooze button, or a separate button on the top/side). The light will activate for a short period (with afterglow function) to allow time checking.

3.4 Manual Time Adjustment (if radio reception is unavailable)

In areas without radio signal reception, or if you prefer manual setting:

1. Locate the time setting knob on the back of the clock.
2. Rotate the knob to set the current time.
3. Ensure the radio reception function is set to OFF if you wish to maintain manual time settings without interference from radio signals.

4. Maintenance

4.1 Cleaning

- Wipe the clock with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the casing or dial.

4.2 Battery Replacement

Replace the AA alkaline battery when the clock's functions (e.g., timekeeping, alarm, light) become weak or stop working. Refer to section 2.1 for battery installation instructions. Always dispose of used batteries responsibly according to local regulations.

5. Troubleshooting

Problem	Possible Cause	Solution
Clock does not display correct time or stops.	Low battery; poor radio signal reception; radio reception function is OFF.	Replace the battery. Move the clock to a location with better signal reception (e.g., near a window). Ensure the radio reception function is ON. Manually set the time if necessary.
Alarm does not sound.	Alarm is not set; alarm switch is OFF; low battery.	Set the alarm time correctly. Slide the alarm switch to the ON position. Replace the battery.
Light function is dim or not working.	Low battery.	Replace the battery.
Second hand does not stop when alarm is set.	Alarm switch is not in the ON position.	Ensure the alarm switch is set to ON.

6. Specifications

- **Model:** TQ-750J-7JF

- **Brand:** Casio
- **Display Type:** Analog
- **Power Source:** 1 x AA Alkaline Battery (included)
- **Functions:**
  - Radio reception function (automatic/manual)
  - Radio wave reception ON/OFF function
  - Step second hand
  - Electronic sound alarm
  - Snooze function
  - Light (with afterglow function)
  - Second hand stop function (with alarm setting)
- **Product Dimensions (H x W x D):** Approximately 7.7 cm x 7.5 cm x 4.4 cm (3.0 in x 3.0 in x 1.7 in)
- **Item Weight:** Approximately 135 grams (4.8 ounces)
- **Material:** Resin
- **Color:** White
- **Indoor/Outdoor Usage:** Indoor



Image 6.1: Diagram showing the dimensions of the CASIO TQ-750J-7JF clock: 7.7cm height, 7.5cm width, and 4.4cm depth. The weight is approximately 135g.




Image 6.2: A hand holding the CASIO TQ-750J-7JF clock, demonstrating its compact size. The image also indicates dimensions of 3.1 inches and 7 cm for reference.

7. Warranty and Support

For warranty information, please refer to the documentation included with your purchase. Casio products typically come

with a manufacturer's warranty covering defects in materials and workmanship.
For technical support, service, or inquiries regarding your CASIO TQ-750J-7JF clock, please contact Casio customer service directly or visit their official website for support resources.
Casio Official Website: www.casio.com

© 2023 Casio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question