

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Danby](#) /

› [Danby DAR110A1WDD 11 Cu.Ft. Apartment Refrigerator Instruction Manual](#)

Danby DAR110A1WDD

Danby DAR110A1WDD 11 Cu.Ft. Apartment Refrigerator Instruction Manual

Model: DAR110A1WDD

INTRODUCTION

This instruction manual provides essential information for the safe and efficient operation, installation, and maintenance of your Danby DAR110A1WDD 11 Cu.Ft. Apartment Refrigerator. Please read this manual thoroughly before using the appliance and retain it for future reference.

The Danby DAR110A1WDD is an 11 cubic feet capacity compact refrigerator designed for various living spaces. Key features include automatic defrost, tempered glass shelves, a vegetable crisper, and a reversible door hinge for flexible installation.

SETUP INSTRUCTIONS

1. Unpacking

Remove all packaging materials, including the foam base and adhesive tape. Inspect the refrigerator for any damage. Keep packaging materials out of reach of children.

2. Placement

Place the refrigerator on a flat, solid surface strong enough to support the unit when fully loaded. Ensure adequate air circulation around the unit. Allow at least 5 inches (12.7 cm) of space between the back and sides of the refrigerator and any adjacent walls or cabinets to ensure proper ventilation and efficient operation. Avoid placing the unit in direct sunlight or near heat sources.

3. Leveling

Adjust the leveling legs at the bottom front of the refrigerator to ensure the unit is stable and level. A level refrigerator operates more efficiently and prevents the door from swinging open or closing improperly.

4. Power Connection

Before plugging in the unit, allow it to stand upright for approximately 2-4 hours. This reduces the possibility of a malfunction in the cooling system from handling during transportation. Connect the refrigerator to a dedicated 115V AC, 60 Hz grounded electrical outlet. Do not use extension cords or ungrounded adapters.

5. Reversible Door Hinge

The door hinge is reversible, allowing the door to open from either the left or right side. Refer to the detailed instructions in the full product manual for steps on reversing the door swing, if desired.




Image: The Danby DAR110A1WDD refrigerator with its dimensions clearly indicated: 23.94 inches deep, 26.06 inches wide, and 58.75 inches high.

OPERATING INSTRUCTIONS

1. Temperature Control

The refrigerator is equipped with a mechanical thermostat for temperature adjustment. The control dial is typically located inside the unit. Turn the dial to a higher number for colder temperatures and a lower number for warmer temperatures. It is recommended to start with a medium setting and adjust as needed based on food load and ambient room temperature.

2. Automatic Defrost

This refrigerator features an automatic defrost system, eliminating the need for manual defrosting. Frost will periodically melt and drain into an evaporation tray, where it evaporates naturally.

3. Interior Storage

The unit includes four full-width tempered glass shelves, a vegetable crisper with a cover, and a CanStor beverage dispenser in the door. Arrange items to allow for optimal air circulation. The interior light illuminates the compartment when the door is open.





Image: A front view of the Danby DAR110A1WDD 11 Cu.Ft. Apartment Refrigerator in white, showcasing its compact design.

MAINTENANCE

1. Cleaning the Interior

Unplug the refrigerator before cleaning. Wash the interior surfaces with a solution of warm water and baking soda (2 tablespoons of baking soda to 1 quart of water). Rinse thoroughly and wipe dry. The tempered glass shelves and crisper can be removed for easier cleaning.

2. Cleaning the Exterior

Clean the exterior with a soft cloth dampened with mild soap and water. For the scratch-resistant worktop, use a non-abrasive cleaner. Ensure the door gasket is clean and free of debris to maintain an effective seal.

3. Power Outages

In case of a power outage, keep the refrigerator door closed as much as possible to maintain internal temperature. Avoid opening the door unnecessarily.

TROUBLESHOOTING

- **Refrigerator does not operate:** Check if the power cord is securely plugged into the outlet. Verify the circuit breaker or fuse is not tripped. Ensure the temperature control is not set to 'OFF'.
- **Temperature inside is not cold enough:** Check the temperature control setting and adjust to a colder setting if necessary. Ensure the door is closed properly and not frequently opened. Avoid placing hot food inside. Verify the unit is not in direct sunlight or near a heat source.
- **Excessive noise:** Ensure the refrigerator is level. Check if the unit is touching a wall or other appliance.

Normal operating sounds include the compressor running, refrigerant circulating, and fan operation.

- **Door does not close completely:** Check if the door gasket is clean and free of obstructions. Ensure the refrigerator is level. Verify that food packages or containers are not blocking the door.

For more detailed troubleshooting, please refer to the comprehensive guide in the full product manual or contact Danby customer support.

SPECIFICATIONS

Feature	Specification
Brand	Danby
Model Number	DAR110A1WDD
Capacity	11 Cubic Feet
Dimensions (D x W x H)	26.06 x 23.94 x 58.75 inches
Item Weight	129.7 pounds
Annual Energy Consumption	337 Kilowatt Hours Per Year
Installation Type	Freestanding
Defrost System	Automatic
Number of Doors	1
Door Hinge	Reversible
Shelf Type	Glass Shelves
Crispers/Drawers	1
Special Features	Automatic Defrost, Compact, Scratch Resistant
Certification	Energy Star Compliant

SAFETY WARNINGS



WARNING: This product can expose you to chemicals including lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. For more information go to www.P65Warnings.ca.gov

Image: A warning label indicating that this product can expose you to chemicals including lead, known to cause cancer, birth defects, or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

WARNING: This product can expose you to chemicals including lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. For more information go to www.P65Warnings.ca.gov.

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Danby website. Keep your proof of purchase for warranty claims.

You can also visit the Danby Store on Amazon for more product information: [Danby Store](#)

