

[Manuals.plus](#) /

› [Peg Perego](#) /

› Peg Perego Gaucho Rock'in Ride-On Electric Vehicle User Manual

Peg Perego IGOD0075US

Peg Perego Gaucho Rock'in Ride-On Electric Vehicle User Manual

Model: IGOD0075US

INTRODUCTION

Welcome to the instruction manual for your Peg Perego Gaucho Rock'in Ride-On Electric Vehicle. This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your new vehicle. Please read all instructions carefully before use to ensure a safe and enjoyable experience.



The Peg Perego Gaucho Rock'in Ride-On Electric Vehicle in black, showcasing its robust design and two-seater capacity.

Safety Information

WARNING: To prevent serious injury, adult supervision is required. Never use near motor vehicles, streets, swimming pools, hills, steps, or sloped driveways. Always wear shoes. Never allow more than two riders.

- Always ensure children wear the provided seatbelts.
- Operate only on flat, level surfaces away from hazards.
- Do not allow children to operate the vehicle in wet conditions.
- Regularly inspect the vehicle for damage or loose parts before each use.
- The 5 mph lockout feature should be engaged for beginner drivers.



Two children safely operating the Gaucho Rock'in, highlighting the two-seater design and seatbelts.

SETUP AND INITIAL USE

Battery Charging

The vehicle includes a 12-volt rechargeable battery and recharger. Before first use, the battery must be charged for a minimum of 18 hours, but no more than 30 hours. Subsequent charges should be 12-14 hours. Do not overcharge the battery.

1. Connect the charger to the battery.
2. Plug the charger into a standard wall outlet.
3. Monitor charging time.
4. Disconnect the charger once charging is complete.

Assembly

While the product is largely pre-assembled, some minor components may require attachment. Refer to the detailed assembly diagrams in the separate assembly guide for specific instructions. Ensure all connections are secure before operation.

OPERATING INSTRUCTIONS

Starting the Vehicle

To start the Gaucho Rock'in, ensure the battery is fully charged and properly connected. The vehicle is operated by a foot pedal accelerator.

Speed and Direction Control

The vehicle features a 2-speed shifter with reverse.

- **Low Speed:** Approximately 2.5 mph.
- **High Speed:** Approximately 5 mph.
- **Reverse:** Allows the vehicle to move backward.
- **5 mph Lockout:** For beginners, a parental lockout feature can be engaged to restrict the vehicle to low speed only. Consult the separate assembly guide for instructions on engaging this feature.



The gear shifter for controlling speed and direction.

Steering

The Gaucho Rock'in is equipped with rack and pinion steering for precise control.



The dashboard and steering wheel, showing the controls for the vehicle.

FEATURES OVERVIEW

- **Super Traction Wheels:** Designed for optimal grip on various surfaces including grass, dirt, gravel, and hard surfaces.
- **Rear Suspension:** Provides a smoother ride over uneven terrain.
- **FM Radio with MP3 Jack:** Allows for entertainment during operation.
- **Toolbox with Tools:** A functional toolbox is included for imaginative play.
- **Working Horn:** For added realism and fun.
- **Adjustable Seats with Seatbelts:** Ensures comfort and safety for different sized riders.



Detail of the Super Traction wheels, designed for various terrains.



The functional toolbox with play tools, enhancing the play experience.



The FM radio with MP3 jack, providing entertainment options.

MAINTENANCE

- **Battery Care:** Always recharge the battery after each use. Store the vehicle with a fully charged battery. If storing for extended periods, recharge monthly.
- **Cleaning:** Wipe the vehicle with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws, nuts, and bolts for tightness. Ensure wheels are securely attached and steering components are functioning correctly.
- **Storage:** Store the vehicle in a dry, protected area when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vehicle does not move	Battery not charged; Loose battery connection; Thermal fuse tripped.	Charge battery; Check battery terminals; Allow vehicle to cool down, then restart.
Vehicle runs slowly	Low battery charge; Overloaded vehicle; Operating on soft surfaces.	Recharge battery; Reduce weight; Operate on harder surfaces.
Radio not working	Radio power off; Low radio battery (if separate); Volume too low.	Turn radio on; Check/replace radio batteries; Adjust volume.

SPECIFICATIONS

Model Number: IGOD0075US

Brand: Peg Perego

Age Range: 3 - 8 years (36 - 96 months)

Battery: 12-Volt Rechargeable

Speeds: 2.5 mph, 5 mph, Reverse (with 5 mph parental lockout)

Maximum Weight Capacity: 35 Kilograms (77 lbs)

Item Weight: 29 Kilograms (64 lbs)

Item Dimensions (L x W x H): 51.6 x 35.4 x 39.4 inches

Features: Rack and Pinion Steering, Rear Suspension, Super Traction Wheels, FM Radio with MP3 Jack, Toolbox, Working Horn, Adjustable Seats with Seatbelts.

Assembly Required: No (minor component attachment may be needed)

Made in: Italy

WARRANTY AND SUPPORT

The Peg Perego Gaucho Rock'in Ride-On Electric Vehicle comes with a **2-year limited warranty**. For warranty claims, replacement parts, or technical support, please contact Peg Perego customer service. Keep your proof of purchase for warranty validation.

For more information, visit the official Peg Perego website: www.pegperego.com

PRODUCT VIDEO

Your browser does not support the video tag.

Official product video demonstrating the features and operation of the Peg Perego Gaucho Rock'in.