

**Manuals+**

[Q & A](#) | [Deep Search](#) | [Upload](#)

**Simply SWC200**

# Simply SWC200 Deluxe Lace Up Steering Wheel Cover

User Manual

## INTRODUCTION

---





Image: The Simply SWC200 Deluxe Lace Up Steering Wheel Cover as it appears in its retail packaging, highlighting the product name and key features.

Thank you for choosing the Simply SWC200 Deluxe Lace Up Steering Wheel Cover. This manual provides essential information for the proper installation, use, and maintenance of your new steering wheel cover. Designed for comfort and durability, this cover is suitable for steering wheels measuring 37-39cm in diameter.

#### Key Features:

- Deluxe soft grip material for enhanced comfort.
- Extra thick material for improved feel and durability.
- Designed to fit all standard 37-39cm steering wheels.
- Lace-up design ensures a snug and secure fit, preventing spinning.

## SETUP AND INSTALLATION

---

Proper installation is crucial for the performance and longevity of your steering wheel cover. Please follow these steps carefully:

1. **Prepare the Steering Wheel:** Ensure your steering wheel is clean and dry before installation. Remove any existing covers or debris.
2. **Position the Cover:** Place the Simply SWC200 cover over the top of your steering wheel. The cover is designed to fit snugly, so some effort may be required to stretch it into place.
3. **Align and Secure:** Work the cover down around the entire circumference of the steering wheel,

ensuring it is evenly distributed and aligned.

4. **Begin Lacing:** Locate the pre-drilled holes along the edges of the cover. Using the provided lacing cord and a suitable needle (not always included, but recommended for ease), begin lacing the cover. Start from the inside of the cover and work your way around, pulling the cord taut to create a firm, secure fit. A cross-stitch or baseball stitch pattern is commonly used for a professional finish.
5. **Complete Lacing:** Continue lacing until the entire cover is securely fastened. Ensure there are no loose sections. Tie off the lacing cord neatly and trim any excess. Tuck the knot and excess cord under the cover for a clean appearance.



Image: The Simply SWC200 Deluxe Lace Up Steering Wheel Cover, shown in its circular form, ready for lacing onto a steering wheel. This image illustrates the texture and overall shape of the product.

## OPERATING AND USAGE

Once installed, the Simply SWC200 Deluxe Lace Up Steering Wheel Cover requires no special operation. It is designed to enhance your driving experience by providing:

- **Improved Grip:** The deluxe soft grip material offers a more secure and comfortable hold on the steering wheel.
- **Enhanced Comfort:** The extra thick material provides additional cushioning, reducing hand fatigue

during long drives.

- **Stable Fit:** The lace-up design ensures the cover remains firmly in place, preventing any unwanted spinning or slipping during use.

Always ensure the cover is securely laced and does not interfere with the safe operation of your vehicle's steering or any steering wheel mounted controls.

## MAINTENANCE AND CARE

To ensure the longevity and appearance of your Simply SWC200 Deluxe Lace Up Steering Wheel Cover, follow these maintenance guidelines:

- **Cleaning:** Wipe the cover regularly with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Drying:** Allow the cover to air dry completely after cleaning. Do not expose it to direct sunlight or high heat for prolonged periods.
- **Inspection:** Periodically inspect the lacing for any signs of wear or loosening. Re-tighten or re-lace if necessary to maintain a secure fit.
- **Avoid Sharp Objects:** Prevent contact with sharp objects that could cut or tear the cover material.

## TROUBLESHOOTING

If you encounter any issues with your Simply SWC200 Deluxe Lace Up Steering Wheel Cover, consider the following common problems and solutions:

- **Cover is Loose or Spinning:**  
*Solution:* This typically indicates that the lacing was not pulled taut enough during installation or has loosened over time. Re-tighten the lacing cord, ensuring it is pulled firmly. If necessary, re-lace the cover entirely to achieve a snug fit.
- **Difficulty Installing the Cover:**  
*Solution:* The cover is designed for a tight fit to prevent movement. Ensure your steering wheel diameter is within the 37-39cm range. If it's still difficult, try warming the cover slightly (e.g., by leaving it in a warm room or in the sun for a few minutes) to make the material more pliable before stretching it over the wheel.
- **Material Appears Damaged or Ripped:**  
*Solution:* Inspect the area of damage. Small tears might be repairable with a strong adhesive suitable for the material. For significant damage, the cover may need to be replaced. Ensure care is taken during installation to avoid excessive force that could cause ripping.

## SPECIFICATIONS

Attribute	Detail
Brand	Simply
Model Number	SWC200
Item Weight	3.2 ounces

Package Dimensions	10.55 x 3.86 x 1.1 inches
Item Diameter	37-39 Centimeters (fits)
Color	Black
GTIN (UPC)	05037409053509
First Available	February 24, 2015

## WARRANTY AND SUPPORT

Specific warranty information for the Simply SWC200 Deluxe Lace Up Steering Wheel Cover is not provided within this manual. For details regarding warranty coverage, returns, or technical support, please refer to the original product packaging or visit the official Simply brand website.

For further assistance, you may also contact the retailer from whom you purchased the product.

© 2024 Simply. All rights reserved.



Image: The official Simply brand logo, featuring the brand name alongside a stylized car icon.