Heavy Duty Foldable Step Stool

Heavy Duty Foldable Step Stool User Manual

Introduction

This manual provides essential instructions for the safe and effective use, setup, maintenance, and storage of your Heavy Duty Foldable Step Stool. Please read this manual thoroughly before using the product and retain it for future reference.



Image: The Heavy Duty Foldable Step Stool, ready for use.

Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always ensure the stool is fully unfolded and stable on a flat, level surface before stepping on it.
- Do not exceed the maximum weight limit of**300 pounds (136 kg)**.
- Step onto and off the stool carefully. Avoid sudden movements or jumping.
- Do not stand on the stool's edges. Distribute your weight evenly across the center of the platform.
- Keep children under supervision when near or using the stool.
- Do not use the stool if any part is damaged, cracked, or unstable.
- Ensure anti-slip rubber feet are clean and intact for maximum stability.
- Avoid using the stool on slippery surfaces without proper precautions.

Setup and Unfolding

The step stool comes pre-assembled and requires no tools for setup.

1. Place the folded stool on a flat surface.
2. Grasp both sides of the stool.
3. Gently pull the two halves of the stool apart until the top surface flattens and the side panels/legs extend outward into a solid 4-point support position. You will hear a click when it is fully locked into place.
4. Verify that all four legs are firmly on the ground and the top surface is flat and stable before use.



Image: Unfolding the step stool for use.

Operating Instructions

Once the stool is fully unfolded and stable:

- Step onto the center of the stool's platform.
- Maintain balance and use a secure handhold if available (e.g., a wall or counter).
- When finished, step off the stool carefully.

Folding and Storage

To fold the stool for compact storage:

1. Ensure no one is standing on the stool.
2. Locate the handle opening in the center of the top surface.
3. Insert your fingers into the opening and pull the handle upwards. The stool will collapse inward.
4. Once folded, the stool is approximately 1.75 inches thick, making it easy to store in narrow spaces.
5. Store in a dry place away from direct sunlight and extreme temperatures.



Image: Folding the step stool for storage.

Maintenance and Care

- Clean the stool with a damp cloth and mild soap. Avoid abrasive cleaners.
- Regularly inspect the stool for any signs of wear, cracks, or damage, especially on the hinges and anti-slip feet.
- If any part is damaged, discontinue use immediately.

Troubleshooting

Problem: Stool feels unstable or wobbly.
Solution: Ensure the stool is fully unfolded and locked into position. Check that all four legs are on a flat, level surface. Verify that the anti-slip feet are clean and intact. Do not use on soft surfaces like thick carpeting if stability is compromised.

Problem: Stool makes creaking or cracking sounds when in use.
Solution: Discontinue use immediately. This may indicate structural stress or damage. Inspect the stool for any visible cracks or deformities. Ensure you are not exceeding the 300-pound weight limit and are distributing weight evenly.

Problem: Stool folds unexpectedly when moved.
Solution: The stool is designed to fold when the handle is pulled up. There is no locking mechanism to keep it permanently unfolded when lifted. Always ensure the stool is placed on the ground before stepping on it. When moving, hold it by the handle in its folded state.

Specifications

Feature	Detail
Product Name	Heavy Duty Foldable Step Stool
Maximum Weight Capacity	300 Pounds (136 kg)

Unfolded Height	Approximately 8.5 inches
Folded Height	14 inches (including handle)
Folded Thickness	Approximately 1.75 inches
Item Weight	2.94 pounds (1.33 kg)
Color	White (may appear light gray)
Special Features	Durable, Foldable, Anti-slip rubber feet
Room Type	Bathroom, Bedroom, Kitchen
Assembly Required	No
UPC	062823834064
ASIN	B00ODF2DO4

Warranty and Support

No specific warranty information is provided with this product. For support or inquiries, please refer to the retailer or original point of purchase.

© 2026 All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question