

Manuals.plus /

› Bose /

› Bose WB-50 Series II Slideconnect Bracket - Black Instruction Manual

## Bose WB-50

# Bose WB-50 Series II Slideconnect Bracket - Black

Instruction Manual

## INTRODUCTION

The Bose WB-50 Series II Slideconnect Bracket is designed for unobtrusive wall-mounting of compatible Bose cube speakers. This high-quality steel bracket allows speakers to sit less than 6 mm from the wall, providing a flush and integrated appearance. It incorporates an integral connector to simplify speaker connection, ensuring a clean and professional installation.

This manual provides essential information for the proper installation, operation, and maintenance of your WB-50 Series II Slideconnect Bracket.

## SAFETY INFORMATION


Please read and understand all safety instructions before installing or using this product. Failure to follow these instructions may result in injury or damage.

- Ensure the mounting surface is structurally sound and capable of supporting the combined weight of the bracket and your speaker.
- Use appropriate tools and hardware for your specific wall type (e.g., drywall, wood stud, masonry).
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Do not attempt to modify the bracket or use it for purposes other than its intended design.

## PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Bose WB-50 Series II Slideconnect Bracket
- Mounting Hardware (screws, wall anchors)
- Speaker Connection Adapter (if applicable for your speaker model)



*Image 1: Main view of the Bose WB-50 Series II Slideconnect Bracket, showing its sleek design and mounting holes.*

## SETUP AND INSTALLATION

---

Follow these steps for secure and proper installation of your Bose WB-50 Series II Slideconnect Bracket:

1. **Choose a Location:** Select a suitable wall location for your speaker. Consider optimal listening angles and proximity to power and audio sources.
2. **Mark Drilling Points:** Hold the bracket against the wall at the desired height and use a pencil to mark the locations for the mounting screws. Ensure the bracket is level.
3. **Drill Holes:** Using an appropriate drill bit for your wall type, drill pilot holes at the marked locations. If installing into drywall without a stud, insert the provided wall anchors.
4. **Attach Bracket:** Secure the bracket to the wall using the provided screws. Ensure it is firmly attached and does not wobble.
5. **Connect Speaker Wires:** If your speaker requires a separate connection adapter, attach your speaker wires to the adapter first. Then, connect the adapter or the speaker's integral connector to the bracket's connection point.
6. **Mount Speaker:** Carefully slide your compatible Bose cube speaker onto the bracket. Ensure it clicks securely into place, establishing a firm connection with the integral connector.

**Compatibility:** This bracket is compatible with select Bose cube speakers, including:

- Virtually Invisible 300
- Lifestyle 600
- SoundTouch 520
- Lifestyle 535 and 525
- Acoustimass series V
- CineMate 520
- SoundTouch Stereo JC series II



*Image 2: Close-up view of the bracket's integral connector, designed for seamless speaker attachment and electrical connection.*

## OPERATION

---

Once installed, the Bose WB-50 Series II Slideconnect Bracket securely holds your Bose cube speaker in its wall-mounted position. The bracket's design ensures that the speaker remains flush with the wall while maintaining a reliable audio connection.

No further operational steps are required for the bracket itself after installation. The speaker's functionality will operate as designed by Bose.

## MAINTENANCE

---

The Bose WB-50 Series II Slideconnect Bracket requires minimal maintenance.

- **Cleaning:** To clean the bracket, use a soft, dry cloth. Avoid using abrasive cleaners, solvents, or

harsh chemicals, as these may damage the finish.

- **Inspection:** Periodically check the mounting screws to ensure they remain tight and secure.

## TROUBLESHOOTING

---

If you encounter any issues during or after installation, refer to the following common solutions:

- **Speaker Not Secure:** Ensure all mounting screws are tightened. Verify that the speaker is fully engaged with the bracket's slide mechanism and has clicked into its locked position.
- **No Audio from Speaker:** Check all speaker wire connections at both the bracket's integral connector/adaptor and your audio receiver/amplifier. Ensure the integral connector is properly seated and making full contact.
- **Bracket Wobbles:** Re-tighten all mounting screws. If the issue persists, the wall anchors may not be properly installed or the mounting surface may be insufficient. Consider relocating the bracket or reinforcing the wall.

For persistent issues, consult the support resources provided by Bose.

## SPECIFICATIONS

---

- **Brand:** Bose
- **Model Name:** WB-50
- **Model Number:** 834232-0010
- **Color:** Black
- **Mounting Type:** Wall Mount
- **Material:** Alloy Steel
- **Item Dimensions:** 10.1 x 6.6 x 0.9 inches
- **Item Weight:** 4.96 ounces

## WARRANTY AND SUPPORT

---

For detailed warranty information, product registration, and technical support, please visit the official Bose website or contact Bose customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

**Bose Official Website:** [www.bose.com](http://www.bose.com)