

[Manuals.plus](#) /

› [iProtec](#) /

› NEBO iPROTEC LG Universal Long Gun Mount Instruction Manual

iProtec FBA_6108

NEBO iPROTEC LG Universal Long Gun Mount Instruction Manual

Model: FBA_6108

1. INTRODUCTION

The NEBO iPROTEC LG Universal Long Gun Mount is designed to securely attach accessories such as flashlights or lasers to long guns. Constructed from anodized aircraft-grade aluminum, this mount is built for durability, water resistance, and impact resistance. Its tool-free design allows for quick and easy installation and removal, accommodating a wide range of barrel and scope diameters.




Image 1.1: Overview of the NEBO iPROTEC LG Universal Long Gun Mount.

2. SETUP AND INSTALLATION

Follow these steps to properly install the iPROTEC LG Universal Long Gun Mount and attach your desired accessory.

2.1 Attaching the Mount to Your Long Gun

1. **Identify Mounting Location:** Choose a suitable location on your long gun's barrel or scope. The mount accommodates diameters from 20mm to 32.5mm.
2. **Open the Clamp:** Locate the quick-release lever on the mount. Pull the lever to the 'UNLOCKED' position to open the clamp jaws. The mount features protective rubber inserts inside the jaws to prevent scratching and ensure a secure grip.



Image 2.1: The quick-release lever showing 'LOCKED' and 'UNLOCKED' positions.

3. **Position the Mount:** Place the open jaws of the mount around the desired section of your long gun. Ensure the rubber inserts are properly seated against the surface.



Image 2.2: View of the mount's jaws with protective rubber inserts.

4. **Close and Secure:** Push the quick-release lever to the 'LOCKED' position. The mount is designed for tool-free installation, providing a firm grip. Adjust the tension by rotating the screw if necessary, but avoid over-tightening.

2.2 Attaching an Accessory to the Mount

The iPROTEC LG mount includes an accessory rail system for additional attachments.

1. **Identify Accessory Rail:** Locate the accessory rail (18mm x 24mm) on the bottom of the mount.



Image 2.3: The accessory rail system located on the mount.

2. **Attach Accessory:** Slide your compatible accessory onto the rail. Ensure it is fully seated and secured according to the accessory's instructions.

3. OPERATION

Once installed, the iPROTEC LG Universal Long Gun Mount provides a stable platform for your accessories. The quick-release lever allows for rapid attachment and detachment of the entire mount from your long gun, facilitating easy adjustments or removal when not in use. Ensure the lever is always fully engaged in the 'LOCKED' position during use to maintain accessory stability.

4. MAINTENANCE

To ensure the longevity and optimal performance of your iPROTEC LG Universal Long Gun Mount, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the mount with a soft, damp cloth to remove dirt and debris. Avoid harsh chemicals or abrasive

- materials that could damage the anodized finish.
- **Inspection:** Periodically inspect the mount for any signs of wear, damage, or loose components. Check the integrity of the rubber inserts.
 - **Storage:** Store the mount in a clean, dry environment when not in use.

5. TROUBLESHOOTING

- Issue: Mount feels loose or shifts slightly after installation.**
Solution: Ensure the quick-release lever is fully pushed into the 'LOCKED' position. The internal rubber inserts are designed to provide a secure, non-slip grip, which may allow for a minimal amount of flex. If the mount is excessively loose, gently tighten the central screw to increase clamping force, then re-engage the lever. Avoid over-tightening the screw, as this can strip threads or damage components.
- Issue: Difficulty attaching the mount to a specific barrel or scope.**
Solution: Verify that the diameter of your long gun's barrel or scope falls within the mount's specified range of 20mm to 32.5mm. If it is outside this range, the mount may not fit securely or at all.

6. SPECIFICATIONS

Feature	Detail
Model Name	Universal Clamp, Long Gun Mount
Part Number	FBA_6108
Material	Anodized Aircraft-Grade Aluminum
Color	Black
Item Weight	0.32 Pounds
Item Dimensions (LxWxH)	4 x 1 x 1 inches
Accommodates Diameters	20mm to 32.5mm (Barrel/Scope)
Accessory Rail System	18mm x 24mm
Key Features	Water and impact-resistant, Protective rubber inserts, No tools required

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The NEBO iPROTEC LG Universal Long Gun Mount is covered by a **1-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, warranty claims, or product inquiries, please contact NEBO customer support through their official website or the retailer where the product was purchased. Provide your product model number (FBA_6108) and a detailed description of your issue to expedite service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question