

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Nature Home Decor](#) /
- › [Nature Home Decor White Onyx Lotion Dispenser User Manual](#)

Nature Home Decor 304WO

Nature Home Decor White Onyx Lotion Dispenser User Manual

Model: 304WO

INTRODUCTION

Thank you for choosing the Nature Home Decor White Onyx Lotion Dispenser. This elegant and functional dispenser is crafted from natural white onyx, offering a unique aesthetic to your bathroom or kitchen. Each piece is handcrafted and polished, ensuring a distinctive appearance due to the natural variations inherent in onyx. This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your new lotion dispenser.

PRODUCT OVERVIEW





Figure 1: The Nature Home Decor White Onyx Lotion Dispenser, showcasing its natural white onyx body and stainless steel pump mechanism.

The Nature Home Decor White Onyx Lotion Dispenser is designed for dispensing liquid soaps, lotions, or hand sanitizers. It features a robust body crafted from natural white onyx and is equipped with a high-quality, tarnish-resistant stainless steel pump. An internal removable plastic bottle facilitates easy filling and cleaning.








Figure 2: An angled view of the dispenser, illustrating the unique veining and color variations inherent in natural white onyx. Each dispenser is distinct due to these natural characteristics.

Due to the inherent properties of natural onyx, each dispenser possesses unique patterns and color nuances. These natural variations are a characteristic of the material and contribute to the individuality of your product.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Inspect the dispenser for any visible damage.
2. **Disassemble:** Unscrew the stainless steel pump head from the onyx body. Gently pull out the inner plastic bottle.
3. **Fill:** Fill the inner plastic bottle with your desired liquid soap, lotion, or hand sanitizer. Do not overfill; leave some space at the top to accommodate the pump mechanism.
4. **Reassemble:** Carefully insert the filled plastic bottle back into the onyx body. Screw the stainless steel pump head back onto the onyx body until secure, but do not overtighten.
5. **Prime:** Press the pump head several times until the liquid begins to dispense. This may take a few presses to draw the liquid up the tube.

OPERATING INSTRUCTIONS

Using your Nature Home Decor Lotion Dispenser is straightforward:

- Place the dispenser on a flat, stable surface.
- Position your hand directly under the nozzle.
- Gently press down on the pump head to dispense the desired amount of liquid.
- Release the pump head to allow it to return to its original position.

MAINTENANCE AND CARE

Proper care will ensure the longevity and beauty of your onyx dispenser:

- **Cleaning the Onyx Body:** Wipe the exterior of the onyx body with a soft, damp cloth. For deeper cleaning, use a mild, pH-neutral soap diluted in water. Avoid abrasive cleaners, harsh chemicals, or acidic substances (like vinegar or lemon juice) as these can damage the natural stone. Rinse thoroughly with clean water and dry immediately with a soft cloth to prevent water spots.
- **Cleaning the Pump:** The stainless steel pump can be cleaned with a soft cloth and mild soap. If the pump becomes clogged, remove it and rinse it under warm running water. You may need to pump warm water through it to clear any blockages.
- **Refilling:** When refilling, it is recommended to rinse the inner plastic bottle with water to prevent residue buildup.
- **Avoid Drops:** While durable, onyx is a natural stone and can chip or break if dropped on a hard surface. Handle with care.
- **Natural Variations:** Remember that onyx is a natural material. Over time, slight changes in appearance may occur, which are part of the stone's natural aging process and not a defect.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pump not dispensing liquid.	<ul style="list-style-type: none"> • Not primed. • Liquid too thick. • Pump nozzle clogged. • Inner bottle empty. 	<ul style="list-style-type: none"> • Press pump head repeatedly to prime. • Dilute liquid with a small amount of water if safe for the product. • Remove pump and rinse nozzle under warm water. • Refill the inner plastic bottle.
Pump sticks or is difficult to press.	<ul style="list-style-type: none"> • Residue buildup around pump mechanism. • Liquid has dried in the pump. 	<ul style="list-style-type: none"> • Remove pump and clean thoroughly with warm water and mild soap. • Soak the pump mechanism in warm water for 15-30 minutes, then rinse.
Leakage from pump base.	<ul style="list-style-type: none"> • Pump not screwed on tightly. • Overfilled bottle. 	<ul style="list-style-type: none"> • Ensure pump head is securely screwed onto the onyx body. • Reduce the amount of liquid in the inner bottle.

SPECIFICATIONS

Model Number	304WO
Brand	Nature Home Decor
Material	White Onyx (Natural Stone), Stainless Steel Pump, Plastic Inner Bottle
Color	Marble (referring to the natural variations of white onyx)
Product Dimensions	Approximately 9 x 3 x 3 inches (Height x Width x Depth)
Item Weight	Approximately 3 pounds
UPC	641061241683

WARRANTY AND SUPPORT

Information regarding specific warranty terms for the Nature Home Decor White Onyx Lotion Dispenser is not provided in this manual. For any inquiries regarding warranty, product support, or replacement parts, please contact the manufacturer or your point of purchase directly.

You may find contact information for Nature Home Decor on their official website or through the retailer where you purchased this product.