

[Manuals.plus](#) /

- › [Bowers & Wilkins](#) /
- › Bowers & Wilkins T7 Portable Bluetooth Speaker User Manual

Bowers & Wilkins T7

Bowers & Wilkins T7 Portable Bluetooth Speaker User Manual

Model: T7

INTRODUCTION

Thank you for choosing the Bowers & Wilkins T7 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read these instructions carefully before use.



Image: Front view of the Bowers & Wilkins T7 Portable Bluetooth Speaker, showcasing its compact design and speaker grille.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Bowers & Wilkins T7 Portable Bluetooth Speaker
- Power Supply Unit with regional adapters
- Quick Start Guide (not included in this digital manual)
- Safety and Warranty Information (refer to separate documentation)

SETUP

1. Charging the Battery

Before first use, fully charge the T7 speaker. Connect the provided power supply unit to the speaker's power input port and then to a wall outlet. The battery indicator light will show charging status.

- A full charge typically takes approximately 4 hours.
- The battery provides up to 18 hours of playback depending on volume and content.




Image: Rear view of the T7 speaker, showing the power input, AUX input, and service port.

2. Powering On/Off

- To power on, press and hold the **Power** button located on the rear panel until the indicator light illuminates.
- To power off, press and hold the **Power** button again until the indicator light turns off.

3. Bluetooth Pairing

The T7 uses Bluetooth for wireless audio streaming. To pair with a new device:

1. Ensure the T7 is powered on.
2. Press and hold the **Bluetooth** button (usually indicated by a Bluetooth symbol) on the top panel until the Bluetooth indicator light flashes blue rapidly. This indicates pairing mode.
3. On your audio device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Bowers & Wilkins T7" from the list of found devices.
5. Once paired, the Bluetooth indicator light on the T7 will glow solid blue.



Image: Top view of the T7 speaker, showing the control buttons for Bluetooth, Play/Pause, Volume Down, and Volume Up.

4. Auxiliary Connection

For devices without Bluetooth, use the 3.5mm auxiliary input:

- Connect one end of a 3.5mm audio cable (not included) to your audio device's headphone jack.
- Connect the other end to the **AUX** input port on the rear of the T7 speaker.
- The T7 will automatically switch to auxiliary input when a cable is detected.

OPERATING YOUR T7 SPEAKER

Controls

The T7 features intuitive controls on its top panel:

- **Bluetooth Button** (*Bluetooth symbol*): Initiates Bluetooth pairing mode.
- **Play/Pause Button** (*Play/Pause symbol*): Press to play or pause audio playback.
- **Volume Down Button** (*Minus symbol*): Decreases the volume.
- **Volume Up Button** (*Plus symbol*): Increases the volume.

Bluetooth Connection Management

The T7 can remember multiple paired devices. To switch between previously paired devices, ensure Bluetooth is enabled on the desired device and select the T7 from its Bluetooth settings. The T7 will automatically connect to the last connected device if available.

Battery Status Indicator

The LED indicator light provides information about the battery status:

- **Solid Green:** Fully charged.
- **Pulsing Amber:** Charging.
- **Solid Amber:** Battery level is low.
- **Solid Red:** Battery is critically low and requires charging.

MAINTENANCE

Cleaning

To clean your T7 speaker:

- Wipe the surfaces with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, benzene, or other chemical solvents, as these may damage

the finish.

- Avoid getting moisture into any openings.

Storage

When storing the T7 for extended periods, ensure it is fully charged and stored in a cool, dry place. Periodically recharge the battery to maintain its health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery depleted; Power cable not connected.	Charge the speaker; Ensure power cable is securely connected to both the speaker and a working outlet.
No sound	Volume too low; Incorrect input selected; Device not paired/connected.	Increase volume on both T7 and source device; Ensure Bluetooth is connected or AUX cable is properly inserted; Re-pair Bluetooth device.
Bluetooth pairing fails	T7 not in pairing mode; Device too far; Interference.	Press and hold Bluetooth button until light flashes rapidly; Move device closer to T7; Turn off other Bluetooth devices nearby.
Poor sound quality via Bluetooth	Device too far; Obstructions; Low battery.	Move device closer to T7; Ensure no large obstructions between devices; Charge the T7.
Speaker unresponsive	Software glitch.	Perform a reset: Locate the small RESET pinhole on the rear panel (next to the service port). Use a paperclip to gently press and hold the reset button for a few seconds. The speaker will power off and restart.

SPECIFICATIONS

- **Model:** T7
- **Product Dimensions:** 4.6 x 9.5 x 5.6 inches (11.7 x 24.1 x 14.2 cm)
- **Item Weight:** 2.07 pounds (0.94 kg)
- **Connectivity:** Bluetooth, 3.5mm Auxiliary Input
- **Battery Type:** 1 Lithium Polymer battery (included)
- **Battery Life:** Up to 18 hours (varies with volume and content)
- **Manufacturer:** Bowers & Wilkins
- **ASIN:** B00OLE9606
- **First Available:** October 20, 2014




Image: Internal view of the T7 speaker, showing the dual drivers and passive bass radiators.

WARRANTY INFORMATION

The Bowers & Wilkins T7 Portable Bluetooth Speaker is covered by a manufacturer's warranty. Please refer to the separate warranty document included with your product or visit the official Bowers & Wilkins website for detailed terms and conditions.

CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or service inquiries, please contact Bowers & Wilkins customer support. Contact information can be found on the official Bowers & Wilkins website or in your product's documentation.

Official Bowers & Wilkins Website: www.bowerswilkins.com