

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Mediatech](#) /

› [Media-Tech MT3325 2.1 21W PC Speaker System User Manual](#)

Mediatech MT3325

Media-Tech MT3325 2.1 21W PC Speaker System User Manual

Model: MT3325

INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Media-Tech MT3325 2.1 21W PC Speaker System. Please read this manual thoroughly before using the product to ensure optimal performance and safety.

SAFETY INFORMATION

- Do not expose the speakers to water or moisture.
- Avoid placing the speakers near heat sources or in direct sunlight.
- Ensure proper ventilation around the subwoofer to prevent overheating.
- Use only the power adapter supplied with the device.
- Keep out of reach of children.
- Do not attempt to open or repair the unit yourself. Refer all servicing to qualified personnel.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Subwoofer
- 2 x Satellite Speakers
- 1 x Wired Control Pod
- 1 x USB Power Cable
- 1 x Audio Input Cable (3.5mm jack)
- 1 x User Manual (this document)



This image displays the complete Media-Tech MT3325 2.1 speaker system. On the left is the subwoofer, a cubic unit with a large silver speaker cone. To its right are two tall, slender satellite speakers, each featuring a smaller silver speaker cone. In the foreground, a small, conical wired control pod with audio input/output jacks is visible.

SETUP INSTRUCTIONS

- 1. Positioning Speakers:** Place the subwoofer on the floor or a sturdy surface, ensuring adequate space for ventilation. Position the satellite speakers on either side of your monitor or listening area for optimal stereo separation.
- 2. Connect Satellite Speakers:** Connect the cables from the two satellite speakers to the corresponding output ports on the back of the subwoofer. Ensure a secure connection.
- 3. Connect Control Pod:** Plug the wired control pod into its dedicated port on the subwoofer.
- 4. Connect to Audio Source:** Use the provided 3.5mm audio cable to connect the control pod's input jack to the audio output (headphone jack) of your PC, laptop, or other audio device.
- 5. Power Connection:** Connect the USB power cable from the subwoofer to an available USB port on your PC or a USB power adapter (not included).

OPERATING INSTRUCTIONS

- 1. Power On/Off:** Once connected, the system should power on automatically when the USB power is supplied. Some models may have a power button on the control pod or subwoofer.
- 2. Volume Control:** Adjust the master volume using the rotary knob on the wired control pod. Turn clockwise to increase volume, counter-clockwise to decrease.

3. **Audio Playback:** Start playing audio from your connected device. Ensure the device's volume is also adjusted appropriately.
4. **Headphone Output:** The control pod may feature a headphone jack for private listening. Plugging in headphones will typically mute the speakers.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use liquid cleaners or abrasive materials.
- **Storage:** If storing the speakers for an extended period, disconnect them from power and store them in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Management:** Ensure cables are not tangled or pinched to prevent damage.

TROUBLESHOOTING

Problem	Possible Solution
No sound from speakers.	<ul style="list-style-type: none">• Ensure the USB power cable is securely connected and receiving power.• Check if the 3.5mm audio cable is properly connected to both the control pod and your audio source.• Verify that the volume knob on the control pod is turned up.• Check the volume settings on your connected PC or audio device.• Ensure headphones are not plugged into the control pod.
Distorted or poor sound quality.	<ul style="list-style-type: none">• Lower the volume on both the speakers and your audio source.• Check for loose cable connections.• Ensure the audio source is playing high-quality audio.
Only one satellite speaker produces sound.	<ul style="list-style-type: none">• Check the connection of the non-working satellite speaker to the subwoofer.• Test with another audio source to rule out a source issue.

SPECIFICATIONS

- **Model Name:** MT3325 2.1 21W
- **Manufacturer:** Media-Tech
- **Total Electrical Power:** 21 Watts
- **Maximum Speaker Output Power:** 6 Watts (This typically refers to the RMS power of the satellite speakers, with the subwoofer contributing to the total 21W.)
- **Connectivity Technology:** USB (for power), 3.5mm Audio Jack (for signal)
- **Speaker Type:** Desktop, 2.1 System
- **Compatible Devices:** Personal Computer
- **Control Method:** Touch (This specification likely refers to the overall user interface of the control pod, which includes a rotary knob for volume.)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided at the time of purchase or visit the official Mediatech website. Keep your proof of purchase for warranty claims.

