

[Manuals.plus](#) /

› [Norpro](#) /

› Norpro Potato Cookier Microwaveable Upright Stand User Manual

Norpro Potato Cookier Microwaveable Upright Stand

Norpro Potato Cookier Microwaveable Upright Stand User Manual

MODEL: POTATO COOKIER MICROWAVEABLE UPRIGHT STAND (ASIN: B000O0D5YU)

Introduction

The Norpro Potato Cookier Microwaveable Upright Stand is designed to facilitate quick and even cooking of potatoes in a microwave oven. This set of four individual stands allows you to prepare multiple potatoes simultaneously, ensuring a perfectly baked result in minutes.

Safety Information

- **Microwave Use Only:** These potato cookers are designed exclusively for microwave oven use. *Do not use them in conventional ovens, toaster ovens, or on stovetops, as the plastic material will melt.*
- **Handle with Care:** Cooked potatoes and the stands will be hot after microwaving. Use oven mitts or appropriate heat protection when removing them from the microwave.
- **Piercing Potatoes:** The prongs are sharp. Exercise caution when piercing potatoes to avoid injury. Keep out of reach of children.
- **Cleaning:** Hand wash only. Do not use abrasive cleaners or scourers that could damage the plastic.

Package Contents

- 4 x Norpro Potato Cookier Microwaveable Upright Stands

Setup

Before first use, wash the potato cookers thoroughly with warm, soapy water and rinse well. Allow them to air dry completely.

Operating Instructions

1. **Prepare the Potato:** Select a potato, such as a large russet. Wash and scrub the potato clean.
2. **Pierce the Potato:** Using the prongs of one Norpro Potato Cookier stand, carefully pierce the potato all over. Ensure multiple punctures are made to allow steam to escape during cooking.
3. **Position the Potato:** Stand the pierced potato upright on the prongs of the potato cookier. The prongs should securely hold the potato in an upright position.
4. **Microwave:** Place the potato and stand inside your microwave oven. For large russet potatoes, microwave for approximately 5-10 minutes. Cooking times may vary depending on the size of the potato and the wattage of your microwave.
5. **Check for Doneness:** Carefully remove the potato from the microwave using oven mitts. Test for doneness by squeezing the potato or inserting a fork. If not fully cooked, return to the microwave for additional time.
6. **Serve:** Once cooked, carefully remove the potato from the stand. The potato is now ready to be served with your desired toppings.



Image: A russet potato positioned upright on the Norpro Potato Cookier stand, ready for microwaving.



Image: The Norpro Potato Cooker in use, demonstrating how it holds a potato upright, alongside a finished baked potato.



Image: A detailed view of one Norpro Potato Cooker stand, highlighting its design and prongs.

Maintenance and Care

- **Cleaning:** After each use, hand wash the potato cookers with warm, soapy water. Rinse thoroughly to remove all food residue.
- **Drying:** Allow the cookers to air dry completely before storing.
- **Storage:** Store the potato cookers in a clean, dry place away from direct heat sources.
- **Avoid Harsh Cleaners:** Do not use abrasive sponges, steel wool, or harsh chemical cleaners, as these can scratch or damage the plastic.

Troubleshooting

Problem	Possible Cause	Solution
Potato not cooking evenly	Insufficient piercing; potato too large; microwave wattage too low.	Ensure the potato is pierced thoroughly all over. Adjust cooking time based on potato size and microwave power. Consider rotating the potato halfway through cooking.

Problem	Possible Cause	Solution
Potato still hard after recommended time	Under-cooking.	Increase microwave cooking time in 1-2 minute increments until desired tenderness is achieved.
Plastic stand melting/deforming	Used in conventional oven or on stovetop.	These stands are for microwave use only. <i>Do not use in conventional ovens, toaster ovens, or on stovetops.</i> Replace damaged stands.

Specifications

- **Product Name:** Norpro Potato Cookier Microwaveable Upright Stand
- **Model:** Potato Cookier Microwaveable Upright Stand
- **ASIN:** B00OO0D5YU
- **Material:** Food-grade plastic (*Note: Not for conventional oven use*)
- **Dimensions (Each Stand):** Approximately 2 1/4" L x 1 1/4" W x 1" H
- **Quantity:** Set of 4
- **Care:** Hand wash only

Warranty and Support

For product support or inquiries, please contact the manufacturer, Norpro, or the retailer from whom the product was purchased. Please refer to your purchase receipt for specific warranty details, if applicable.