

[Manuals.plus](#) /

› [Artemide](#) /

› Artemide Eclisse Table Lamp Instruction Manual - Model 0028030A

Artemide 0028030A

Artemide Eclisse Table Lamp Instruction Manual

Model: 0028030A | Brand: Artemide

1. INTRODUCTION

Thank you for choosing the Artemide Eclisse Table Lamp. This manual provides essential information for the safe and efficient use of your lamp. Please read these instructions carefully before installation and operation, and retain them for future reference.



2. SAFETY INSTRUCTIONS

- Ensure the power supply is disconnected before installation, cleaning, or bulb replacement.
- This lamp is designed for indoor use only (IP20 rating). Do not expose to moisture or extreme temperatures.
- Use only E14 base bulbs with a maximum wattage of 18W. Exceeding this limit may cause overheating and damage.
- Do not attempt to modify the lamp's electrical components. Refer all servicing to qualified personnel.
- Keep the lamp away from flammable materials.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged upon unpacking:

- Artemide Eclisse Table Lamp (main unit)
- Instruction Manual (this document)

Note: The light source (bulb) is not included and must be purchased separately. Refer to the Specifications section for compatible bulb types.

4. SETUP

4.1 Bulb Installation

1. Ensure the lamp is unplugged from the power outlet.
2. Gently rotate the inner white sphere to expose the E14 bulb socket.
3. Carefully screw an E14 base bulb (max 18W) into the socket until it is secure. Do not overtighten.
4. Rotate the inner sphere back to its desired position.



Figure 2: The Eclisse lamp with the inner sphere rotated to reveal the E14 bulb socket for installation.

4.2 Placement

Place the lamp on a stable, flat surface. Ensure the power cord is not pinched or obstructed. Connect the power plug to a suitable 120V electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

The Artemide Eclisse lamp features a touch-sensitive switch. To turn the lamp on or off, gently touch the designated area on the lamp's base or body. (Specific touch area may vary slightly by production batch; typically located on the base.)

5.2 Adjusting Light Intensity (Dimming)

The unique design of the Eclisse lamp allows for mechanical adjustment of light intensity. To dim the light or create a focused beam, gently rotate the inner white sphere. This sphere moves within the outer shell, progressively covering the light source and reducing the emitted light.



Figure 3: The Eclisse lamp with the inner sphere partially rotated, demonstrating how to adjust light output.





Figure 4: The Eclipse lamp with the inner sphere fully rotated, effectively blocking the light source.

6. MAINTENANCE

6.1 Cleaning

To clean the lamp, ensure it is unplugged and cool. Use a soft, dry cloth to wipe the metal surfaces. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.

6.2 Bulb Replacement

When the bulb needs replacement, follow the steps outlined in Section 4.1 "Bulb Installation". Always ensure the lamp is unplugged and the old bulb has cooled down before handling.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, faulty bulb, loose connection.	Check power outlet. Ensure lamp is plugged in. Replace bulb. Verify bulb is screwed in correctly.
Light flickers.	Loose bulb, incompatible bulb, unstable power.	Tighten bulb. Ensure bulb meets specifications (E14, max 18W). Try a different power outlet.
Inner sphere is stiff to rotate.	Minor friction, dust accumulation.	Gently rotate it a few times. Clean any visible dust around the rotating mechanism with a soft, dry cloth. Do not apply lubricants.

8. SPECIFICATIONS

Brand: Artemide
Model: Eclipse
Model Number: 0028030A
Dimensions: 12 cm (Diameter) x 18 cm (Height)
Weight: 1.27 kg
Material: Metal
Color: Red
Bulb Socket: E14
Max Wattage: 18W
Voltage: 120 Volt
IP Rating: IP20 (Indoor use only)
Switch Type: Touch
Dimmable: Yes (Mechanical rotation of inner sphere)



Figure 5: Dimensions of the Artemide Eclisse Table Lamp.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact Artemide customer service directly. Keep your purchase receipt as proof of purchase.

For recycling information regarding this product and other types of lamps, please consult local regulations and recycling facilities.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question