

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Pure Enrichment](#) /
- › [Pure Enrichment PureSteam Portable Fabric Steamer - Model PEMINISTM Instruction Manual](#)

Pure Enrichment PEMINISTM

Pure Enrichment PureSteam Portable Fabric Steamer

Model: PEMINISTM

INTRODUCTION

The Pure Enrichment PureSteam Portable Fabric Steamer is designed for efficient wrinkle removal and fabric refreshing. Its compact and lightweight design makes it suitable for both home use and travel.

This manual provides essential information for safe and effective operation, maintenance, and troubleshooting.



Image: The Pure Enrichment PureSteam Portable Fabric Steamer, a white handheld device with a blue water tank window, shown from the front angle.

IMPORTANT SAFETY INFORMATION

Please read all instructions before using this appliance to reduce the risk of fire, electric shock, or injury.

- Always use distilled water to prevent mineral buildup and extend the life of the steamer.
- Do not overfill the water tank.
- Keep the steamer upright during operation to prevent hot water from spitting.
- Avoid direct contact with the steam nozzle as steam is hot and can cause burns.
- The steamer features an automatic shut-off function if it overheats or runs low on water.
- Always unplug the steamer when filling with water, emptying, or when not in use.
- Keep out of reach of children and pets.

PACKAGE CONTENTS

Verify that all items are included in your package:

- Pure Enrichment PureSteam Portable Fabric Steamer
- 8 ft. long power cord (integrated)
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your PureSteam Portable Fabric Steamer:



Image: A detailed diagram of the steamer highlighting its key components: Nozzle, Safety Lock, 130 mL Easy-Fill Water Tank, Easy Power Button, Ergonomic Handle, and Long-Reach Cord.

1. **Nozzle:** Distributes steam evenly.
2. **Nozzle Safety Lock:** Secures the nozzle in place.
3. **130 mL Easy-Fill Water Tank:** Transparent tank for water, with a maximum fill line.
4. **Easy Power Button:** One-touch control for turning the steamer on/off.
5. **Ergonomic Handle:** Provides a comfortable grip during use.
6. **Long-Reach Cord:** 8-foot cord for flexible use.

SETUP

Follow these steps to prepare your steamer for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Water Tank:** Twist off the nozzle head to access the water tank. Fill the 130 mL tank with distilled water up to the MAX line. Do not overfill.
3. **Reattach Nozzle:** Securely twist the nozzle head back onto the steamer, ensuring the safety lock is engaged.
4. **Position:** Place the steamer on a flat, heat-resistant surface or hold it upright.

Video: Pure Enrichment Portable Steamer Setup and Use

Your browser does not support the video tag.

Video Description: This video demonstrates the process of filling the water tank, attaching the nozzle, and turning on the Pure Enrichment PureSteam Portable Fabric Steamer. It shows the steamer being used on a garment to remove wrinkles.

OPERATING INSTRUCTIONS

To begin steaming your garments:

1. **Power On:** Plug the steamer into a standard electrical outlet. Press the Easy Power Button to turn the unit on. The indicator light will illuminate.
2. **Heat Up:** Allow approximately 2 minutes for the steamer to heat up and produce continuous steam.
3. **Prepare Garment:** Hang your garment on a clean, sturdy hanger. Gently pull the fabric taut with your free hand.
4. **Steam:** Hold the steamer upright and move the nozzle slowly over the fabric in a vertical motion, from top to bottom. Maintain a slight distance between the nozzle and the fabric, especially for delicate materials.
5. **Continuous Steaming:** The 130 mL water tank provides up to 10 minutes of continuous steaming.
6. **Power Off:** Once finished, press the Easy Power Button to turn off the steamer and unplug it from the outlet.

Video: Effective and Lightweight Steaming Demonstration

Your browser does not support the video tag.

Video Description: This video showcases the Pure Enrichment PureSteam Portable Fabric Steamer in action, demonstrating its effectiveness and lightweight design while removing wrinkles from clothing.

FABRIC GUIDELINES

The PureSteam Portable Fabric Steamer is safe for use on a wide range of fabrics. Always test on an inconspicuous area first.

Loved by the Press



Image: A collage showing swatches of linen, cotton, silk, and denim, illustrating the steamer's versatility across different fabric types.

- **Suitable Fabrics:** Cotton, linen, silk, denim, wool, synthetics, and most delicate fabrics.
- **Not Recommended:** Leather, suede, plastic, or vinyl.
- For delicate fabrics like silk, hold the steamer slightly further away to avoid direct contact.

MAINTENANCE

Proper care ensures the longevity of your steamer:

1. **Empty Water Tank:** After each use, ensure the steamer is unplugged and cooled. Twist off the nozzle head and empty any remaining water from the tank.
2. **Clean Exterior:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners.
3. **Storage:** Store the steamer in a cool, dry place. Ensure the water tank is completely dry before storing to prevent mildew.

TROUBLESHOOTING

If you encounter issues with your steamer, refer to the following common problems and solutions:

- **No Steam:** Ensure the unit is plugged in, powered on, and the water tank is filled above the minimum level. Allow sufficient time (approx. 2 minutes) for heating.
- **Water Spitting:** This can occur if the steamer is tilted too much or if tap water is used, leading to mineral buildup. Always keep the steamer upright and use distilled water.
- **Steamer Not Heating:** Check if the power button is on and the unit is properly plugged in. The auto

shut-off feature may have activated if the water level is too low or if it overheated. Refill the tank or allow it to cool down.

SPECIFICATIONS

- **Model Number:** PEMINISTM
- **Brand:** Pure Enrichment
- **Product Dimensions:** 6"L x 3"W x 8.5"H
- **Item Weight:** 1.1 Pounds
- **Wattage:** 940 watts
- **Voltage:** 100 Volts
- **Heat Time:** 2 Minutes
- **Water Tank Capacity:** 130 Milliliters
- **Power Cord Length:** 8 ft.
- **Certifications:** ETL-certified



Image: The Pure Enrichment PureSteam Portable Fabric Steamer with its dimensions (length, width, height, and cord length) clearly indicated.

WARRANTY AND CUSTOMER SUPPORT

Your Pure Enrichment PureSteam Portable Fabric Steamer comes with an industry-leading 5-Year Manufacturer's Warranty.

For any questions, concerns, or support needs, please contact Pure Enrichment customer support. They are available 7 days a week to assist you.

Refer to the product packaging or the official Pure Enrichment website for the most current contact information.