Intex 57190EP

INTEX Swim Center Inflatable Family Lounge Pool Instruction Manual

Model: 57190EP | Brand: Intex

Introduction

This manual provides essential information for the safe and efficient use of your INTEX Swim Center Inflatable Family Lounge Pool. Please read all instructions carefully before setup and operation. Retain this manual for future reference.



Image: The Intex Swim Center Inflatable Family Lounge Pool, showcasing its oval shape, blue and white design, and built-in bench with backrest.

Important Safety Information

WARNING: To prevent drowning or other serious injuries, pay close attention to the following safety guidelines.

- Never leave children unattended in or around the pool. Adult supervision is required at all times.
- Keep children within sight and reach.
- Empty the pool after each use to prevent water accumulation.
- Ensure the pool is placed on a level, stable surface, free from sharp objects.
- Do not dive or jump into the pool.
- Keep all electrical devices away from the pool.
- Follow all local regulations regarding pool safety and fencing.



Image: An adult supervising three children playing in the Intex Family Lounge Pool, demonstrating safe use.

Parts List

Verify that all components are present before beginning assembly:

- Inflatable Pool
- Repair Patch

Setup Instructions

1. **Choose a Location:** Select a flat, level surface in your yard, free from sharp objects, debris, or excessive slopes. Ensure adequate drainage away from the pool area.
2. **Unfold the Pool:** Carefully unfold the inflatable pool and lay it flat in your chosen location.
3. **Inflate Air Chambers:** The pool features two air chambers, each with a combo valve for quick inflation and deflation.
    - Open the valve cap and pull out the stem.
    - Insert an air pump nozzle (not included) into the valve.
    - Inflate each chamber until it is firm to the touch but not overinflated. Overinflation can cause damage.
    - Close the valve stem and push the cap securely back into place.



Image: An illustrative diagram highlighting the built-in cup holders, comfortable backrest, and bench seating of the inflatable pool.

4. **Fill with Water:** Once fully inflated, begin filling the pool with water using a garden hose. Do not overfill. The

recommended water capacity is 156 gallons (590 liters).

Operating Instructions

The INTEX Swim Center Inflatable Family Lounge Pool is designed for recreational use by individuals aged 3 years and older, with adult supervision.

- **Built-in Bench and Cup Holders:** Utilize the comfortable built-in bench with backrest for relaxation. The two integrated cup holders are convenient for beverages.



Image: A close-up view of the blue built-in cup holder, integrated into the white rim of the inflatable pool.



Image: A woman in a purple swimsuit sitting on the built-in bench of the pool, holding a water bottle in the integrated cup holder.

- **Water Level:** Maintain an appropriate water level, ensuring it is not too high to prevent splashing out or too low for comfortable use.
- **Supervision:** Always ensure constant adult supervision when the pool is in use, especially with children.

Maintenance

- **Draining the Pool:** The pool is equipped with a convenient drain plug for quick and easy draining.
  - Locate the drain plug at the bottom of the pool.
  - Remove the cap to allow water to drain. Direct the water to a suitable drainage area.
  - Once empty, replace the drain plug cap securely.
- **Cleaning:** Regularly clean the pool with mild soap and water. Rinse thoroughly and allow to dry completely before storage. Do not use abrasive cleaners or brushes.
- **Storage:** When not in use, deflate the pool, clean it, and ensure it is completely dry. Fold it neatly and store it in a cool, dry place away from direct sunlight and extreme temperatures.

- **Repair Patch:** In case of small punctures, use the included repair patch.
  - Clean and dry the damaged area thoroughly.
  - Cut the repair patch to a size slightly larger than the puncture.
  - Apply the patch firmly over the hole, pressing out any air bubbles.
  - Allow sufficient time for the patch to bond before re-inflating or filling the pool.

Troubleshooting

Problem	Possible Cause	Solution
Pool deflates quickly.	Puncture or loose valve cap.	Check for punctures and use the repair patch. Ensure valve caps are securely closed.
Water leaks from drain plug.	Drain plug not fully sealed.	Ensure the drain plug cap is firmly in place.
Pool is unstable.	Uneven ground or under-inflated chambers.	Relocate to a level surface. Inflate air chambers to recommended firmness.

Specifications



Image: Graphic illustrating the pool's inflated size (90" x 86" x 31"), weight (16.77 lbs), and water capacity (156 gal / 590L).

Feature	Detail
Model Number	57190EP
Dimensions (Inflated)	90" L x 86" W x 31" H
Water Capacity	156 Gallons (590 Liters)
Material	Rugged 13-gauge Vinyl (Polyvinyl Chloride - PVC)
Color	Blue
Recommended Age	3+ years (with adult supervision)
Special Features	Built-in bench, 2 air chambers with combo valves, 2 cup holders, Drain plug

Feature	Detail
Item Weight	14.99 pounds (6800 Grams)




Image: Graphic displaying key specifications: Drain Plug, 13-Gauge Vinyl, and 3+ Years Old recommended age.

Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please contact Intex customer service. Refer to the product packaging or the official Intex website for the most current contact details.

Website: www.intexcorp.com

© 2024 Intex Recreation Corp. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What type of pump or attachment do I need to inflate the Intex 57190EP Swim Center Inflatable Family Lounge Pool?

The Intex 57190EP Swim Center Inflatable Family Lounge Pool features two air chambers equipped with combo valves. These valves are designed with a large opening for quick inflation and deflation.To inflate this pool successfully,...

Read full answer