

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Britax](#) /

› [Britax Frontier ClickTight Harness-2-Booster Car Seat Instruction Manual](#)

Britax Frontier ClickTight

Britax Frontier ClickTight Harness-2-Booster Car Seat Instruction Manual

Model: Frontier ClickTight (E9LY76L)

Brand: Britax

1. INTRODUCTION

This manual provides essential information for the proper installation, use, and maintenance of your Britax Frontier ClickTight Harness-2-Booster Car Seat. Please read all instructions carefully before using the car seat to ensure maximum safety and comfort for your child. Retain this manual for future reference.



Image 1: The Britax Frontier ClickTight Harness-2-Booster Car Seat, showcasing its design and features.

2. SAFETY INFORMATION

The Britax Frontier ClickTight Harness-2-Booster Car Seat is designed with advanced safety features to protect your child. Always follow these guidelines:

- **Weight and Height Limits:**
 - Forward-facing harness mode: For children weighing 25-90 pounds and standing height 30-58 inches.
 - Booster mode: For children weighing 40-120 pounds and standing height 45-62 inches.
- **SafeCell Impact Protection:** Features a steel frame, energy-absorbing base, and V-shaped tether to minimize seat rotation and reduce forward movement in a crash.
- **Side Impact Protection:** Equipped with 2 strong layers of side energy absorption, including a deep foam-lined shell and head protection.
- Always ensure the car seat is securely installed and the child is properly restrained according to the chosen mode.
- Never use a car seat that has been involved in a moderate to severe crash, even if it appears

undamaged.



Image 2: Side view of the car seat, illustrating the two layers of side impact protection.




Image 3: Rear view of the car seat, detailing the patented V-Shape Rip Stitch Tether and Stabilizing Steel Frame for enhanced safety.

3. PRODUCT FEATURES

- **ClickTight Installation System:** Simplifies car seat installation using the vehicle's seat belt.
- **9-Position Quick-Adjust Headrest & Harness:** Allows for easy adjustment of harness height and headrest without rethreading.
- **5-Point Harness:** Provides secure restraint in harness mode, easily tucks away for booster mode.
- **Integrated Cup Holders:** Two cup holders for convenience, easy to clean.
- **Forward-Facing Design:** Designed for forward-facing use only.

Harnessed Mode

25 - 90 lbs



Belt-Positioning Booster Mode

40 - 120 lbs



Standing Height
62" Or less

Image 4: Front view of the Britax Frontier ClickTight Car Seat, showing the harness and headrest.

4. SETUP & INSTALLATION

The Britax ClickTight installation system makes securing the car seat simple and secure. Follow these steps for proper installation:

- 1. Open:** Lift the ClickTight panel to open the belt path.
- 2. Buckle:** Thread the vehicle's seat belt through the designated belt path and buckle it. Ensure there is no slack.
- 3. Close:** Press the ClickTight panel down firmly until it clicks into place.

Always check for a secure installation by attempting to move the car seat at the belt path. It should not move more than one inch side-to-side or front-to-back.

CLICK  TIGHT
INSTALLATION SYSTEM

Forward Facing



1. Open



2. Buckle



3. Close

Image 5: Visual guide for the three-step ClickTight installation process: Open the panel, buckle the seat belt, and close the panel.

Installation Video

Video 1: Official Britax video demonstrating the ClickTight installation process for the Harness-2-Booster Car Seat. This video provides a visual walkthrough of securing the car seat using the vehicle's seat belt.

5. OPERATING INSTRUCTIONS

Harness Mode (25-90 lbs)

For younger children within the specified weight and height limits, use the 5-point harness system. Ensure

the harness straps are snug against your child's body and the chest clip is at armpit level.

9-Position Quick-Adjust Headrest & Harness



Image 6: Detail of the 5-point harness system, which can be easily tucked away when transitioning to booster mode.

Booster Mode (40-120 lbs)

As your child grows and meets the minimum requirements for booster mode, the 5-point harness can be stored within the seat. The car seat then functions as a belt-positioning booster, using the vehicle's seat belt to secure your child.



Image 7: Illustration comparing a child secured in harnessed mode (left) and booster mode (right), showing the appropriate use for different ages and sizes.

Adjustments

- **Headrest and Harness Height:** Use the quick-adjust mechanism to raise or lower the headrest and harness simultaneously. This ensures the harness straps are always at the correct height for your child's shoulders without rethreading.



5-Point Harness

Easily tucks away
for booster mode

Image 8: The 9-position quick-adjust headrest and harness system, demonstrating its range of motion for growing children.



2 Integrated
Cup Holders

Image 9: Detail of the two integrated cup holders, designed for convenience and easy cleaning.

6. MAINTENANCE & CLEANING

Regular cleaning helps maintain the car seat's condition and hygiene. Refer to the full user guide for detailed cleaning instructions for specific components.

- **Fabric Covers:** Machine wash with cold water on a gentle cycle with mild detergent. Tumble dry on low heat or air dry. Do not use bleach.
- **Harness Straps:** Wipe with a damp cloth and mild soap. Do not machine wash, bleach, or immerse in water, as this may weaken the straps.
- **Buckle:** Clean with a damp cloth. If food or liquid gets into the buckle, flush with warm water. Do not use detergents or lubricants.
- **Plastic and Metal Parts:** Wipe with a damp cloth and mild soap.

7. TROUBLESHOOTING

If you encounter any issues with your Britax Frontier ClickTight car seat, please consult the full user manual for detailed troubleshooting steps. Common issues and their solutions often include:

- **Loose Installation:** Re-engage the ClickTight system, ensuring the vehicle seat belt is fully tightened before closing the panel. Verify the top tether is correctly attached and tightened.
- **Harness Adjustment Difficulty:** Ensure the quick-adjust handle is fully engaged when adjusting the headrest and harness height. Check for any twists in the harness straps.
- **Buckle Sticking:** Clean the buckle as described in the Maintenance section.

For persistent problems or concerns, contact Britax Customer Service.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions	21 x 19 x 28 inches (minimum) to 19 W x 36 H x 21 D inches (maximum)
Item Model Number	E9LY76L
Minimum Weight Recommendation (Harness)	25 Pounds
Maximum Weight Recommendation (Harness)	90 Pounds
Minimum Weight Recommendation (Booster)	40 Pounds
Maximum Weight Recommendation (Booster)	120 Pounds
Maximum Height Recommendation (Harness)	58 Inches
Maximum Height Recommendation (Booster)	62 Inches
Material Type	Steel and Mesh Fabric
Item Weight	24.9 pounds
Orientation	Forward Facing

9. WARRANTY & SUPPORT

For information regarding product warranty, registration, or to contact customer support, please visit the official Britax website or refer to the warranty card included with your purchase. Britax is committed to providing safe and reliable products and offers support for any questions or concerns you may have.

Legal Disclaimer: In no event, regardless of cause, shall Britax be liable for any indirect, special, incidental, punitive or consequential damages of any kind, whether arising under breach of contract, tort (including negligence), strict liability or otherwise, and whether based on this agreement or otherwise, even if advised of the possibility of such damages.

