

[manuals.plus](#) /

› [Symphonized](#) /
› [Symphonized NXT Bluetooth Portable Wood Speaker User Manual](#)

Symphonized NXT

Symphonized NXT Bluetooth Portable Wood Speaker User Manual

INTRODUCTION

Thank you for choosing the Symphonized NXT Bluetooth Portable Wood Speaker. This manual provides detailed instructions for the proper setup, operation, and maintenance of your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

PRODUCT OVERVIEW

The Symphonized NXT speaker is crafted from natural wood, designed to deliver clear acoustics and deep bass. It features Bluetooth 4.1 connectivity for wireless audio streaming and an auxiliary input for wired connections.

Key Features:

- Handcrafted from a solid piece of natural wood for enhanced sound quality.
- Bluetooth 4.1 for quick and easy wireless connection.
- Up to 6 hours of continuous playtime on a single charge.
- Includes an auxiliary cable for wired audio playback.
- Compact and portable design.
- Built-in controls for volume and track management.
- Strong moisture resistance and shockproof rubber base.

What's Included:

- Symphonized NXT Portable Bluetooth Wood Speaker
- Eco-friendly carrying pouch
- Tangle-free Aux/Micro USB dual cable



Figure 1: Included accessories with the Symphonized NXT speaker.

SETUP

Charging the Speaker:

1. Connect the Micro USB end of the provided dual cable to the charging port on the speaker.
2. Connect the USB-A end of the cable to a compatible USB power adapter (not included) or a computer's USB port.

3. The charging indicator light will illuminate. A full charge takes approximately 2 hours.
4. Once fully charged, the indicator light may change or turn off (refer to LED indicator section for details).

Note: Ensure the speaker is fully charged before first use for optimal battery life.

Bluetooth Pairing:

1. Ensure the speaker is charged and powered off.
2. Slide the power switch (located on the bottom of the speaker) to the "ON" position. The speaker will enter pairing mode automatically, indicated by a flashing LED light (typically blue).
3. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
4. Search for available devices and select "Symphonized NXT" from the list.
5. Once connected, the LED indicator on the speaker will stop flashing and remain solid (typically blue).
6. You can now play audio wirelessly through your Symphonized NXT speaker.

Note: The speaker has a Bluetooth working distance of up to 33 feet (10 meters). Obstacles may reduce this range.

Wired Connection (AUX Mode):

1. Connect one end of the provided 3.5mm auxiliary cable to the AUX input port on the speaker.
2. Connect the other end of the 3.5mm auxiliary cable to the headphone jack or audio output of your device (e.g., MP3 player, computer).
3. The speaker will automatically switch to AUX mode.
4. Adjust the volume on both your device and the speaker for desired audio level.

OPERATING INSTRUCTIONS

Power On/Off:

- To power on, slide the switch on the bottom of the speaker to "ON".
- To power off, slide the switch on the bottom of the speaker to "OFF".

User-Friendly Operation

Durable Construction



Built-in controls



Strong Moisture Resistance
and Shockproof Rubber Base

Figure 2: Power switch and control buttons are located on the bottom of the speaker.

Volume Control:

- Press the + button to increase volume.
- Press the - button to decrease volume.

Track Control:

- Press the >>| button to skip to the next track.

- Press the |<< button to go to the previous track.
- Press the >|| button to play or pause audio.

Note: These controls are located on the bottom panel of the speaker.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Use the provided carrying pouch for protection during transport.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker regularly, even if not in use, to maintain battery health.
- **Moisture Protection:** While the speaker has strong moisture resistance, it is not waterproof. Avoid submerging it in water or exposing it to heavy rain.

TROUBLESHOOTING

No Power:

- Ensure the speaker is fully charged.
- Verify the power switch is in the "ON" position.

Cannot Pair via Bluetooth:

- Make sure the speaker is in pairing mode (flashing LED). If not, power cycle the speaker.
- Ensure your device's Bluetooth is enabled and within the 33-foot (10-meter) range.
- Forget "Symphonized NXT" from your device's Bluetooth list and attempt to pair again.
- Try pairing with a different Bluetooth device to rule out an issue with your primary device.

No Sound or Low Volume:

- Increase the volume on both the speaker and your connected device.
- If using AUX mode, ensure the cable is securely connected to both devices.
- If using Bluetooth, ensure the speaker is properly paired and connected.

Sound Distortion:

- Reduce the volume on both the speaker and your connected device.
- Ensure there are no obstructions between your device and the speaker if using Bluetooth.
- Check the audio source for quality issues.

SPECIFICATIONS

Model Name	NXT
Speaker Type	Portable Bluetooth Speaker
Wireless Communication Technology	Bluetooth 4.1

Bluetooth Range	Up to 33 feet (10 meters)
Speaker Maximum Output Power	3.3 Watts
Audio Output Mode	Stereo
Power Source	Battery Powered (1 Lithium Ion battery required)
Battery Life	Up to 6 hours
Charging Time	Approximately 2 hours
Product Dimensions	4.1"D x 4"W x 3.1"H
Item Weight	4.8 ounces
Material	Genuine Bamboo Wood
Is Waterproof	FALSE (Moisture Resistant)
Connectivity Technology	Auxiliary, Bluetooth, USB

WARRANTY AND SUPPORT

The Symphonized NXT Bluetooth Portable Wood Speaker comes with a **1-Year Limited Warranty**. This warranty covers manufacturing defects and ensures that your product is free from defects in materials and workmanship under normal use.

For warranty claims or technical support, please contact Symphonized customer service. You can find contact information on the official Symphonized website or through your retailer.

Please retain your proof of purchase for warranty validation.