



[Manuals.plus](#) /

> [Intex](#) /

> Intex PureSpa Attachable Cup Holder User Manual

Intex 28500E

Intex PureSpa Attachable Cup Holder User Manual

Model: 28500E

INTRODUCTION

The Intex PureSpa Attachable Cup Holder is designed to enhance your spa experience by providing a convenient and secure location for your beverages and small items. This accessory easily attaches to the wall of your Intex PureSpa, ensuring your refreshments are always within reach while you relax.

SAFETY INFORMATION

WARNING: This product can expose you to chemicals including Di(2-ethylhexyl)phthalate (DEHP), which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. Do not use this cup holder with hot liquids, alcohol, glass containers, breakable cups, or electrical objects. Ensure items placed in the holder are stable and will not spill or cause injury.

PRODUCT FEATURES

- **Attachable Design:** Securely attaches to the walls of your Intex PureSpa.
- **Beverage Capacity:** Holds 2 standard-sized beverage containers in dedicated cupholders.
- **Additional Storage:** Features a larger open area for other drinks, snacks, or personal items.
- **Durable Construction:** Made from durable laminated material designed to resist water damage.
- **Removable:** Easily removes for convenient storage when not in use.
- **Compatibility:** Designed for use with Intex PureSpa models 28401, 28403, 28404, 28413, 28421, 28423, and 28453.



Figure 1: Front view of the Intex PureSpa Attachable Cup Holder.

SPA CUPHOLDER TRAY DIMENSIONS




Figure 2: Dimensions of the PureSpa Cup Holder: 10.25 inches (L) x 8.60 inches (W) x 7 inches (H).

PURESPA CUPHOLDER TRAY

FEATURES



Fits all PureSpa models



Securely attaches to the spa wall



Removable for convenience



**Holds 2 standard size
beverage containers**

Figure 3: Key features illustrated: Fits all PureSpa models, securely attaches, removable, and holds two standard size beverage containers.

SETUP AND INSTALLATION

The Intex PureSpa Attachable Cup Holder is designed for quick and easy installation on your PureSpa unit.

1. Ensure your Intex PureSpa is properly inflated and set up according to its own user manual.
2. Locate a desired position on the spa wall where you wish to attach the cup holder.
3. Align the attachment clips on the underside of the cup holder with the top edge of the spa wall.
4. Gently but firmly push the cup holder downwards until the clips securely grip the spa wall. The design allows it to softly grip the spa wall without causing damage.
5. Verify that the cup holder is stable and does not wobble before placing any items on it.



Figure 4: The cup holder securely attached to the spa wall, ready for use.

OPERATING INSTRUCTIONS

Using your Intex PureSpa Attachable Cup Holder is straightforward:

1. Once installed, place your standard-sized beverage containers into the designated cup holder slots.
2. Utilize the larger flat area for snacks, a mobile phone, or other small personal items you wish to keep dry and accessible.
3. Always ensure items are placed securely to prevent them from falling into the spa water.

INTEX®



Figure 5: A user placing a water bottle into one of the cup holder slots.



Figure 6: The cup holder accommodating two standard water bottles.

MAINTENANCE

To ensure the longevity and cleanliness of your Intex PureSpa Attachable Cup Holder:

- After each use, or as needed, wipe down the cup holder with a damp cloth to remove any spills or residue.
- For deeper cleaning, use mild soap and water. Rinse thoroughly and allow to air dry completely before storing.
- Store the cup holder in a cool, dry place away from direct sunlight when not in use for extended periods.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the material.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------------------|--|---|
| Cup holder is not attaching securely. | Spa wall not fully inflated or clips not properly aligned. | Ensure your PureSpa is inflated to the recommended pressure. Re-align the clips and apply firm, even pressure until it clicks into place. |
| Items are falling out of the holder. | Holder is overloaded or items are unstable. | Do not overload the holder. Ensure items are placed upright and are not top-heavy. Avoid using with glass or breakable items. |
| Discoloration or residue on holder. | Exposure to harsh chemicals or prolonged sun exposure. | Clean regularly with mild soap and water. Store in a shaded area when not in use to prevent sun damage. Avoid harsh cleaning agents. |

SPECIFICATIONS

| Attribute | Detail |
|--------------------------------|--|
| Brand | Intex |
| Model Number | 28500E |
| Color | Original Version (Tan) |
| Material | Plastic |
| Product Dimensions (L x W x H) | 10.25" x 8.63" x 7" (26cm x 22cm x 18cm) |
| Item Weight | 11.2 ounces |
| Compatibility | Intex PureSpa models 28401, 28403, 28404, 28413, 28421, 28423, 28453 |

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Intex website or the full user manual provided with your Intex PureSpa product.

You can also download the comprehensive user manual (PDF) for this product and other Intex PureSpa accessories from the following link:

[Download User Manual \(PDF\)](#)

For further assistance, please visit the [Intex Store on Amazon](#).



© 2025 Intex. All rights reserved.