Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UGREEN 10350

UGREEN 5ft USB A to B Printer Cable Instruction Manual

Model: 10350 | Brand: UGREEN

1. Introduction

The UGREEN 5ft USB A to B Printer Cable is designed for high-speed data transfer between your computer and various USB B devices. This cable provides a stable and efficient connection for peripherals such as printers, scanners, servers, hard drives, cameras, and MIDI instruments like pianos.



Figure 1: UGREEN 5ft USB A to B Printer Cable, showcasing its black cable and gold-plated USB-A and USB-B connectors.

2. Product Features

- **High-Speed Data Transfer:** Supports up to 480 Mbps for USB 2.0 devices, ensuring quick and efficient data transmission. It is backward compatible with USB 1.1 (12 Mbps) and USB 1.0 (1.5 Mbps).
- **Universal Compatibility:** Ideal for connecting a wide range of USB B devices including HP, Canon, Brother, Samsung, Dell, Epson, Lexmark, Xerox printers, scanners, MIDI keyboards, digital pianos, and DACs.
- **Premium Build Quality:** Features corrosion-resistant gold-plated connectors and robust foil/braid shielding to ensure long-term performance without signal loss or noise interference.
- **Plug and Play:** No additional drivers are required for installation. Simply connect the cable to your devices and it's ready for use.

- **Optimal Length:** The 5ft (1.5m) length provides sufficient reach for most desktop setups, allowing flexible placement of your printer or other peripherals.



Figure 2: Illustrates the superior stability of a wired connection using the UGREEN cable compared to a wireless (Wi-Fi) connection for data transfer.



Figure 3: Demonstrates the cable's ability to maintain signal integrity over its length, allowing for flexible device placement without loss.

3. Setup & Connection

Connecting your UGREEN USB A to B Printer Cable is straightforward. Follow these steps:

1. Locate the USB-A port on your computer (laptop or desktop).
2. Locate the USB-B port on your printer, scanner, or other compatible device. This port is typically square-shaped.
3. Insert the USB-A end of the UGREEN cable into the USB-A port on your computer.
4. Insert the USB-B end of the UGREEN cable into the USB-B port on your peripheral device. Ensure a firm and secure connection.
5. Your computer should automatically detect the connected device. No additional drivers are typically needed for most modern operating systems (Windows, Mac OS, Linux, Chrome OS).

4. Operating Instructions

Once connected, the UGREEN USB A to B Printer Cable facilitates seamless data transfer. Here’s how to operate it with common devices:

4.1. With Printers and Scanners

- Ensure both your computer and the printer/scanner are powered on.
- Initiate your print job or scan operation from your computer's software. The cable will provide a direct, stable connection for fast processing.



Figure 4: Demonstrates the cable enabling fast printing from a laptop to a printer.



Figure 5: Highlights the cable's ability to ensure clear and undistorted print output.

4.2. With MIDI Keyboards and Digital Pianos

- Connect the USB-B end of the cable to your MIDI keyboard or digital piano.
- Connect the USB-A end to your computer.
- Use your preferred music software (DAW, notation software) to send or receive MIDI data. The cable ensures a stable MIDI connection without noise or glitches.



Figure 6: Shows the UGREEN cable providing a stable MIDI connection between a laptop and a MIDI keyboard.

5. Care & Maintenance

To ensure the longevity and optimal performance of your UGREEN USB A to B Printer Cable, follow these care guidelines:

- **Handle with Care:** Avoid excessive bending, twisting, or pulling on the cable, especially near the connectors.
- **Clean Connectors:** If connectors appear dirty, gently wipe them with a dry, lint-free cloth. Avoid using liquids or abrasive cleaners.
- **Proper Storage:** When not in use, coil the cable loosely and store it in a dry, cool place away from direct sunlight and extreme temperatures.
- **Inspect Regularly:** Periodically check the cable and connectors for any signs of wear, damage, or corrosion.



Figure 7: Highlights the 24K gold-plated plug for long lifespan and the durable PVC jacket designed to prevent easy breakage.

6. Troubleshooting

If you encounter issues with your UGREEN USB A to B Printer Cable, consider the following common solutions:

- **Device Not Recognized:**
  - Ensure both ends of the cable are securely plugged into the correct ports.
  - Try connecting the cable to a different USB port on your computer.
  - Restart your computer and the connected device (printer, scanner, etc.).
  - Verify that the connected device is powered on and functioning correctly independently of the cable.
- **Slow Data Transfer:**
  - Confirm that both your computer's USB port and the device's USB-B port support USB 2.0 speeds.
  - Ensure no other high-bandwidth USB devices are simultaneously connected and heavily in use on the same USB hub.

- **Intermittent Connection:**
  - Check for any physical damage to the cable or connectors.
  - Ensure the cable is not excessively bent or kinked, which can damage internal wiring.

As this is a Plug and Play cable, driver issues are rare. If problems persist after trying these steps, consider testing with another known-good USB A to B cable to isolate the issue.

7. Technical Specifications

Specification	Detail
Brand	UGREEN
Model Name	10350
Connector Type	USB Type B (Male-to-Male)
Cable Type	USB 2.0
Data Transfer Rate	Up to 480 Megabits Per Second (USB 2.0)
Compatible Devices	Laptop, Scanner, Printer, Server, Hard Drive, Camera, Piano, DAC
Special Feature	High Speed, Corrosion Resistant (Gold-plated connectors)
Color	Black
Item Weight	2.11 ounces (0.06 Kilograms)
Product Dimensions	5.31 x 7.68 x 0.39 inches
Hardware Platform	PC, Mac
Operating System Compatibility	Linux, Chrome OS, Mac OS, All Windows



Figure 8: Visual representation of the cable's broad compatibility with printers, scanners, fax machines, MIDI keyboards, digital pianos, and DAC decoders.

8. Warranty & Support

UGREEN products are manufactured with high standards of quality and reliability. For any product inquiries, technical support, or warranty claims, please contact UGREEN customer service through their official website or the retailer from whom you purchased the product. Please refer to your purchase documentation for specific warranty terms and conditions.

Manufacturer: UGREEN GROUP LIMITED

© 2025 UGREEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00P0FO1P0

More documents and user manuals: **https://manuals.plus/**