

[Manuals.plus](#) /

› [Simple Designs](#) /

› Simple Designs LF1014-BLK 62.5" Modern Etagere 3-Shelf Floor Lamp Instruction Manual

Simple Designs LF1014-BLK

Simple Designs LF1014-BLK 62.5" Modern Etagere 3-Shelf Floor Lamp Instruction Manual

Model: LF1014-BLK | Brand: Simple Designs

INTRODUCTION

Thank you for purchasing the Simple Designs LF1014-BLK 62.5" Modern Etagere 3-Shelf Floor Lamp. This manual provides essential information for the safe assembly, operation, and maintenance of your new lamp. Please read all instructions carefully before use and retain this manual for future reference.



Figure 1: Simple Designs LF1014-BLK Floor Lamp

SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, please follow these safety guidelines:

- Ensure the power is OFF before assembly, disassembly, or bulb replacement.
- Use only the specified bulb type and wattage (1 x 100W equivalent Type A medium base bulb, not included).
- Do not use with a dimmer switch unless the bulb is specifically rated for dimmable use.
- Keep the lamp away from water and moisture. This product is for indoor use only and is not water resistant.
- Do not place heavy objects on the shelves. The shelves are designed for light decorative items.
- Ensure all connections are secure before plugging in the lamp.
- If the power cord is damaged, it must be replaced by a qualified electrician to avoid hazards.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Bottom Board
- 1 x Fabric Shade
- 1 x Lamp Holder Board
- 2 x Shelf Boards
- 4 x Short Posts
- Hardware (screws, connectors, etc.)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your floor lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratching.
2. **Assemble the Frame:** Connect the short posts to the bottom board and the two shelf boards using the provided hardware. Ensure all connections are finger-tight initially.
3. **Attach Lamp Holder Board:** Secure the lamp holder board to the top of the frame.
4. **Tighten Connections:** Once the frame is upright and stable, carefully tighten all screws with a screwdriver. Do not overtighten.
5. **Install Light Bulb:** Screw a 100W equivalent Type A medium base bulb (not included) into the lamp holder.
6. **Attach Fabric Shade:** Carefully place the fabric shade over the top section of the lamp, ensuring it sits securely.
7. **Organize Cord:** Use the provided cord clips to secure the power cord along one of the lamp's vertical posts for a neat appearance.



Figure 2: Assembled lamp with decorative items

OPERATING INSTRUCTIONS

To operate your Simple Designs Floor Lamp:

- Plug the lamp into a standard 120V electrical outlet.
- The lamp features a convenient pull-chain on/off switch. Gently pull the chain to turn the light ON or OFF.







Figure 3: Pull-chain switch for easy operation

MAINTENANCE

Regular maintenance will help prolong the life of your lamp:

- **Cleaning:** Disconnect the power before cleaning. Wipe the lamp frame and shelves with a soft, dry cloth. Do not use abrasive cleaners or polishes. The linen shade can be gently dusted or spot cleaned with a damp cloth if necessary.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely. Unscrew the old bulb and replace it with a new 100W equivalent Type A medium base bulb.

TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

- **Light does not turn on:**
 - Check if the lamp is properly plugged into a working outlet.
 - Ensure the light bulb is screwed in tightly and is not burnt out. Replace if necessary.
 - Verify the pull chain mechanism is functioning correctly.
- **Lamp is unstable:**
 - Ensure all assembly screws are securely tightened.
 - Place the lamp on a flat, level surface.

SPECIFICATIONS

Feature	Detail
Model Number	LF1014-BLK
Product Dimensions	10"D x 10"W x 62.5"H
Item Weight	9.5 Pounds
Base Material	Engineered Wood
Shade Material	Linen
Shade Color	White
Color	Black
Light Source Type	LED (compatible)
Bulb Base	E26 Medium
Wattage	100 watts (equivalent)

Switch Type	Pull Chain
Power Source	Corded Electric
Voltage	120 Volts
Indoor/Outdoor Usage	Indoor






Figure 4: Product Dimensions

WARRANTY AND SUPPORT

This Simple Designs product comes with a **1-year limited warranty** against manufacturer defects. For warranty claims or technical support, please contact the manufacturer, All The Rages, directly. Keep your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

