

Somfy Telis 16 RTS

Somfy Telis 16 RTS Silver Remote with Display (Model 1811082) Instruction Manual

This manual provides detailed instructions for the setup, operation, and maintenance of your Somfy Telis 16 RTS remote control.

INTRODUCTION

The Somfy Telis 16 RTS remote is designed to control up to 16 individual or grouped motorized products, such as blinds and shades. Its on-screen display and intuitive controls enhance convenience in managing multiple window treatments.





Front view of the Somfy Telis 16 RTS Silver Remote, showing the display and control buttons.

Product Features

- Remote control for up to 16 RTS motorized devices or groups
- On-screen icons identify different channels
- "My" function remembers a favorite motor setting
- Silver finish blends subtly into any decor

SETUP AND INSTALLATION

Battery Installation

The Somfy Telis 16 RTS remote requires batteries for operation.

1. Locate the battery compartment on the back of the remote.
2. Open the compartment cover.
3. Insert the specified batteries, ensuring correct polarity.
4. Close the battery compartment cover securely.



Side view of the Somfy Telis 16 RTS remote, illustrating its ergonomic design and potential battery compartment location.

Pairing with Motorized Devices

To control your motorized blinds or shades, the remote must be paired with each device or group. Refer to the specific instructions for your Somfy motorized product for detailed pairing procedures. Generally, this involves a short press on the programming button of the motor, followed by a press on the remote's programming button.

OPERATING INSTRUCTIONS

Channel Selection

The Telis 16 RTS remote allows control of up to 16 channels. Use the channel selection buttons (usually

located below the display) to cycle through the available channels. The selected channel number will be shown on the display.





Close-up of the Somfy Telis 16 RTS remote display, showing a channel number and product icon.

Basic Control Functions

Once a channel is selected, use the following buttons for operation:

- **Up Arrow (▲):** Moves the motorized product up (e.g., opens blinds).
- **Down Arrow (▼):** Moves the motorized product down (e.g., closes blinds).
- **"My" Button:** Stops the movement or recalls a pre-programmed favorite position.



Angled view of the Somfy Telis 16 RTS remote, highlighting the up, down, and 'my' control buttons.

Setting a "My" Favorite Position

The "My" function allows you to save a preferred intermediate position for your motorized product.

1. Move the motorized product to your desired intermediate position using the Up or Down arrows.
2. Press the "My" button to stop the movement.
3. Press and hold the "My" button until the motorized product jogs slightly. This indicates the position has been saved.
4. To recall this position, simply press the "My" button when the product is fully open or closed.

MAINTENANCE

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.

Battery Replacement

When the battery indicator appears on the display or the remote's range decreases, replace the batteries. Refer to the "Battery Installation" section for instructions.

TROUBLESHOOTING

Remote Not Responding

- Check battery level and replace if necessary.
- Ensure the remote is within range of the motorized product.
- Verify the correct channel is selected on the remote.
- Re-pair the remote with the motorized product if connection issues persist.

Motorized Product Not Moving to "My" Position

- Ensure a "My" position has been correctly programmed. Repeat the "Setting a 'My' Favorite Position" steps if unsure.

SPECIFICATIONS

Technical Specifications

Feature	Detail
Manufacturer	Somfy
Part Number	1811082
Item Weight	0.01 ounces
Product Dimensions	5 x 2 x 8 inches
Item Model Number	Telis Silver, 16 Channel
Finish	Silver
Item Package Quantity	1
Special Features	Ergonomic
Batteries Included?	Yes
Batteries Required?	Yes
Description Pile	Rechargeable Lithium-Ion
Brand	Somfy
Max Number of Supported Devices	16 (channels)

Feature	Detail
Compatible Devices	Motorized Devices, Somfy Automation System
Connectivity Technology	Infrared (RTS)

WARRANTY INFORMATION

The Somfy Telis 16 RTS remote control comes with a 5-year warranty. For detailed terms and conditions, please refer to the official Somfy warranty documentation or contact Somfy customer support.





Somfy 5-year warranty logo.





SUPPORT AND CONTACT

For further assistance, technical support, or to inquire about additional Somfy products, please visit the official Somfy website or contact their customer service department.

You can find more information and products at the [Somfy Store on Amazon](#).

Related Documents - Telis 16 RTS

	<p>Somfy Tilt 50 WireFree RTS Programming and Operation Instructions</p> <p>A comprehensive guide detailing the programming and operation of Somfy Tilt 50 WireFree RTS motorized window covering systems. Covers initial setup, limit setting, transmitter pairing, and operational modes for various Somfy remote controls.</p>
	<p>Somfy SONESSE 40 Motors: Product Overview and Specifications</p> <p>A comprehensive guide to Somfy's SONESSE 40 motors, detailing their features, technical specifications, applications for roller, Venetian, and Roman blinds, mounting options, and integration capabilities.</p>

	<p>Somfy Telis RTS Remote Controls: Programming and Operation Guide</p> <p>Comprehensive guide to programming and operating Somfy Telis RTS single and five-channel remote controls for motorized window coverings, including setting favorite positions and replacing batteries.</p>
	<p>Odbiornik Somfy Universal RTS: Instrukcja Instalacji i Obsługi</p> <p>Szczegółowy przewodnik instalacji i programowania odbiornika Somfy Universal RTS, zawierający dane techniczne, funkcje automatyki słonecznej i wiatrowej oraz rozwiązywanie problemów.</p>
	<p>Somfy Telis 16 RTS Remote Control User Guide</p> <p>A comprehensive guide to the Somfy Telis 16 RTS remote control, detailing its features, programming, and usage for controlling window coverings.</p>
	<p>Somfy Telis 1 & 4 RTS Patio Remote Control User Guide</p> <p>Comprehensive guide for the Somfy Telis 1 and Telis 4 RTS Patio remote controls, covering introduction, programming new channels, setting favorite positions, operation, and battery installation. Features Radio Technology Somfy® for awnings, screens, and shutters.</p>