Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM B00PDEHUF6

HOMCOM Foldable Luggage Cart Instruction Manual

Model: B00PDEHUF6

Introduction

Thank you for choosing the HOMCOM Foldable Luggage Cart. This versatile and durable cart is designed to assist you in transporting various items with ease. Its lightweight aluminum and plastic construction, combined with a foldable design and telescopic handles, makes it an ideal solution for moving, storage, shopping, and more. Please read this manual carefully before use to ensure safe and efficient operation.

Safety Instructions

- **Maximum Load Capacity:** Do not exceed the maximum load capacity of 70 kg (154 lbs). Overloading can cause damage to the cart and potential injury.
- **Secure Load:** Always ensure items are securely placed on the base plate and, if necessary, secured with straps (not included) to prevent shifting or falling during transport.
- **Stable Surface:** Use the cart on stable, level surfaces. Exercise caution on uneven terrain, inclines, or stairs.
- **Handle Grip:** Maintain a firm grip on the telescopic handles at all times.
- **Children and Pets:** Keep children and pets away from the cart during operation. This product is not a toy.
- **Storage:** Store the cart in a dry, safe place when not in use.
- **Inspection:** Before each use, inspect the cart for any signs of damage, loose parts, or wear. Do not use if damaged.

Setup and Folding

The HOMCOM Foldable Luggage Cart is designed for quick and easy deployment and storage.

Unfolding the Cart:

1. Place the folded cart on a flat surface.
2. Gently press down on the base plate. The wheels will automatically open and lock into position simultaneously.
3. Extend the telescopic handle to your desired height by pressing the release button (if present) and pulling the handle upwards. Ensure it locks securely at one of the adjustable levels.



Image: The cart's foldable design, showing how it transitions from a compact, folded state to a fully extended, ready-to-use position. The base plate and wheels deploy simultaneously.



Image: The ergonomic telescopic handle can be adjusted to three different height levels to suit various user preferences and load sizes.

Folding the Cart for Storage:

1. Ensure the handle is fully retracted.
2. Pull the base plate upwards. The wheels will automatically fold inwards and the cart will collapse into its compact form.





Image: A detailed view of the cart when fully folded, highlighting its compact design for easy storage.

Operating Instructions

1. **Load Placement:** Place items centrally on the base plate. For larger items, ensure they are balanced and do not extend excessively beyond the cart's dimensions.
2. **Handle Adjustment:** Adjust the telescopic handle to a comfortable height that allows for easy pulling without excessive bending or reaching.
3. **Movement:** Tilt the cart slightly backward to engage the wheels and then pull or push the cart. The smooth-rolling PU wheels are designed for various surfaces.
4. **Navigating Obstacles:** When encountering stairs or curbs, carefully tilt the cart and move one wheel at a time, or lift the cart over the obstacle if the load is manageable. Avoid sudden movements.



Image: The luggage cart in action, demonstrating its use for transporting packages. The ergonomic handles and sturdy wheels facilitate easy movement.



Image: Detail of the two PU wheels, designed for smooth movement and stability during transport, even with heavy loads.



Image: A detailed view of the aluminum base plate, featuring a textured surface for better grip and stability of items being transported.

Maintenance

- **Cleaning:** Wipe the cart with a damp cloth to remove dirt and dust. Avoid abrasive cleaners.
- **Lubrication:** Periodically check the wheel axles and moving parts for smooth operation. Apply a small amount of silicone-based lubricant if necessary.
- **Storage:** Store the cart in a dry environment to prevent corrosion of metal parts.



Image: A detailed view of one of the durable PU wheels and its robust attachment, designed for longevity and smooth rolling.

Troubleshooting

- **Cart not unfolding/folding smoothly:** Check for any obstructions in the folding mechanism or wheels. Ensure the base plate is fully pressed or pulled.
- **Handle sticking:** Ensure the handle release button (if applicable) is fully engaged. Clean the telescopic tubes and apply a small amount of lubricant if needed.
- **Wheels not rolling smoothly:** Check for debris caught in the wheels or axles. Clean and lubricate if necessary. Ensure wheels are securely attached.

Specifications

Feature	Detail
Brand	HOMCOM
Model	B00PDEHUF6
Material	Aluminum, Plastic
Color	Silver
Item Weight	3 kg (6.6 lbs)
Style	Foldable
Dimensions (Unfolded)	41 x 38.7 x 100 cm (L x W x H)
Dimensions (Folded)	41 x 6 x 70 cm (L x W x H)*(Inferred from image)*
Max Load Capacity	70 kg (154 lbs)



Image: A visual representation of the cart's dimensions, including height, width, and depth, in both its operational and compact storage configurations.

Product Overview Video

Your browser does not support the video tag.

Video: An official HOMCOM product video demonstrating the features and usage of the foldable luggage cart, including its folding mechanism, telescopic handle, and ease of transport. (Note: The video source is a placeholder as a specific m3u8 URL was not provided in the input, but it is a seller-created video.)

Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact HOMCOM customer service. Refer to your purchase documentation for specific warranty terms and contact details.
You can typically find support information on the manufacturer's official website or through the retailer where you purchased the product.

© 2026 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00PDEHUF6

More documents and user manuals: **https://manuals.plus/**