

[Manuals.plus](#) /

› [Child Craft](#) /

› Child Craft Sport Multi-Child Quad Stroller F99036.03 Instruction Manual

Child Craft F99036.03

Child Craft Sport Multi-Child Quad Stroller

MODEL: F99036.03

Important Safety Information

Read all instructions before assembly and use of the stroller. Keep this manual for future reference. Failure to follow these instructions could result in serious injury or death to your child.

- **WARNING:** Never leave children unattended in the stroller.
- **WARNING:** Always use the restraint system. Ensure all children are properly secured with the 5-point harness.
- **WARNING:** Do not overload the stroller. Each seat accommodates children up to 40 pounds. The total weight capacity for children is 160 pounds.
- **WARNING:** Ensure the stroller is fully erected and all locks are engaged before placing children in it.
- **WARNING:** Avoid serious injury from falling or sliding out. Always use the safety harness.
- **WARNING:** Do not use the stroller on stairs or escalators.
- **WARNING:** Engage the brake system when parking the stroller.

Package Contents

Verify that all components are present before beginning assembly:

- 1 x Child Craft Sport Multi-Child Quad Stroller frame and fabric assembly

Setup and Assembly

The Child Craft Sport Multi-Child Quad Stroller is designed for quick and easy setup.

1. **Unfolding the Stroller:** Place the folded stroller on a flat, stable surface. Release any locking mechanisms that secure the stroller in its folded position. Carefully pull the handlebar upwards until the frame fully extends and locks into place. Listen for an audible click to confirm the frame is securely locked.
2. **Attaching Wheels (if necessary):** If wheels are not pre-attached, align each wheel with its axle and push firmly until it clicks into place. Ensure all wheels rotate freely.
3. **Canopy Adjustment:** Extend the canopies over each seating area to provide sun protection.



Figure 1: Fully assembled Child Craft Sport Multi-Child Quad Stroller. This image shows the stroller in its upright, ready-to-use position, highlighting its four seating areas and overall structure.

Operating Instructions

Familiarize yourself with the stroller's features for safe and efficient operation.

1. **Child Seating:** Each seat is designed to accommodate one child up to 40 pounds. The stroller features an in-line stadium design, allowing children to see their surroundings and interact.
2. **Harness System:** Each seat is equipped with an adjustable 5-point harness. Place the child in the seat, bring the shoulder straps over the child's shoulders, and the waist straps around their hips. Connect the buckle pieces securely in the center. Adjust straps for a snug fit.



Figure 2: Detail of the 5-point harness system. This image illustrates how the harness straps and buckle are configured to secure a child safely in the seat.

3. **Seat Recline:** Seats can be reclined to accommodate infants. Locate the recline adjustment mechanism behind each seat and follow the instructions to adjust the seat angle.
4. **Braking System:** The stroller features a safe brake system that engages automatically when the stroller handle is released. To manually engage or disengage the brake, refer to the brake lever located near the handlebar. Always ensure the brake is engaged when the stroller is stationary.
5. **Maneuverability:** The stroller is designed for easy maneuverability. Its rubberized, shock-absorbing foam wheels provide a comfortable ride. The 'through the door' sizing allows for easier passage through standard doorways.
6. **Folding for Storage:** To fold the stroller, ensure all children are removed and any items are cleared from the storage baskets. Locate the folding mechanisms, typically near the handlebar or side frame, and follow the instructions to collapse the stroller. Secure it with any integrated locking latches for transport or storage.



Figure 3: View of the stroller's handlebar. This image shows the padded handlebar, which is part of the control and braking system, along with the Child Craft branding.

Maintenance

Regular maintenance ensures the longevity and safe operation of your stroller.

- **Cleaning Fabric:** The stroller features easy-to-clean fabric. Wipe spills and dirt immediately with a damp cloth and mild soap. Do not use harsh detergents or abrasive cleaners. Allow to air dry completely.
- **Wheel Maintenance:** Periodically check wheels for debris and ensure they rotate smoothly. Clean any dirt or hair from the wheel axles.
- **Frame Care:** Wipe the metal frame with a soft, damp cloth. Dry thoroughly to prevent rust.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use.



Figure 4: Detail of a stroller wheel. This image highlights the rubberized, shock-absorbing foam wheel designed for a comfortable ride and durability.

Troubleshooting

If you encounter issues with your stroller, refer to the following common solutions:

- **Stroller does not fold/unfold smoothly:** Check for any obstructions in the folding mechanism. Ensure all locking latches are disengaged before folding and fully engaged after unfolding.
- **Wheels are stiff or do not turn:** Inspect wheels for debris (e.g., hair, dirt) caught in the axles. Clean as necessary. Ensure wheels are properly attached and locked into place.
- **Brake system not engaging/disengaging:** Check the brake mechanism for any obstructions. Ensure the handlebar is fully engaged for the automatic brake to function correctly. If the issue persists, contact customer support.
- **Harness difficult to buckle/unbuckle:** Ensure no fabric is caught in the buckle. Press the release button firmly. If the buckle is damaged, discontinue use and contact customer support for replacement parts.

Specifications

Attribute	Detail
Model Number	F99036.03
Brand	Child Craft
Item Weight	65 pounds
Material Type	Metal, fabric

Harness Type	5 Point
Maximum Weight Recommendation (per child)	40 pounds
Number of Children Accommodated	4
Age Range Description	Less than 36 months
Color	Regatta Blue
UPC	849801003366

Warranty and Support

This Child Craft Sport Multi-Child Quad Stroller comes with a **1-year warranty** from the date of purchase, covering manufacturing defects.

For warranty claims, replacement parts, or technical assistance, please contact Child Craft customer support. Keep your proof of purchase for all warranty inquiries.

Customer Support: For assistance, please visit the official Child Craft website or refer to the contact information provided with your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

