

CRELANDO B00PISVJMM

Crelando Painting Case with Integrated Table Easel

Model: B00PISVJMM

1. INTRODUCTION

The Crelando Painting Case is a high-quality model crafted from natural wood, featuring an integrated table easel. This practical case includes a carrying handle and two clasps, making it ideal for artists working with oil, acrylic, or watercolor paints. It offers convenient internal compartments for organizing brushes and paints. The easel's height is adjustable, accommodating canvases up to 70 cm tall, and its tilt angle can be continuously adjusted. The kit is comprehensive, containing 50 pieces, including two 380 g/m² canvases (approx. 25 x 30 cm and 30 x 40 cm, with 3 layers of white primer), eighteen 18 ml acrylic paints, one mixing palette, two 2B pencils, two sets of 8 extension corners, and ten high-quality nylon brushes (3 round pointed brushes: sizes 4, 6, 8; 4 oval 'cat's tongue' brushes: sizes 10, 12, 14, 18; 3 flat brushes: sizes 16, 20, 22). The case dimensions are approximately 33 x 13 x 45 cm (length x width x depth).



Image: The Crelando Painting Case in its closed, portable configuration, showcasing its natural wood finish and compact design.

2. SAFETY INFORMATION

Please read and understand all safety information before using the product.

- **N-Butyl Acrylate:** This product contains n-butyl acrylate. Direct skin contact may cause sensitivity. Always use paints in a well-ventilated area.

- **Children:** This product is intended for use by individuals aged 14 and above. Keep out of reach of small children due to small parts and chemical components.
- **Disposal:** Dispose of paint residues and cleaning water according to local environmental regulations. Do not pour paints down drains.
- **Storage:** Store the painting case and supplies in a cool, dry place, away from direct sunlight and extreme temperatures.

3. PRODUCT COMPONENTS

Your Crelando Painting Case includes the following items:

- 1 x Wooden Painting Case with Integrated Table Easel
- 2 x Canvases (approx. 25 x 30 cm and 30 x 40 cm, 380 g/m², with 3 layers of white primer)
- 18 x Acrylic Paints (18 ml tubes)
- 1 x Mixing Palette
- 2 x 2B Pencils
- 2 x Sets of 8 Extension Corners (for canvases)
- 10 x High-Quality Nylon Brushes:
 - 3 x Round Pointed Brushes (Sizes: 4, 6, 8)
 - 4 x Oval 'Cat's Tongue' Brushes (Sizes: 10, 12, 14, 18)
 - 3 x Flat Brushes (Sizes: 16, 20, 22)



Image: The Crelando Painting Case opened, displaying the integrated easel holding a blank canvas, alongside various art supplies including paints, brushes, and a palette.

4. ASSEMBLY AND SETUP

4.1 Unpacking

1. Carefully remove the painting case and all components from the packaging.
2. Check the contents against the 'Product Components' list to ensure all items are present and undamaged.

4.2 Setting up the Easel

1. Place the closed painting case on a stable, flat surface.
2. Unlatch the two front clasps and gently open the top lid of the case.
3. The integrated easel mechanism will unfold. Adjust the easel's back support to achieve your desired tilt angle. The angle is continuously adjustable.
4. To adjust the height for your canvas, slide the canvas support bar up or down along the easel mast. The easel accommodates canvases up to 70 cm in height.
5. Place your canvas onto the support bar. Ensure it is securely seated.



Image: The Crelando Painting Case with its easel fully set up, holding a vibrant painting, surrounded by various art supplies ready for use.

5. USAGE GUIDELINES

5.1 Using the Easel

- Ensure the easel is stable on a flat surface before beginning to paint.
- Adjust the canvas height and tilt angle to a comfortable position for your painting style.
- The internal compartments are designed to keep your paints, brushes, and other small accessories organized during use.

5.2 Using the Paints and Brushes

- The included acrylic paints are water-soluble when wet but become water-resistant when dry.
- Squeeze a small amount of paint onto the mixing palette for use.
- Clean brushes thoroughly with water immediately after use to prevent paint from drying and hardening in the bristles.
- The 2B pencils are suitable for sketching outlines on your canvas before painting.

6. CARE AND MAINTENANCE

- **Cleaning the Easel:** Wipe the wooden easel surfaces with a dry or slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the wood finish.
- **Brush Care:** After each use, wash brushes with soap and water until all paint is removed. Reshape the bristles and allow them to air dry completely before storing.

- **Paint Storage:** Ensure paint tube caps are tightly sealed after each use to prevent paints from drying out. Store paints at room temperature.
- **Case Storage:** When not in use, close the case securely with the clasps. Store the case in a dry environment to protect the wood.

7. TROUBLESHOOTING

- **Easel Instability:** Ensure the easel is placed on a completely flat and stable surface. Check that all adjustable components are tightened securely.
- **Paint Drying in Tubes:** If paint has dried in the tube, ensure the cap is tightly sealed after each use. Store paints in a cool, consistent environment. Small amounts of dried paint near the opening can sometimes be removed with a toothpick.
- **Stiff Brushes:** If brushes become stiff due to dried paint, soak them in warm water with a mild soap for a few hours, then gently work out the dried paint. For stubborn acrylics, a specialized brush cleaner may be necessary.

8. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	CRELANDO
Model Number	B00PISVJMM
Material	Natural Wood
Color	White, Wood Color
Case Dimensions (L x W x D)	Approx. 33 x 13 x 45 cm
Max. Canvas Height	70 cm
Easel Type	Single Mast Table Easel
Assembly Required	No (Integrated Easel)
Included Paints	18 x 18ml Acrylic Paints
Total Pieces	50

9. WARRANTY AND SUPPORT

For any questions regarding your Crelando Painting Case, please refer to the retailer's return and warranty policies. Keep your proof of purchase for any warranty claims. For further assistance, please contact the customer support of your point of purchase.

