

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [ARTERO](#) /

› ARTERO X-Tron Professional Hairstyling Clippers User Manual

ARTERO 8435037160755

ARTERO X-Tron Professional Hairstyling Clippers

Model: 8435037160755

INTRODUCTION

The ARTERO X-Tron Professional Hairstyling Clippers are designed for precision and ease of use, suitable for both professional and personal grooming. This manual provides comprehensive instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.



Figure 1: Front view of the ARTERO X-Tron Clippers.

SAFETY INFORMATION

Please read all safety warnings and instructions carefully before using the clippers to prevent electric shock, fire, and serious injury.

- Avoid contact with eyes, skin, and water.
- Follow proper cleaning and maintenance procedures as outlined in this manual.
- For professional use, adhere to additional safety precautions when handling clients.
- Keep out of reach of children.
- Do not operate if the cord or plug is damaged.

SETUP

Before first use, ensure the clippers are fully charged.

1. **Unpacking:** Carefully remove all components from the packaging. Verify that all items listed in the "Package Contents" section are present.
2. **Initial Charge:** Connect the charging base to a power outlet using the provided multi-plug adapter. Place the clippers onto the charging base. The LCD screen will indicate charging status. A full charge takes approximately 90 minutes.
3. **Blade Preparation:** Before first use, apply 2 drops of the included mineral oil between the blade's teeth while the clippers are on and the blades' teeth are facing downwards. This lubricates the blades for optimal performance.



Figure 2: Clippers placed in the charging base.

OPERATING INSTRUCTIONS

The ARTERO X-Tron clippers can be operated both corded and cordless, powered by a lithium battery.

1. **Power On/Off:** Press the power button to turn the clippers on or off.
2. **Adjusting Speed:** Use the adjustable speed button to cycle through the 3 available speed settings: 5500 RPM, 6000 RPM, and 6500 RPM. The current RPM will be displayed on the informative LCD screen.
3. **Adjusting Blade Height:** The standard blade features two cutting positions: 1mm and 1.9mm. Use the sliding button on the clipper body to change the blade height.
4. **Attaching Comb Attachments:** For longer cutting lengths, attach one of the included comb attachments (3/6/9/12mm). Ensure the comb is securely fastened before use.
5. **Usage:** Guide the clippers smoothly through the hair, ensuring even pressure. The lightweight design (185g) and compact dimensions (160 x 30 x 35mm) provide comfortable handling.
6. **Battery Life:** The lithium battery provides a run time of up to 150 minutes at 5500 RPM, 135 minutes at 6000 RPM, and 120 minutes at 6500 RPM on a full charge. Monitor the battery level on the LCD screen.



Figure 3: Side view of the clippers highlighting controls.

MAINTENANCE

Proper maintenance is crucial for prolonging the life and performance of your ARTERO X-Tron clippers.

- **Cleaning:** After each use, turn off the clippers and use the provided cleaning brush to remove any hair from the blades and clipper body.
- **Oiling Blades:** With the clippers on and blades facing downwards, apply 2 drops of mineral oil between the blade's teeth. This lubricates and cools the blades.
- **Disinfection (Professional Use):** For professional use, apply Artero Oil Fresh spray (ref. Y447) between each client's appointment. This spray acts as a disinfectant, coolant, lubricant, cleanser, and anti-oxidant. It can be used as many times as required during one client's appointment.
- **Storage:** Once cleaned, store the clippers in a safe place to prevent damage.



Figure 4: Included accessories for maintenance and use.

TROUBLESHOOTING

If you encounter any issues with your ARTERO X-Tron clippers, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Clippers not turning on.	Low battery or not plugged in.	Ensure clippers are fully charged or connected to power.
Blades pulling hair or cutting poorly.	Blades are dull, dirty, or not oiled.	Clean blades thoroughly, apply mineral oil. Consider blade replacement if dull.
Excessive noise or vibration.	Lack of lubrication or foreign object.	Oil blades. Check for and remove any hair or debris caught in the blade mechanism.
Charging base not working.	Faulty connection or power adapter.	Check power outlet and connections. Try plugging clippers directly into the charger if the base is suspected.

SPECIFICATIONS

Feature	Specification
Brand	ARTERO
Model	X-Tron (Item model number: 8435037160755)
Power Source	Corded or Cordless (Lithium Battery)
Power	7W
RPM Settings	5500 / 6000 / 6520 (Adjustable)
Display	Informative LCD Screen
Weight	185g (6.5 oz)
Dimensions	160 x 30 x 35mm (6.3 x 1.2 x 1.4 inches)
Run Time (approx.)	5500RPM: 150 min; 6000RPM: 135 min; 6500RPM: 120 min
Charge Time	90 minutes
Blade Cutting Heights	1mm and 1.9mm (Adjustable via sliding button)
Comb Attachments	3/6/9/12mm (Set of 2 dual trimming combs)
Voltage	100-240V
Plug Type	Multi-plug for various countries

WARRANTY AND SUPPORT

ARTERO stands behind the quality of its products. The ARTERO X-Tron Professional Hairstyling Clippers come with a 100% ARTERO guarantee.

For any questions, technical support, or warranty claims, please contact ARTERO customer service. Refer to the packaging or the official ARTERO website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00PJ2WU98>

More documents and user manuals: <https://manuals.plus/>