

[Manuals.plus](#) /

› [ECOXGEAR](#) /

› ECOXGEAR Ecopebble Wireless Bluetooth Speaker Instruction Manual

ECOXGEAR GDI-EGPB101

ECOXGEAR Ecopebble Wireless Bluetooth Speaker Instruction Manual

Model: GDI-EGPB101

Brand: ECOXGEAR

1. INTRODUCTION

The ECOXGEAR Ecopebble is a compact, rugged, and waterproof wireless Bluetooth speaker designed for active lifestyles. This manual provides essential information for setting up, operating, and maintaining your Ecopebble speaker, ensuring optimal performance and longevity.



Image: The ECOXGEAR Ecopebble speaker, a compact black device with a hexagonal shape and a perforated speaker grille, covered in water droplets to highlight its waterproof capabilities.

2. KEY FEATURES

- **Waterproof & Submersible:** IPX7 rated, designed to withstand submersion up to 6.6 feet (2 meters).
- **Shockproof & Dustproof:** Built to endure drops and resist dust, making it ideal for outdoor adventures.
- **Floats:** Engineered to float on water, preventing loss in aquatic environments.
- **Wireless Bluetooth Connectivity:** Easily connects to your smartphone, tablet, or other Bluetooth-enabled devices.
- **Built-in Microphone:** Allows for hands-free speakerphone calls.
- **Long Battery Life:** Up to 12 hours of playtime on a single charge.
- **Integrated Mount:** Features a standard screw mount for versatile attachment to various gear like bikes or boats.
- **Portable Design:** Compact and lightweight for easy transport.
- **Wide Temperature Range:** Operates reliably in temperatures from -40°F to 165°F (-40°C to 71°C).

3. SETUP

3.1 Charging Your Ecopebble

Before first use, fully charge your ECOXGEAR Ecopebble. Locate the charging port, typically protected by a waterproof seal. Connect the provided USB charging cable to the speaker and a power source (e.g., USB wall adapter, computer USB port). The LED indicator will show charging status and turn off when fully charged.

3.2 Bluetooth Pairing

1. Ensure your Ecopebble is powered on.
2. Activate Bluetooth on your mobile device (smartphone, tablet, etc.).
3. On your device, search for available Bluetooth devices.
4. Select "ECOPEBBLE" from the list.
5. Once paired, the speaker will indicate a successful connection (e.g., an audible tone or steady LED light).

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To power on the Ecopebble, press and hold the Power button until you hear an audible confirmation. To power off, press and hold the Power button again until the speaker shuts down.

4.2 Volume Control

Adjust the volume directly on the Ecopebble using the dedicated volume buttons (+ for increase, - for decrease). You can also control the volume from your connected Bluetooth device.

4.3 Playing Music

Once paired, simply start playing audio from your connected device. The Ecopebble will automatically play the sound. Use your device to control playback (play, pause, skip tracks).

4.4 Speakerphone Function

When a call comes in while connected via Bluetooth, the music will pause. Press the Call button (if available, or the Play/Pause button) on the Ecopebble to answer the call. Speak into the built-in microphone. To end the call, press the Call button again.

5. MAINTENANCE

To ensure the longevity and performance of your ECOXGEAR Ecopebble, follow these maintenance guidelines:

- **Cleaning:** Rinse the speaker with fresh water after exposure to saltwater, sand, or dirt. Use a soft, damp cloth to wipe down the exterior. Do not use harsh chemicals or abrasive cleaners.
- **Waterproof Seal:** Always ensure the charging port cover is securely and tightly closed before exposing the speaker to

water. Failure to do so will compromise its waterproof integrity.

- **Storage:** Store the Ecopebble in a cool, dry place when not in use. Avoid prolonged exposure to extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in constant use.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Battery is drained.	Charge the Ecopebble fully.
No Sound	Volume too low; Not paired; Device issue.	Increase volume on speaker and device. Re-pair Bluetooth. Check audio on source device.
Bluetooth Disconnection/Poor Range	Obstacles; Distance; Interference.	Reduce distance between speaker and device. Remove obstacles. Avoid strong Wi-Fi signals.
Water Leakage	Charging port cover not sealed.	Ensure the charging port cover is tightly secured before water exposure.

7. SPECIFICATIONS

- **Model Number:** GDI-EGPB101
- **Weight:** 8 ounces
- **Battery:** 1 Lithium Ion (included)
- **Battery Life:** Up to 12 hours
- **Connectivity:** Bluetooth
- **Waterproof Rating:** IPX7 (submersible up to 6.6 ft / 2 m)
- **Operating Temperature:** -40°F to 165°F (-40°C to 71°C)
- **Manufacturer:** Grace Digital

8. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the ECOXGEAR Ecopebble's rugged, waterproof, and portable features in various outdoor settings, including off-roading, paddleboarding, and snowy environments. It highlights its durability and versatility.

9. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official ECOXGEAR website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Website: www.ecoxgear.com

© 2023 ECOXGEAR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00PMIF5KK>

More documents and user manuals: <https://manuals.plus/>