

Krinner 94710-EA

Krinner Christmas Tree Genie M Instruction Manual

Model: 94710-EA

1. PRODUCT OVERVIEW

The Krinner Christmas Tree Genie M is an innovative tree stand designed for quick, easy, and secure setup of live Christmas trees. Its unique single-cable operation ensures even pressure around the tree trunk, providing exceptional stability. The integrated water reservoir and level indicator help keep your tree fresh throughout the holiday season.

- Easy one-person setup.
- Suitable for trees up to 7 ft tall with trunk diameters up to 5 inches.
- Water reservoir holds up to 1.2 gallons (4.5 liters) of water.
- Water level indicator for convenient refilling.
- Foot pedal 'DINGS' when the tree is securely positioned.



Figure 1: Krinner Christmas Tree Genie M

KRINNER

The Better Tree Stand



Figure 2: Key features of the Tree Genie M, including tree height capacity and water reservoir size.

2. SETUP INSTRUCTIONS

Follow these steps to set up your Christmas tree securely in the Krinner Tree Genie M stand:

- 1. Prepare the Tree:** Ensure the tree trunk is cut straight and clean at the bottom. Remove any lower branches that might interfere with the stand's clamping mechanism. The trunk diameter should not exceed 5 inches.
- 2. Position the Stand:** Place the Krinner Tree Genie M stand in your desired location, ensuring it is on a flat, stable surface.

3. **Insert the Tree:** Carefully lift the tree and insert its trunk into the center of the stand. Guide the trunk onto the metal spike at the bottom of the reservoir. Ensure the tree is as upright as possible.
4. **Secure the Tree:** While holding the tree upright, repeatedly press the foot pedal down with your foot. The internal claws will tighten around the tree trunk via the single-cable system. Continue pressing until you hear an audible "DING" sound, indicating the tree is securely clamped.




Figure 3: Pressing the foot pedal to secure the tree.

5. **Lock the Pedal:** Once the tree is secure, slide the red safety lock button on the foot pedal to the "locked" position to prevent accidental release.
6. **Add Water:** Fill the water reservoir with fresh water. The water level indicator will rise as you fill it, showing the maximum water level. The reservoir holds up to 1.2 gallons (4.5 liters).



Figure 4: Water reservoir with visible water level indicator.

3. OPERATING INSTRUCTIONS

Using your Krinner Christmas Tree Genie M is straightforward:

- **Watering:** Regularly check the water level indicator. When it drops, refill the reservoir with fresh water to ensure your tree remains hydrated and fresh.
- **Stability Check:** Periodically check the tree's stability. If it feels loose, ensure the foot pedal is locked. If necessary, unlock the pedal, press it a few more times until it "DINGS" again, and then re-lock it.
- **Relocating the Tree:** If you need to move the tree, ensure the foot pedal is locked before attempting to move the stand and tree together. For significant moves, it is recommended to release the tree, move the stand, and then re-secure the tree.

4. MAINTENANCE

Proper maintenance will extend the life of your Krinner Tree Genie M:

- **Cleaning:** After the holiday season, empty any remaining water from the reservoir. Clean the stand with mild soap and water. Rinse thoroughly and allow it to air dry completely before storage.
- **Storage:** Store the tree stand in a cool, dry place away from direct sunlight. Ensure the clamping mechanism is clean and free of debris.
- **Inspection:** Before each use, inspect the single-cable system and the clamping claws for any signs of wear or damage. Do not use the stand if any components appear damaged.

5. TROUBLESHOOTING

Common issues and their solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Tree is not stable.	Foot pedal not fully engaged or locked. Trunk too small/large.	Ensure foot pedal is pressed until it "DINGS" and then locked. Verify trunk diameter is within specifications (up to 5 inches).
Water level indicator not moving.	Indicator stuck or reservoir is full/empty.	Gently tap the indicator. Ensure water is being added or removed. Clean the indicator area if debris is present.
Difficulty inserting tree trunk.	Lower branches obstructing. Trunk too wide.	Trim lower branches. Ensure trunk diameter is within the 5-inch limit.

6. SPECIFICATIONS

Feature	Detail
Brand	Krinner
Model Number	94710-EA
Product Dimensions	5.3"D x 15.5"W x 15.8"H
Color	Green
Material	Metal, Plastic
Item Weight	13 Pounds
Max. Tree Height	7 ft
Max. Trunk Diameter	5 inches
Water Reservoir Capacity	1.2 Gallons (4.5 Liters)
Special Feature	Water Level Indicator

7. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Krinner website or the documentation included with your product.

- **User Manual (PDF):** [Download Here](#)
- **User Guide (PDF):** [Download Here](#)
- **Visit the Krinner Store:** [Krinner Official Store](#)